

Scheppach MS225-56 (20516)

Scheppach MS225-56 Gasoline Lawn Mower User Manual

Model: MS225-56 (Part No. 20516)

[Introduction](#) [Safety Instructions](#) [Setup](#) [Operating](#) [Maintenance](#) [Troubleshooting](#)
[Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Scheppach MS225-56 Gasoline Lawn Mower. Please read this manual thoroughly before operating the machine to ensure proper use and to prevent injury or damage.

Key Features:

- Powerful 224 cm³ 4-stroke gasoline engine with 6 HP.
- XXL cutting width of 56 cm, suitable for gardens up to 2200 m².
- Wheel drive for easy and comfortable mowing.
- Robust 65 L fabric grass catcher box.
- Integrated side and rear discharge, as well as mulching function for professional results.
- Professional gearbox for extra high torque and particularly high performance.
- Integrated cleaning function for quick cleaning.



Figure 1: Scheppach MS225-56 Gasoline Lawn Mower. This image shows the complete lawn mower from a front-side angle, highlighting its robust design and key components like the engine, wheels, and grass catcher.



Figure 2: Overview of 6-in-1 functions. This graphic illustrates the six primary functions of the mower: Mowing, Catching, Mulching, Side Discharge, Cleaning Function, and Wheel Drive.

2. SAFETY INSTRUCTIONS

Always observe the following safety precautions to prevent personal injury and damage to the lawn mower.

General Safety Rules:

- Read and understand all instructions before operating the machine.
- Keep children and bystanders away from the operating area.
- Wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and sturdy footwear.
- Never operate the mower in wet grass or rain.
- Ensure the engine is off and the spark plug cap is removed before performing any maintenance or cleaning.
- Do not refuel the engine while it is running or hot.
- Inspect the area to be mowed and remove any objects that could be thrown by the blade.
- Exercise extreme caution when operating on slopes.

3. SETUP AND ASSEMBLY

Before first use, the lawn mower requires some assembly and preparation.

3.1 Handle Assembly:

Unfold the handle and secure it in the operating position using the provided knobs or levers. Ensure all connections are tight.

Durch den klappbaren Handgriff ist der Rasenmäher platzsparend und einfach zu transportieren.



Figure 3: Folding the handle for compact storage or transport. The image shows a person folding the handle of the lawn mower, demonstrating its space-saving design.

3.2 Grass Catcher Box Assembly:

Assemble the fabric grass catcher box according to the instructions. Once assembled, attach it securely to the rear of the mower.

3.3 Adding Fuel and Oil:

Fill the engine with the recommended type and amount of engine oil. Then, fill the fuel tank with fresh, unleaded gasoline. Refer to the engine manual for specific oil and fuel requirements.

3.4 Adjusting Cutting Height:

The central cutting height adjustment allows for 7 different positions, ranging from 25 mm to 75 mm. Adjust the lever to your desired cutting height before starting the mower.

Die zentrale Schnitthöhenverstellung erfolgt in 7 Stufen von 25-75 mm.



Figure 4: Central cutting height adjustment. This image shows a hand operating the lever to adjust the cutting height, with an inset graphic indicating the 7 height settings from 25-75 mm.

3.5 Installing Side Discharge:

For side discharge operation, lift the side cover and insert the side discharge chute. Ensure it is securely in place. This can be easily mounted or dismounted as needed.

Der Seitenauswurf lässt sich bei Bedarf leicht montieren bzw. demontieren.



Figure 5: Installation of the side discharge chute. A person is shown attaching the red side discharge cover to the mower, demonstrating how it can be easily installed or removed.

4. OPERATING INSTRUCTIONS

4.1 Starting the Engine:

1. Ensure the spark plug cap is firmly attached.
2. Push the primer bulb (if equipped) a few times until fuel is visible.
3. Move the throttle lever to the "START" or "CHOKE" position.
4. Pull the starter cord firmly until the engine starts.
5. Once started, move the throttle to the "RUN" position.

4.2 Mowing Techniques:

The Scheppach MS225-56 offers multiple mowing options:

- **Collecting:** Attach the grass catcher box to collect clippings.
- **Mulching:** Remove the grass catcher and side discharge chute. The mower will finely chop grass clippings and return them to the lawn as natural fertilizer.
- **Side Discharge:** Attach the side discharge chute to eject clippings to the side, useful for taller grass or areas where collection is not desired.




Figure 6: Application examples for mowing, catching, and mulching. This graphic illustrates the different grass cutting and discharge methods available with the mower.

4.3 Using the Wheel Drive:

The integrated wheel drive assists during mowing, especially on steeper lawn areas, providing optimal support and reducing effort.

Der Radantrieb unterstützt während des Mähvorgangs optimal – besonders an steileren Rasenflächen.



Figure 7: Engaging the wheel drive. A hand is shown operating the lever for the wheel drive, indicating its ease of use for assisted mowing.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lawn mower.

5.1 Cleaning:

The mower features an integrated cleaning function for quick and easy cleaning of the cutting deck. Connect a garden hose to the designated port, start the engine, and let the rotating blade clean the underside.

Easy Clean - Reinigungsfunktion mit Wasseranschluss.



Figure 8: Easy Clean function with water connection. This image shows a garden hose connected to the mower's cleaning port, demonstrating the integrated cleaning feature.

5.2 Blade Care:

Regularly inspect the cutting blade for sharpness and damage. A dull blade can tear grass, leading to an unhealthy lawn. Sharpen or replace the blade as needed. Always disconnect the spark plug before working on the blade.

5.3 Engine Maintenance:

Periodically check and change the engine oil, clean or replace the air filter, and inspect the spark plug. Refer to the engine manual for detailed service intervals.

5.4 Storage:

Before storing the mower for extended periods, especially during off-season, ensure the fuel tank is empty or treated with a fuel stabilizer. Clean the mower thoroughly and store it in a dry, protected area. The foldable handle allows for space-saving storage.

6. TROUBLESHOOTING

This section provides solutions to common operational issues. For problems not listed here, contact authorized service personnel.

Problem	Possible Cause	Solution
Engine does not start	No fuel; old fuel; spark plug issue; clogged air filter	Add fresh fuel; replace fuel; clean/replace spark plug; clean/replace air filter
Mower cuts unevenly	Dull or bent blade; incorrect cutting height setting; uneven terrain	Sharpen/replace blade; adjust cutting height; mow on level ground
Excessive vibration	Bent blade; loose components; engine imbalance	Inspect/replace blade; tighten all fasteners; consult service center
Engine loses power	Clogged air filter; old fuel; low oil level; dirty spark plug	Clean/replace air filter; use fresh fuel; check/add oil; clean/replace spark plug

7. TECHNICAL SPECIFICATIONS


Below are the key technical specifications for the Scheppach MS225-56 Lawn Mower:

Feature	Specification
Model	MS225-56 (Part No. 20516)
Engine Type	224 cm³ 4-stroke gasoline engine
Engine Power	6 HP
Cutting Width	56 cm
Cutting Height Adjustment	7 positions (25 - 75 mm)
Grass Catcher Volume	65 L
Recommended Lawn Area	Up to 2200 m²
Drive Type	Wheel drive (Self-propelled)
Functions	Mowing, Catching, Mulching, Side Discharge, Cleaning Function
Product Dimensions (L x W x H)	161T x 70B x 114H cm
Item Weight	38 Kilograms

Rasenfläche



Schnitthöhe und -breite



65 L Fangbox



Easy Clean




Figure 9: Key specifications overview. This graphic summarizes the recommended lawn area (2200 m²), cutting width (560 mm), cutting height range (25-75 mm), grass box capacity (65 L), and the Easy Clean function.

8. WARRANTY AND SUPPORT

Scheppach products are manufactured with high-quality materials and undergo strict quality controls. In the unlikely event of a defect, please refer to your purchase documentation for warranty terms and conditions.

Customer Support:

For technical assistance, spare parts, or service inquiries, please contact your authorized Scheppach dealer or visit the official Scheppach website for contact information. When contacting support, please have your model number (MS225-56) and serial number (if applicable) ready.

You can find more information and support resources on the official Scheppach website: www.scheppach.com



Related Documents - MS225-56 (20516)

	<p>Scheppach MS225-56 Bedienungsanleitung Benzin-Rasenmäher</p> <p>Umfassende Bedienungsanleitung für den Scheppach MS225-56 Benzin-Rasenmäher. Enthält Sicherheitshinweise, Montageanleitungen, Betriebsinformationen und Wartungstipps für eine sichere und effiziente Nutzung.</p>
	<p>scheppach MS225-53E Benzin Rasenmäher Bedienungsanleitung</p> <p>Umfassende Bedienungsanleitung für den scheppach MS225-53E Benzin Rasenmäher. Enthält Sicherheitshinweise, Montage, Bedienung, Wartung und Fehlerbehebung für optimale Leistung und Langlebigkeit.</p>
	<p>Scheppach MS225-53 Benzin Rasenmäher Bedienungsanleitung</p> <p>Umfassende Bedienungsanleitung für den Scheppach MS225-53 Benzin-Rasenmäher. Enthält Informationen zu Betrieb, Sicherheit, Wartung, Montage, Fehlerbehebung und technischen Daten für den Einsatz im privaten Garten.</p>
	<p>Scheppach MR224-61 Bedienungsanleitung</p> <p>Offizielle Bedienungsanleitung für den Scheppach MR224-61 Benzin-Aufsitzrasenmäher. Enthält detaillierte Informationen zur sicheren Bedienung, Montage, Wartung, Fehlerbehebung und technischen Daten für Ihre Scheppach Rasenpflegegeräte.</p>
	<p>Scheppach LBH2600P Bedienungsanleitung Laubbläser & Sauger</p> <p>Umfassende Bedienungsanleitung für den Scheppach LBH2600P Laubbläser und -sauger. Bietet detaillierte Anleitungen zu Montage, sicherer Bedienung, Wartung und Fehlerbehebung für dieses Gartengerät.</p>



[scheppach PCS56 Benzin-Kettensäge: Betriebsanleitung](#)

Die offizielle Betriebsanleitung für die scheppach PCS56 Benzin-Kettensäge. Enthält wichtige Informationen zur sicheren Bedienung, Wartung und Fehlerbehebung für optimale Leistung und Langlebigkeit.