Béaba 5-in-1 Multi Milk

BEABA 5-in-1 Multi Milk Baby Bottle and Food Warmer Instruction Manual

Model: 5-in-1 Multi Milk

1. Introduction

Thank you for choosing the BEABA 5-in-1 Multi Milk Baby Bottle and Food Warmer. This appliance is designed to safely and efficiently warm baby bottles, breastmilk, and baby food, as well as defrost and sterilize items. Please read this manual thoroughly before first use and retain it for future reference.





Image 1.1: The BEABA 5-in-1 Multi Milk Baby Bottle and Food Warmer with a baby bottle being warmed.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- · Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Always ensure the water level is correct for the selected function.
- Always check the temperature of the warmed food or liquid before feeding to a baby.

3. PRODUCT COMPONENTS

The BEABA 5-in-1 Multi Milk Warmer includes the following parts:

- · Main Warmer Unit with Digital Touch Screen Display
- · Removable Support Basket
- · Steam Lid



Image 3.1: Exploded view of the BEABA 5-in-1 Multi Milk Warmer components.

4. SETUP

- 1. **Unpack:** Carefully remove all components from the packaging.
- 2. **Clean:** Before first use, clean the removable support basket and steam lid with warm soapy water. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
- 3. Placement: Place the warmer on a stable, flat, heat-resistant surface, away from direct sunlight or heat sources.
- 4. Power Connection: Plug the power cord into a suitable electrical outlet. The digital display will illuminate.

5. OPERATING INSTRUCTIONS

The BEABA 5-in-1 Multi Milk Warmer features a digital touch screen for easy operation. It offers five distinct modes:



5.1. Water Bath Mode (Gentle Warming for Breastmilk)

This mode uses a gentle water bath to warm breastmilk, preserving its nutrients. It is also suitable for formula or baby food that requires slow, even heating.

- 1. Place the bottle or food jar into the removable support basket.
- 2. Add water to the warmer unit, ensuring the water level is below the rim of the bottle/jar and covers the contents to be warmed.
- 3. Place the support basket with the bottle/jar into the warmer.
- 4. Select the Water Bath mode icon on the digital display.
- 5. Adjust the desired temperature and warming time using the '+' and '-' buttons. Refer to the recommended warming times in the table below (if provided in product documentation).
- 6. Press the start button to begin warming. The warmer will automatically shut off when the cycle is complete.
- 7. Carefully remove the bottle/jar using the support basket handle. Always check the temperature before feeding.

5.2. Fast Warming Mode (Steam Heating)

This mode uses steam to quickly heat bottles. It is ideal for formula or water for formula preparation.

- 1. Place the bottle into the removable support basket.
- 2. Add the recommended amount of water for steam warming (usually a small amount, refer to specific instructions for exact volume).
- 3. Place the support basket with the bottle into the warmer.
- 4. Cover with the steam lid.
- 5. Select the Fast Warming mode icon on the digital display.
- 6. Adjust the desired warming time using the '+' and '-' buttons.
- 7. Press the start button. The warmer will generate steam to heat the bottle rapidly.
- 8. Once complete, carefully remove the bottle using the support basket handle. Be cautious of hot steam. Always check the temperature before feeding.

5.3. Defrost Mode

This mode gently thaws frozen breastmilk or baby food.



Image 5.2: Defrosting a breastmilk storage bag in the BEABA warmer.

- 1. Place the frozen breastmilk bag or baby food container into the removable support basket.
- 2. Add water to the warmer unit, ensuring the water level is appropriate for defrosting.
- 3. Place the support basket with the item into the warmer.
- 4. Select the Defrost mode icon.
- 5. Adjust the defrosting time as needed.
- 6. Press the start button. The warmer will gently thaw the contents.
- 7. Once complete, remove the item and check for complete thawing.

5.4. Baby Food Warmer Mode

This mode is specifically designed for warming baby food jars or containers.



Image 5.3: Warming a baby food jar in the BEABA warmer.

- 1. Place the baby food jar or container into the removable support basket.
- 2. Add water to the warmer unit, ensuring the water level is appropriate for warming the food.
- 3. Place the support basket with the food into the warmer.
- 4. Select the Baby Food Warmer mode icon.
- 5. Adjust the desired warming time and temperature.
- 6. Press the start button.
- 7. Once complete, carefully remove the food and stir thoroughly. Always check the temperature before feeding.

5.5. Sterilization Mode

This mode uses steam to sterilize small items like pacifiers, bottle nipples, or small bottle parts.

- 1. Place the clean items to be sterilized into the removable support basket.
- 2. Add the recommended amount of water for sterilization (usually a small amount, refer to specific instructions for exact volume).
- 3. Place the support basket with items into the warmer.
- 4. Cover with the steam lid.
- 5. Select the Sterilization mode icon.
- 6. Press the start button. The warmer will generate steam to sterilize the items.
- 7. Once complete, allow items to cool before carefully removing them.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your warmer.

- Always unplug the appliance and allow it to cool completely before cleaning.
- Main Unit: Wipe the exterior with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- Removable Parts: The support basket and steam lid can be washed with warm soapy water and rinsed thoroughly. They are generally dishwasher-safe (top rack only), but refer to specific product instructions for confirmation.
- **Descaling:** Over time, mineral deposits (limescale) may build up in the heating chamber. To descale, mix 50ml of white vinegar with 100ml of cold water and pour into the heating chamber. Let it stand for 30 minutes (do not heat). Pour out the solution and rinse the chamber thoroughly with clean water. Repeat if necessary. Descale regularly, especially in areas with hard water.
- Storage: When not in use, ensure the warmer is clean and dry. Store it in a cool, dry place.

7. TROUBLESHOOTING

If you encounter issues with your BEABA 5-in-1 Multi Milk Warmer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Warmer does not turn on.	Not plugged in; power outlet issue; damaged cord.	Ensure the warmer is securely plugged into a working outlet. Check the power cord for damage.

Problem	Possible Cause	Solution
Food/milk not warming sufficiently.	Insufficient water; incorrect time/temperature setting; limescale buildup.	Add more water to the heating chamber. Increase warming time or temperature. Descale the unit.
Warmer produces excessive steam/boiling.	Too much water; incorrect mode selected; too high temperature setting.	Reduce water volume. Ensure the correct mode is selected. Lower the temperature setting.
Digital display not responding.	Temporary electronic glitch.	Unplug the unit for a few minutes, then plug it back in to reset.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

• Product Dimensions: 5.3 x 5.1 x 11.7 inches

• Material Composition: Plastic

• Item Weight: 1.71 pounds

• Power: [Not specified in input, placeholder if needed]

• Model: 5-in-1 Multi Milk

9. WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please visit the official Béaba website or contact their customer service department. Keep your proof of purchase for warranty claims.

Béaba Official Website: www.beaba.com

© 2025 Béaba. All rights reserved.

Related Documents



Béaba Multi Milk Bottle Warmer Instructions and Safety Guide

Comprehensive guide to the Béaba Multi Milk bottle warmer, covering setup, usage, safety precautions, and troubleshooting for various warming modes like steam, bain-marie, defrost, and sterilization.



BÉABA MILK PREP User Manual and Instructions

The BÉABA MILK PREP is designed to simplify the preparation of baby bottles and other milk-based beverages. This comprehensive guide offers essential information for safe and effective use, covering operation, key safety features, cleaning procedures, and troubleshooting tips.



BÉABA BABYCOOK® Duo Instructions and Guide

Comprehensive instructions and guide for the BÉABA BABYCOOK® Duo, detailing its features, operation, maintenance, and troubleshooting for preparing baby food.



BEABA Flower Foldable Bottle Drying Rack - Compact, High Capacity

Discover the BEABA Flower Foldable Bottle Drying Rack. This compact and portable drying rack holds up to 8 baby bottles and accessories, making it ideal for small spaces and travel. Easy to fold and store.