Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Lorelli /
- Lorelli First Tricycle Instruction Manual Model 1005059

Lorelli 1005059

Lorelli First Tricycle Instruction Manual

Model: 1005059

1. Introduction

Thank you for choosing the Lorelli First Tricycle. This manual provides important information for the safe and proper use, assembly, and maintenance of your tricycle. Please read it thoroughly before initial use and retain it for future reference.

The Lorelli First Tricycle is designed for children aged 3 to 5 years, with a maximum weight capacity of 20 kg. It features an ergonomic seat, an integrated bell, durable EVA tires, a mudguard, non-slip pedals, and soft rubber grips for a comfortable and secure riding experience.



Figure 1: Lorelli First Tricycle, White

2. Important Safety Information

WARNING: Not suitable for children under 36 months (3 years) due to small parts and potential fall hazard.

- Always supervise children when they are using the tricycle.
- Ensure all parts are securely fastened before each use. Regularly check for loose screws or damaged components.
- The tricycle is intended for use on flat, even surfaces. Avoid slopes, stairs, or uneven terrain.
- Do not use near traffic, swimming pools, or other hazardous areas.
- Children should wear appropriate safety gear, including a helmet, when riding.
- The maximum weight capacity for this tricycle is 20 kg. Do not exceed this limit.
- This product does not have brakes; braking is performed by the child's feet. Ensure the child understands how to stop safely.

3. Package Contents

Upon opening the package, please verify that all components are present and undamaged:

- Tricycle Frame (main body)
- · Front Wheel with Mudguard and Pedals
- Rear Wheels (2 units)
- · Handlebars with Bell and Soft Rubber Grips
- · Ergonomic Seat
- Assembly Hardware (if applicable, e.g., screws, washers)

If any parts are missing or damaged, please contact customer support before assembly or use.

4. Initial Setup and Safety Checks

The Lorelli First Tricycle is designed for minimal assembly. Please follow these steps for initial setup and safety verification:

- 1. **Unpack Components:** Carefully remove all parts from the packaging.
- 2. **Handlebar Installation:** Insert the handlebar stem into the front fork tube. Ensure it is aligned correctly and tighten any securing bolts firmly. Check that the bell is securely attached to the handlebars.
- 3. **Seat Adjustment:** The ergonomic seat can be adjusted to two positions. Select the position that best suits the child's height, ensuring their feet can comfortably reach the pedals. Secure the seat firmly in place.
- 4. Wheel Check: Verify that all three EVA wheels are securely attached and rotate freely without excessive wobble. Tighten any visible fasteners if necessary.
- 5. **Pedal Check:** Ensure the non-slip pedals are firmly attached to the front wheel axle.
- 6. **Overall Stability:** Gently shake the tricycle to confirm all connections are tight and there are no loose parts.



Figure 2: Tricycle Dimensions (Length: 74 cm, Width: 48 cm, Height: 55 cm)

5. Operating Instructions

Once the tricycle is assembled and safety checks are complete, the child can begin to use it under adult supervision.

- **Riding:** Instruct the child to sit on the ergonomic seat, place their feet on the non-slip pedals, and grasp the soft rubber grips on the handlebars. They can propel the tricycle by pedaling forward.
- Steering: The handlebars allow the child to steer the front wheel, guiding the tricycle's direction.
- **Braking:** This tricycle does not have hand brakes. The child should be taught to stop by placing their feet on the ground.
- Bell Usage: The integrated bell can be used to alert others to the child's presence.

Features Overview:



Rutschfeste Pedale

Non-slip pedals






Non-slip pedals provide secure foot placement.




Weiche Gummi-Griffe

Soft rubber grips





Soft rubber grips and an ergonomic seat ensure comfort.



Integrated mudguard and bell for safety and cleanliness.

6. Maintenance

Regular maintenance helps ensure the longevity and safe operation of the tricycle.

- **Cleaning:** Clean the tricycle with a damp cloth and mild soap. Avoid abrasive cleaners or solvents. Dry thoroughly after cleaning.
- **Inspection:** Periodically inspect all bolts, nuts, and fasteners to ensure they are tight. Check for any signs of wear, cracks, or damage to the frame, wheels, seat, or handlebars.
- Tire Care: The EVA tires are maintenance-free and do not require inflation. Keep them free from debris.
- **Storage:** Store the tricycle in a dry, cool place, away from direct sunlight and extreme temperatures, to prevent material degradation.

7. Troubleshooting

If you encounter issues with your Lorelli First Tricycle, refer to the following common problems and solutions:

- Loose Wheels/Wobble: If wheels feel loose or wobble, check the axle bolts and tighten them securely. Ensure all retaining clips or caps are properly in place.
- **Difficulty Steering:** Check that the handlebar stem is properly inserted and tightened. Ensure no debris is obstructing the steering mechanism.
- **Pedals Not Turning:** Inspect the pedals for any obstructions or damage. Ensure they are securely attached to the front wheel axle.
- **General Instability:** Re-check all assembly points, especially the handlebar and seat connections, to ensure they are fully tightened according to the initial setup instructions.

If problems persist after attempting these solutions, please contact customer support.

8. Product Specifications

Feature	Specification
Brand	Lorelli
Model Number	1005059
Recommended Age	36 months - 5 years
Maximum Weight Capacity	20 Kilograms
Product Dimensions (L x W x H)	74 x 48 x 55 cm
Item Weight	3.5 Kilograms
Main Material	Plastic
Color	White
Assembly Required	No (minimal setup/checks)



Dreirad First





Figure 3: Age and Weight Recommendations

9. Warranty and Customer Support

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. Lorelli is committed to product quality and customer satisfaction.

If you have any questions, require assistance, or need to report a problem with your Lorelli First Tricycle, please contact the retailer where the product was purchased or visit the official Lorelli website for customer support contact details.



Lorelli DALLAS Children Tricycle - Manual Instruction and Safety Guide

Official manual instructions and safety guidelines for the Lorelli DALLAS children's tricycle. Learn about assembly, usage, and safety requirements for children aged 24-72 months.



Lorelli Navigator Car Seat Manual

Instruction manual for the Lorelli Navigator car seat, covering installation and usage for Groups 1, 2, and 3 (9-36 kg).



Lorelli Draxter Scooter - User Manual and Instructions

Comprehensive user manual for the Lorelli Draxter scooter, designed for children up to 20kg. Provides essential information on assembly, safe operation, maintenance, and troubleshooting.



Lorelli LYNX Isofix Car Seat: User Manual & Installation Guide

Comprehensive instruction manual for the Lorelli LYNX Isofix child car seat. Learn about installation, safety features, and usage guidelines for children from birth up to 12 years. Ensure safe travel with Lorelli.



EXPEDITION

Lorelli EXPEDITION Car Seat: i-Size Safety Manual & Installation Guide

Comprehensive user manual for the Lorelli EXPEDITION i-Size car seat. Find detailed instructions for installation, safe usage, and maintenance for children 100-150 cm. Visit www.lorelli.eu for more information.







Lorelli VIOLA 3 in 1 Stroller: Manual Instruction, Safety, and Assembly Guide

Comprehensive user manual for the Lorelli VIOLA 3 in 1 stroller. Includes safety guidelines, assembly instructions, parts list, operation details, and maintenance tips for safe and optimal use.