



Manuals.plus /

› **Ninja** /

› Ninja DualBrew Pro Hot & Iced Coffee Maker Instruction Manual

Ninja CFP105CO

Ninja DualBrew Pro Hot & Iced Coffee Maker Instruction Manual

Model: CFP105CO | Brand: Ninja

PRODUCT OVERVIEW

The Ninja CFP105 DualBrew 14-Cup Hot and Iced Coffee Maker is a versatile system designed for both ground coffee and K-Cup pods. It offers 10 brew sizes for grounds (XS Cup, Small Cup, Cup, XL Cup, Travel Mug, XL Travel Mug, ¼ Carafe, ½ Carafe, ¾ Carafe, or Full Carafe) and 4 traditional pod brew sizes (6, 8, 10, or 12 oz.). This coffee maker features an easy cleaning function, dishwasher-safe parts, and a removable Ninja pod adapter for thorough cleaning. Users can select from Classic, Rich, or Over Ice brew styles. The Over Ice function ensures flavorful iced coffee that is not watered down. An adjustable warming plate keeps coffee warm for up to 4 hours. The 70-oz. removable water reservoir allows for convenient filling, and a foldable single-serve platform minimizes splashing. Thermal Flavor Extraction Duo technology ensures optimal flavor for both grounds and pods through even saturation and precise temperature control.



Figure 1: The Ninja DualBrew Pro Coffee Maker, showcasing the main unit with the glass carafe and the detached removable water reservoir.

KEY FEATURES

- **Dual Coffee System:** Brews both ground coffee and K-Cup pods.
- **Multiple Brew Sizes:** 10 sizes for grounds (XS Cup to Full Carafe) and 4 for pods (6, 8, 10, 12 oz.).
- **3 Brew Styles:** Choose from Classic, Rich, or Over Ice for customized coffee.
- **Iced Coffee Function:** Specifically designed to brew over ice without dilution.
- **Keep Warm Function:** Adjustable warming plate maintains coffee temperature for up to 4 hours.
- **70-oz. Removable Water Reservoir:** Large capacity for multiple brews and easy refilling.
- **Foldable Single Serve Platform:** Elevates smaller cups to prevent splashing.
- **Thermal Flavor Extraction Duo:** Ensures optimal flavor through even saturation and precise temperature control.
- **Easy Cleaning:** Features a dedicated clean function, dishwasher-safe parts, and a removable pod adapter for convenient maintenance.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Ensure all parts listed in the "What's Included" section are present.

2. **Initial Cleaning:** Before first use, wash the glass carafe, removable water reservoir, brew basket, and Ninja pod adapter with warm, soapy water. Rinse thoroughly and dry.
3. **Positioning:** Place the coffee maker on a clean, dry, and level surface. Ensure adequate clearance above the unit for opening the brew head.
4. **Fill Water Reservoir:** Fill the 70-oz. removable water reservoir with fresh, filtered water up to the "FULL" line. Place it securely back onto the unit.
5. **First Clean Cycle:** Perform a clean cycle without coffee to prime the system. Refer to the "Maintenance & Cleaning" section for detailed instructions on running a clean cycle.



Figure 2: The Ninja DualBrew Pro Coffee Maker with its removable water reservoir detached, illustrating ease of filling and cleaning.

OPERATING INSTRUCTIONS

Brewing Ground Coffee:

1. **Prepare Brew Basket:** Open the brew head. Insert the grounds adapter brew basket into the brew head.
2. **Add Grounds:** Use the Ninja Smart Scoop to add your desired amount of ground coffee to the filter. Close the brew head securely.
3. **Select Brew Size:** Place the 14-cup glass carafe on the warming plate. Use the control panel to select your desired brew size (e.g., Full Carafe).
4. **Choose Brew Style:** Select your preferred brew style: Classic, Rich, or Over Ice.
5. **Start Brewing:** Press the BREW button to begin. The machine will automatically dispense coffee into the carafe.

Brewing K-Cup Pods:

1. **Insert Pod Adapter:** Ensure the Ninja Pod Adapter is securely in place within the brew head.
2. **Insert K-Cup:** Lift the handle and insert a K-Cup pod into the adapter. Close the handle firmly until the pod is punctured.
3. **Place Cup:** Place your coffee mug on the foldable single-serve platform.
4. **Select Brew Size:** Use the control panel to select your desired pod brew size (6, 8, 10, or 12 oz.).
5. **Choose Brew Style:** Select your preferred brew style: Classic, Rich, or Over Ice.
6. **Start Brewing:** Press the BREW button. The machine will dispense coffee directly into your mug.



Figure 3: The coffee maker in action, demonstrating its ability to brew into both a single mug and the glass carafe simultaneously.



Figure 4: A close-up view of the foldable single-serve platform, designed to accommodate various cup sizes and prevent splashing.

MAINTENANCE & CLEANING

Regular cleaning ensures optimal performance and longevity of your Ninja DualBrew Pro Coffee Maker.

- **Daily Cleaning:**

- Wash the glass carafe, brew basket, and Ninja pod adapter with warm, soapy water after each use. These parts are also dishwasher-safe.
- Wipe down the exterior of the machine with a damp cloth.

- **Deep Cleaning (Descaling):**

The machine has a dedicated "Clean" function. When the "CLEAN" indicator illuminates, it's time to descale the unit. This process removes mineral buildup and ensures proper operation.

- a. Empty the water reservoir.
- b. Pour 16 oz. of white vinegar into the water reservoir, then fill the rest with water up to the "FULL" line.

- c. Place the empty carafe on the warming plate.
- d. Press the "CLEAN" button. The cleaning cycle will begin and typically takes about 20 minutes.
- e. Once the cycle is complete, discard the vinegar solution.
- f. Rinse the water reservoir thoroughly and fill it with fresh water. Run two full carafe cycles with plain water to rinse out any remaining vinegar.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee is too weak/strong	Incorrect coffee-to-water ratio; wrong brew style selected.	Adjust the amount of coffee grounds or select a different brew style (e.g., "Rich" for stronger coffee). Ensure correct brew size is selected.
"CLEAN" light stays on after cleaning	Descaling cycle not completed properly or mineral buildup is severe.	Ensure the descaling solution was used correctly and the full clean cycle ran. If necessary, repeat the descaling process.
Coffee not brewing	Water reservoir empty; brew head not closed; pod not punctured (for K-Cups).	Fill water reservoir. Ensure brew head is fully closed. For K-Cups, ensure the handle is pressed down firmly to puncture the pod.
Watered-down iced coffee	"Over Ice" brew style not selected.	Always select the "Over Ice" brew style when making iced coffee to ensure proper concentration.

SPECIFICATIONS

Brand: Ninja

Model Name: NINJA CFP105CO

Product Dimensions: 12.49"D x 9.94"W x 11.03"H

Color: Black

Coffee Maker Type: Drip Coffee Machine

Filter Type: Reusable

Coffee Input Type: Grounds and Pods

Water Reservoir Capacity: 70 oz.

Voltage: 120 Volts

Special Features: Auto Shut-Off, Cup Warmer, Dishwasher Safe Parts, Permanent Filter, Timer

Item Weight: 9.1 pounds

UPC: 732388001316

WARRANTY & SUPPORT

This product is a renewed item and is backed by a 90-day warranty. For any issues or support needs, please refer to the original seller or Amazon Renewed support channels.

For further assistance, please visit the [Amazon Renewed Store](#) or contact their customer service.

