

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Imetec](#) /
- › [Imetec RapidVapor Plus Steam Iron User Manual](#)

Imetec 9044

Imetec RapidVapor Plus Steam Iron User Manual

Model: 9044

[Introduction](#)

[Safety Information](#)

[Product Overview](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

Congratulations on your purchase of the Imetec RapidVapor Plus Steam Iron. This appliance is designed to make your ironing experience fast, efficient, and effortless. Featuring a 1.2 L removable water tank for uninterrupted ironing, a fluid ceramic soleplate for smooth gliding, and Calc Clean technology for extended longevity, the RapidVapor Plus is engineered for optimal performance on all fabric types. Please read this manual carefully before first use to ensure safe operation and to achieve the best results from your new steam iron.



Figure 1: Imetec RapidVapor Plus Steam Iron and its packaging. The image shows the iron unit with its water tank and the product box in the background, illustrating the complete product presentation.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before using the iron.
- Do not leave the iron unattended while it is connected to the power supply or on an ironing board.
- Always unplug the iron from the electrical outlet when filling with water, emptying, or when not in use.
- Do not operate the iron with a damaged cord or if the iron has been dropped or damaged. Contact customer service for repair.
- Keep the iron and its cord out of reach of children.
- Use the iron only for its intended purpose.
- Do not immerse the iron or its base in water or other liquids.

- The iron must be used and rested on a stable surface.
- Never direct steam at people or pets.

3. PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the different parts of your Imetec RapidVapor Plus steam iron for optimal use.



Un repassage rapide.
Tout de suite prêt, puissant et léger.

Figure 2: Person ironing with the Imetec RapidVapor Plus steam iron, highlighting its quick, powerful, and lightweight design. This image shows the iron in action, demonstrating its ergonomic handle and steam output.

Key Components:

- **Ceramic Soleplate:** Designed for smooth gliding across all fabric types.
- **Water Tank (1.2 L):** Removable for easy refilling, allowing for uninterrupted ironing sessions.
- **Temperature Control Dial:** Adjusts heat settings for different fabrics.

- **Steam Button/Trigger:** Activates steam output.
- **Calc Clean Indicator:** Alerts when descaling is needed.
- **Power Cord:** Connects the iron to the electrical outlet.



Figure 3: Close-up of the Imetec RapidVapor Plus ceramic soleplate gliding smoothly over fabric. The image emphasizes the ceramic coating and its ability to move effortlessly across garments.

4. SETUP AND FIRST USE

Before using your Imetec RapidVapor Plus steam iron for the first time, follow these steps:

1. **Unpack:** Remove all packaging materials and labels from the iron.
2. **Clean Soleplate:** Wipe the soleplate with a soft, damp cloth to remove any manufacturing residues.
3. **Fill Water Tank:**

- Ensure the iron is unplugged.
- Remove the 1.2 L water tank by pulling it gently from the base.
- Fill the tank with tap water up to the 'MAX' indicator. Distilled or demineralized water is recommended to prolong the life of the iron, especially in areas with hard water.
- Reinsert the water tank firmly until it clicks into place.

4. **Position:** Place the iron on a stable, heat-resistant ironing board.

5. **Plug In:** Connect the power cord to a grounded electrical outlet.



Figure 4: The removable 1.2 L water tank of the Imetec RapidVapor Plus, shown being detached from the main unit. This design allows for easy and continuous refilling during ironing sessions.

5. OPERATING INSTRUCTIONS

The Imetec RapidVapor Plus is ready for use in just 1 minute, providing ultra-fast and efficient ironing.

5.1. Temperature Settings

1. Turn the temperature control dial to the desired setting based on the fabric type. Refer to the garment's care label.
2. Allow the iron to heat up. The indicator light will turn off when the set temperature is reached.

5.2. Steam Ironing

For effective steam ironing, ensure the water tank is filled and the iron is heated to a suitable temperature (usually indicated by the steam symbol on the dial).

- Press the steam button/trigger to release a continuous flow of steam.
- For stubborn creases, use the powerful 300g steam shot by pressing the steam button firmly. The iron operates at 5.5 bar pressure for excellent steam penetration.
- The fluid ceramic soleplate ensures smooth gliding and even heat distribution, making ironing easier.



Figure 5: Imetec RapidVapor Plus demonstrating powerful steam performance with 5.5 bar pressure and 300g steam shot. The image shows steam being emitted from the iron while in use, with icons indicating pressure and steam output.

5.3. Dry Ironing

For dry ironing, ensure the water tank is empty or the steam function is turned off. Set the temperature according to the fabric type.

5.4. Continuous Refill

The 1.2 L removable water tank allows for continuous refilling during ironing, ensuring uninterrupted sessions. Simply remove the tank, refill, and reinsert it without needing to turn off or unplug the iron.

6. MAINTENANCE AND CARE

Regular maintenance ensures the longevity and optimal performance of your Imetec RapidVapor Plus steam iron.

6.1. Calc Clean Technology

The iron features Calc Clean technology with two integrated filters and a self-cleaning ceramic plate to protect against limescale buildup. An audible reminder will sound when cleaning is necessary.

1. When the Calc Clean indicator activates, ensure the iron is cool and unplugged.
2. Follow the specific descaling instructions provided in the full manual (if available) or consult the Imetec website for detailed steps. Generally, this involves emptying the tank, filling with a descaling solution (or water for self-clean), heating the iron, and then flushing out the steam and water.
3. Regular descaling helps maintain steam performance and extends the life of the appliance.



Figure 6: Detail of the Imetec RapidVapor Plus iron's Calc Clean technology, showing the 'CALC CLEAN' marking on the iron's body. This feature helps prevent limescale buildup for consistent performance.

6.2. Cleaning the Soleplate

- Ensure the iron is cool and unplugged.
- Wipe the ceramic soleplate with a soft, damp cloth. Do not use abrasive cleaners or metallic scouring pads, as these can damage the surface.
- For stubborn marks, a specialized soleplate cleaning stick can be used, following its instructions.

6.3. Storage

- Always empty the water tank after each use.
- Allow the iron to cool completely before storing.
- Store the iron in an upright position to prevent damage to the soleplate.
- Wrap the power cord neatly around the base or use the designated cord storage if available.



Repassage ultra-rapide, grande efficacité

Figure 7: Imetec RapidVapor Plus iron on an ironing board next to neatly folded laundry, illustrating fast and efficient ironing results. This image also shows the compact storage of the iron unit.

7. TROUBLESHOOTING

If you encounter issues with your Imetec RapidVapor Plus, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet fault; temperature dial set to minimum.	Check power connection; test outlet with another appliance; turn temperature dial to a higher setting.

Problem	Possible Cause	Solution
No steam or insufficient steam.	Water tank empty; temperature too low for steam; Calc Clean needed; steam vents blocked.	Refill water tank; increase temperature setting; perform Calc Clean procedure; clean soleplate vents.
Water leaking from soleplate.	Temperature too low for steam; overfilled water tank; iron not hot enough before steam use.	Increase temperature; do not overfill tank; allow iron to fully heat up before using steam.
Calc Clean indicator is on.	Limescale buildup detected.	Perform the Calc Clean descaling procedure as per instructions.

If the problem persists after trying these solutions, please contact Imetec customer support.

8. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Imetec
Model Number	9044
Color	Grey with Blue Details
Product Dimensions (L x W x H)	36 x 18 x 0.1 cm
Item Weight	2.5 Kilograms
Automatic Shut-off Function	No
Special Features	Unlimited autonomy, Fast heating, Temperature control, Uniform heat distribution, Removable water tank
Base Material	Ceramic
Frequency	50 Hz
Model Year	2024
Water Tank Capacity	1.2 Liters

9. WARRANTY AND SUPPORT





Your Imetec RapidVapor Plus Steam Iron is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions.

- **Spare Parts Availability:** 2 Years.

- For technical assistance, repairs, or to inquire about spare parts, please visit the official Imetec website or contact their customer service department.
- Keep your proof of purchase for warranty claims.

© 2024 Imetec. All rights reserved.

Related Documents - 9044

	<p>IMETEC Sistema Stirante S3901: Guida Completa all'Uso e alla Sicurezza</p> <p>Scopri come utilizzare al meglio il tuo IMETEC Sistema Stirante S3901. Questa guida completa fornisce istruzioni dettagliate, consigli sulla sicurezza e manutenzione per un'esperienza di stiratura ottimale.</p>
	<p>Imetec Ferro a Vapore P8401/P8402: Manuale d'Uso e Sicurezza</p> <p>Manuale completo per il ferro da stiro a vapore Imetec P8401/P8402. Include istruzioni dettagliate per l'uso, avvertenze di sicurezza, manutenzione e risoluzione dei problemi per garantire un'esperienza di stiratura ottimale.</p>
	<p>IMETEC Q8602 Piastra per Capelli - Manuale d'Uso</p> <p>Manuale d'uso completo per la piastra per capelli IMETEC Q8602, con istruzioni dettagliate su sicurezza, utilizzo, manutenzione e garanzia.</p>
	<p>IMETEC MULTISTYLER Type C7003: Manuale d'uso e istruzioni</p> <p>Scopri come utilizzare al meglio il tuo IMETEC MULTISTYLER Type C7003 con il manuale d'uso completo. Istruzioni dettagliate per uno styling perfetto e sicuro dei capelli.</p>

<div><div></div><div>Manuale per l'uso Instructions for use Instructions d'utilisation Bedienungsanleitung Instrucciones de uso</div></div> <div>SCALDALETTO</div> <div><table><tr><td>IT</td><td>SCALDALETTO</td><td>pagina</td><td>1</td></tr><tr><td>EN</td><td>HEATER LEISERLEINSET</td><td>page</td><td>11</td></tr><tr><td>FR</td><td>CHAUFFE-EAU CHAUFFAIENT</td><td>page</td><td>21</td></tr><tr><td>ES</td><td>CALENTADOR</td><td>pagina</td><td>31</td></tr></table></div> <div><div>TYPE R1502 R1503 R1505 R1506 R1508 R1511</div><div></div></div>	IT	SCALDALETTO	pagina	1	EN	HEATER LEISERLEINSET	page	11	FR	CHAUFFE-EAU CHAUFFAIENT	page	21	ES	CALENTADOR	pagina	31	<div>IMETEC Scaldaletto: Manuale d'Uso e Sicurezza</div> <div>Manuale completo per lo scaldaletto IMETEC, che include istruzioni dettagliate per l'uso, la sicurezza, la pulizia, la manutenzione e la risoluzione dei problemi. Copre i modelli R1502, R1503, R1505, R1506, R1508, R1511.</div>																
IT	SCALDALETTO	pagina	1																														
EN	HEATER LEISERLEINSET	page	11																														
FR	CHAUFFE-EAU CHAUFFAIENT	page	21																														
ES	CALENTADOR	pagina	31																														
<div><div></div><div>Manuale per l'uso Instructions for use Instructions d'utilisation Bedienungsanleitung Instrucciones de uso</div></div> <div>TERMOFORO</div> <div><table><tr><td>IT</td><td>TERMOFORO</td><td>pagina</td><td>1</td></tr><tr><td>EN</td><td>HEATING PAD</td><td>page</td><td>11</td></tr><tr><td>FR</td><td>CHAUSSURE CHAUFFANT</td><td>page</td><td>21</td></tr><tr><td>ES</td><td>CALENTADOR</td><td>pagina</td><td>31</td></tr><tr><td>IT</td><td>ALFOMBRILLA ELETTRICA</td><td>pagina</td><td>41</td></tr><tr><td>EN</td><td>ELECTRIC CARPET</td><td>page</td><td>51</td></tr><tr><td>FR</td><td>CHAUSSURE CHAUFFANT</td><td>page</td><td>61</td></tr><tr><td>ES</td><td>CALENTADOR</td><td>pagina</td><td>71</td></tr></table></div> <div><div>TYPE R6701</div><div></div></div>	IT	TERMOFORO	pagina	1	EN	HEATING PAD	page	11	FR	CHAUSSURE CHAUFFANT	page	21	ES	CALENTADOR	pagina	31	IT	ALFOMBRILLA ELETTRICA	pagina	41	EN	ELECTRIC CARPET	page	51	FR	CHAUSSURE CHAUFFANT	page	61	ES	CALENTADOR	pagina	71	<div>Manuale d'uso IMETEC TYPE R6701 - Termoforo Elettrico</div> <div>Manuale di istruzioni per l'uso del termoforo IMETEC TYPE R6701. Questo documento fornisce una guida completa per l'utilizzo sicuro ed efficace, inclusi dettagli su specifiche tecniche, istruzioni di sicurezza, uso, pulizia, manutenzione, risoluzione dei problemi e garanzia.</div>
IT	TERMOFORO	pagina	1																														
EN	HEATING PAD	page	11																														
FR	CHAUSSURE CHAUFFANT	page	21																														
ES	CALENTADOR	pagina	31																														
IT	ALFOMBRILLA ELETTRICA	pagina	41																														
EN	ELECTRIC CARPET	page	51																														
FR	CHAUSSURE CHAUFFANT	page	61																														
ES	CALENTADOR	pagina	71																														