



Manuals.plus /

- › Fresh 'n Rebel /
- › Fresh 'n Rebel Clam Fuse Over-Ear Bluetooth Headphones User Manual

Fresh 'n Rebel CLAM-FUSE

Fresh 'n Rebel Clam Fuse

OVER-EAR BLUETOOTH HEADPHONES USER MANUAL

Model: CLAM-FUSE

1. Introduction

Thank you for choosing the Fresh 'n Rebel Clam Fuse Over-Ear Bluetooth Headphones. This manual provides detailed instructions on how to set up, operate, and maintain your headphones to ensure optimal performance and a superior audio experience. The Clam Fuse headphones offer hybrid active noise cancellation, an ENC microphone for crystal-clear calls, and an ambient sound mode, all designed for your convenience and listening pleasure.

2. Product Overview

2.1 Package Contents

Your Fresh 'n Rebel Clam Fuse package includes the following items:

- Clam Fuse Headphones
- USB to USB-C Charging Cable
- Carrying Pouch
- Quick Start Guide (this manual)



CONTENU DE LA BOÎTE

- Clam Fuse
- Câble de chargement (USB vers USB-C)
- Guide de démarrage rapide



Image: All items included in the Fresh 'n Rebel Clam Fuse retail box.

2.2 Headphone Components and Controls

Familiarize yourself with the various parts and controls of your Clam Fuse headphones:



Image: Front view of the Fresh 'n Rebel Clam Fuse headphones in Pastel Pink.

Image: Detailed view of the control buttons on the headphone earcup.

- **Power Button:** Press and hold to power on/off.
- **Volume Up/Next Track Button:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track Button:** Short press for volume down, long press for previous track.
- **Multi-function Button (MFB):** Play/Pause, Answer/End calls, Activate voice assistant.
- **ANC/Ambient Mode Button:** Toggle between Active Noise Cancellation, Ambient Sound Mode, and normal mode.
- **USB-C Port:** For charging the headphones.
- **Microphone:** Integrated ENC microphone for clear calls.

3. Setup

3.1 Charging the Headphones

Before first use, fully charge your Clam Fuse headphones. Connect the supplied USB-C cable to the charging port on the headphones and the other end to a USB power source (e.g., wall adapter, computer USB port). The LED indicator will show charging status. A full charge provides up to 45 hours of listening time.

3.2 Pairing with a Device

1. Ensure the headphones are turned off.
2. Press and hold the Power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Fresh 'n Rebel Clam Fuse" from the list.
5. Once connected, the LED indicator will turn solid blue.

The headphones will automatically reconnect to the last paired device when powered on, if it's within range and Bluetooth is enabled.

4. Operating Instructions

4.1 Power On/Off

- **Power On:** Press and hold the Power button for 3 seconds.
- **Power Off:** Press and hold the Power button for 3 seconds.

4.2 Music Playback

- **Play/Pause:** Short press the MFB.
- **Volume Up:** Short press the Volume Up button.
- **Volume Down:** Short press the Volume Down button.
- **Next Track:** Long press the Volume Up button.
- **Previous Track:** Long press the Volume Down button.

4.3 Call Management

The integrated ENC microphone ensures clear phone calls.



DES APPELS NICKEL !

Microphone antibruit
pour des appels
téléphoniques parfaits

Image: A person wearing the Clam Fuse headphones, emphasizing the clear call quality provided by the ENC microphone.

- **Answer/End Call:** Short press the MFB.
- **Reject Call:** Long press the MFB.
- **Activate Voice Assistant:** Double-press the MFB.

4.4 Active Noise Cancellation (ANC) and Ambient Sound Mode

The Clam Fuse headphones feature Hybrid Active Noise Cancellation to reduce ambient noise and an Ambient Sound Mode to stay aware of your surroundings.

ANC HYBRIDE

Supprimer efficacement
le bruit



Image: Visual representation of Hybrid Active Noise Cancellation on the Clam Fuse headphones.

MODE DE SON AMBIANT

Accentue les sons ambiants pour vous garder alerte pouvoir rester




Image: Visual representation of Ambient Sound Mode on the Clam Fuse headphones.

- **Toggle Modes:** Short press the ANC/Ambient Mode button to cycle through: ANC On → Ambient Sound Mode On → Normal Mode (ANC Off).

Video: An official promotional video showcasing the features and design of the Fresh 'n Rebel Clam Fuse headphones.

5. Maintenance

To ensure the longevity and optimal performance of your Clam Fuse headphones, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in the provided carrying pouch to protect them from dust and scratches. Avoid storing in extreme temperatures.
- **Water Resistance:** These headphones are not waterproof. Avoid exposure to liquids.

6. Troubleshooting

If you encounter any issues with your Clam Fuse headphones, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; Bluetooth off on device; device already connected to another Bluetooth device.	Ensure headphones are in pairing mode (flashing blue/red LED). Turn on Bluetooth on your device. Disconnect from other Bluetooth devices.
No sound.	Volume too low; headphones not connected; audio source issue.	Increase headphone and device volume. Re-pair headphones. Check audio source.
ANC not effective.	ANC mode not activated; improper fit.	Press the ANC button to activate ANC. Adjust headphones for a snug fit over your ears.

7. Specifications

Feature	Detail
Brand	Fresh 'n Rebel
Model Name	Clam Fuse
Model Number	CLAM-FUSE
Color	Pastel Pink
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Ear Placement	Over-Ear
Noise Control	Hybrid Active Noise Cancellation
Special Features	Over-ear detection, Ambient Sound Mode, Integrated ENC Microphone
Battery Life	Up to 45 hours
Frequency Range	20 Hz - 20,000 Hz
Water Resistance Level	Not Water Resistant
Compatible Devices	Desktops, Laptops, Tablets, Mobile Phones, Car Audio Systems, Smart Speakers, Music Production Equipment

8. Warranty and Support

Your Fresh 'n Rebel Clam Fuse headphones come with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. For warranty claims or technical support, please visit the official Fresh 'n Rebel website or contact their customer service.

For more information and support, please visit: www.freshnrebel.com