

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Brother](#) /

› [Brother Stellaire 2 Innov-is XE2 Disney Embroidery Machine User Manual](#)

## Brother XE2

# Brother Stellaire 2 Innov-is XE2 Disney Embroidery Machine User Manual

Model: XE2

## INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Brother Stellaire 2 Innov-is XE2 Disney Embroidery Machine. Please read all instructions carefully before operating the machine to ensure proper function and to prevent damage.

## SETUP

### 1. Unpacking and Component Identification

Carefully remove all components from the packaging. Verify that all listed items are present. Refer to the image below for visual identification of key components.



*Image: Various components included with the Brother Stellaire 2 Innov-is XE2 Disney Embroidery Machine. This includes multiple embroidery hoops of different sizes, a grid sheet for design placement, several empty bobbins, a spool of thread, scissors, a seam ripper, a needle set, and the operation manual.*

## 2. Power Connection

1. Ensure the machine's power switch is in the **OFF** position.
2. Connect the power cord to the machine's power input.
3. Plug the other end of the power cord into a grounded electrical outlet.

## 3. Hoop Attachment

1. Select the appropriate embroidery hoop size for your project.
2. Place your fabric securely within the inner and outer rings of the hoop, ensuring it is taut but not stretched.
3. Attach the hooped fabric to the embroidery unit carriage, ensuring it clicks firmly into place.

## 4. Thread Loading

1. Place the desired thread spool onto the spool pin.
2. Follow the numbered threading path indicated on the machine to guide the upper thread.
3. Insert a wound bobbin into the bobbin case according to the machine's instructions.

## OPERATING INSTRUCTIONS

### 1. Powering On and Basic Controls

1. Press the **Power** button to turn on the machine. The touch screen will illuminate.

2. Familiarize yourself with the touch screen interface for navigation and selection.

## 2. Selecting Designs

1. From the main menu, select the **Embroidery** option.
2. Browse the built-in designs or insert a USB drive into the designated port to access external designs.
3. Select your desired design and adjust its size, rotation, or position on the screen as needed.

## 3. Starting Embroidery

1. Once the design is selected and the fabric is hooped, press the **Start/Stop** button.
2. The machine will begin stitching the design. Monitor the process for any issues.

## 4. Monitoring Progress

The touch screen displays real-time information about the embroidery process, including stitch count, remaining time, and current thread color. The machine will pause automatically when a thread color change is required.

## MAINTENANCE

---

### 1. Cleaning the Machine

1. Regularly clean the bobbin area and feed dogs using the provided brush to remove lint and dust.
2. Wipe the machine's exterior with a soft, dry cloth. Avoid using harsh chemicals.

### 2. Needle Replacement

Replace the needle frequently, especially when working with different fabric types or if the needle becomes bent or dull. Always use needles recommended by Brother for optimal performance.

### 3. Software Updates

Periodically check the Brother support website for available software updates to ensure your machine has the latest features and improvements. Follow the instructions provided with the update package.

## TROUBLESHOOTING

---

- **Thread Breaks:**

*Possible Causes:* Incorrect threading, old or poor-quality thread, incorrect needle size, tension issues.

*Solutions:* Re-thread the machine, use new thread, replace the needle, adjust tension settings.

- **Skipped Stitches:**

*Possible Causes:* Bent or dull needle, incorrect needle insertion, improper hooping.

*Solutions:* Replace needle, ensure needle is inserted correctly, re-hoop fabric tightly.

- **Machine Not Powering On:**

*Possible Causes:* Power cord not securely connected, power outlet issue.

*Solutions:* Check all power connections, try a different outlet.

## SPECIFICATIONS

---

<b>Product Dimensions</b>	12.64 x 24.1 x 13.7 inches
<b>Item Weight</b>	45 pounds
<b>Manufacturer</b>	Brother
<b>Model Number</b>	XE2
<b>Color</b>	White
<b>Material</b>	Plastic
<b>Power Source</b>	Electric
<b>UPC</b>	012502673293

## **WARRANTY AND SUPPORT**

Your Brother Stellaire 2 Innov-is XE2 Disney Embroidery Machine comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical assistance, troubleshooting not covered in this manual, or to inquire about service, please contact Brother customer support. Contact information can typically be found on the Brother official website or in your warranty documentation.