

Benzara BM312298

Benzara BM312298 3 Piece Outdoor Coffee Table and Chairs Set User Manual

Model: BM312298

INTRODUCTION

This manual provides instructions for the assembly, use, and maintenance of your Benzara BM312298 3 Piece Outdoor Coffee Table and Chairs Set. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.

SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not exceed the weight capacity of the chairs or table.
- Keep children away from the assembly area.
- Avoid placing hot items directly on the wooden tabletop without protection.
- This product is designed for outdoor use.

PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly.

- 1 x Coffee Table
- 2 x Chairs
- 2 x Seat Cushions (Gray Fabric)
- 2 x Back Cushions (Gray Fabric)
- Assembly Hardware (screws, washers, Allen wrench)



Image: The complete 3-piece outdoor set, including two chairs with gray cushions and one rectangular coffee table with a wooden plank top.

SETUP AND ASSEMBLY

Follow these steps to assemble your outdoor furniture set. It is recommended to have two people for assembly.

Tools Required:

- Included Allen Wrench
- (Optional) Phillips Head Screwdriver

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratching.
2. **Assemble Chairs:**
 - Attach the chair backrest to the side frames using the provided hardware. Ensure all screws are finger-tight only at this stage.
 - Attach the seat frame to the assembled backrest and side frames. Secure with hardware, again finger-tight.
 - Once all chair components are loosely assembled, place the chair on a level surface and tighten all screws securely with the Allen wrench. Do not overtighten.
 - Repeat for the second chair.



Image: A single outdoor chair with gray cushions, green aluminum frame, and wooden armrests.

3. Assemble Coffee Table:

- Attach the table legs to the tabletop frame using the provided hardware. Ensure all screws are finger-tight.
- Once all table components are loosely assembled, place the table on a level surface and tighten all screws securely with the Allen wrench. Do not overtighten.



Image: The rectangular outdoor coffee table with a wooden plank top and green aluminum legs.

4. **Attach Cushions:** Place the seat and back cushions onto the assembled chairs.

OPERATING AND USAGE

Your Benzara outdoor furniture set is designed for comfortable outdoor lounging. Here are some guidelines for optimal use:

- **Placement:** Position the furniture on a flat, stable surface to prevent wobbling.
- **Cushion Care:** While cushions are UV-resistant, prolonged exposure to direct sunlight and rain can affect their longevity. Consider storing cushions indoors during inclement weather or when not in use.
- **Weight Distribution:** Distribute weight evenly on chairs and the table.

MAINTENANCE

Proper maintenance will extend the life and appearance of your furniture set.

- **Cleaning:** Wipe with a dry cloth. For more stubborn dirt, use a damp cloth with mild soap and water, then dry thoroughly.
- **Wood Care:** The wooden elements (tabletop and armrests) may benefit from periodic treatment with a suitable outdoor wood protector or oil to maintain their finish and prevent weathering.
- **Frame Care:** The aluminum frames are rust-resistant. Clean with a soft cloth and mild detergent as needed.
- **Cushion Cleaning:** Spot clean fabric cushions with a mild detergent and water solution. Allow to air dry completely.
- **Seasonal Storage:** During off-seasons or extended periods of non-use, consider covering the furniture or storing it in a dry, protected area to shield it from harsh weather conditions.

TROUBLESHOOTING

This section addresses common issues you might encounter with your furniture set.

- **Wobbly Chair/Table:** Ensure all assembly screws are tightened securely. Check that the furniture is placed on a level surface.
- **Fading Cushions:** While UV-resistant, prolonged direct sun exposure can cause fading. Rotate cushions periodically or store them when not in use.
- **Minor Scratches on Frame:** Use a touch-up paint pen matching the frame color for minor cosmetic scratches.

SPECIFICATIONS

Feature	Detail
Brand	Benzara
Model Number	BM312298
Material	Fabric, Aluminum, Solid Wood and Eucalyptus Wood
Color	Gray, Green and Brown
Coffee Table Dimensions (L x W x H)	36 x 19.62 x 17.75 inches
Chair Dimensions (L x W x H)	28 x 32.62 x 33 inches
Chair Seat Height	18.25 inches
Chair Seat Depth	21 inches
Item Weight	66.3 pounds (total set)
UPC	198288021715



Image: Diagram showing the dimensions of the coffee table (36L x 19.63W x 17.75H inches) and a chair (28L x 32.63W x 33H inches).

WARRANTY AND SUPPORT

For specific warranty information or customer support, please refer to the retailer's policy or contact Benzara customer service directly. Keep your purchase receipt for warranty claims.

Manufacturer: Benzara

Brand: Benzara

For further assistance, please visit the [Benzara Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question