

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MASINGO](#) /

› [MASINGO Allegro X8 2.0 Professional Karaoke Machine Instruction Manual](#)

MASINGO Allegro X8 2.0

MASINGO Allegro X8 2.0 Professional Karaoke Machine Instruction Manual

Model: Allegro X8 2.0

1. INTRODUCTION

Thank you for choosing the MASINGO Allegro X8 2.0 Professional Karaoke Machine. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

2. WHAT'S IN THE Box

The MASINGO Allegro X8 2.0 package includes the following components:

- Allegro X8 Karaoke Machine
- 2 Wireless Microphones
- Charging Adapter
- User Manual
- Auxiliary Cable

ALL-INCLUSIVE KARAOKE AWESOMENESS



Image: The Masingo Allegro X8 2.0 Karaoke Machine with its included accessories: two wireless microphones, a power adapter, a remote control, and the user manual.

3. PRODUCT OVERVIEW

3.1 Key Features

- **15-inch Touch-Screen Tablet:** Integrated display for lyrics and app navigation.
- **Dual Wireless Microphones:** Two rechargeable microphones with individual displays for volume, echo, and EQ control.
- **Multiple Playback Modes:** Supports Tablet, Bluetooth, USB, AUX-out, Micro-SD, HDMI, and Guitar inputs.
- **Portable Design:** Equipped with wheels and a telescoping handle for easy transport.
- **Voice Effects:** 'Magic Mode' allows voice alteration (e.g., Man, Woman, Electric, Shout).
- **Long-lasting Battery:** Features a 12V 5000 mAh rechargeable battery providing 3-4 hours of operation.

3.2 Physical Components





Image: The MASINGO Allegro X8 2.0 Karaoke Machine, showcasing its overall design with the integrated touchscreen and speaker grille.

THE X8 TOUCHSCREEN

INTERACTIVE KARAOKE EXPERIENCE



Image: A detailed view of the 15-inch touchscreen tablet, highlighting its Android 12 operating system, 4GB RAM, and 64GB storage. The screen displays various app icons like YouTube and Spotify.

DUAL CRYSTAL-CLEAR WIRELESS MICS



VISUAL CONTROL

Monitor battery levels and frequency on LED screen



INSTANT POWER

Insert AA batteries for quick & easy mic setup

Image: Two wireless microphones are shown, emphasizing their visual control displays for battery levels and frequency, and the easy AA battery setup.

CONNECT IN SECONDS, SING FOR HOURS

 HDMI

 WIFI

 BLUETOOTH 5.0

 USB

 MICRO SD



Image: A close-up of the top control panel, showing HDMI, WiFi, Bluetooth 5.0, USB, and Micro SD connectivity options.

TAKE THE SHOW ON THE ROAD



BATTERY CAPACITY

12V 5000 mAh



BATTERY RUN TIME

3-4 hours



Image: A person is shown easily transporting the karaoke machine using its telescoping handle and wheels, highlighting its portability and 12V 5000 mAh battery capacity.

Product Video: Introducing the Allegro X8 2.0 Karaoke Machine

Video Description: This official seller video provides an introduction to the MASINGO Allegro X8 2.0 Karaoke Machine, showcasing its features and design. It highlights the integrated touchscreen, dual wireless microphones, and portable nature of the device.

4. SETUP

4.1 Initial Charging

- Before first use, fully charge the karaoke machine using the provided charging adapter.
- Connect the charging adapter to the DC 15V input port on the control panel.
- Allow approximately 3-4 hours for a full charge.

4.2 Microphone Setup

- Insert 2 AA batteries into each wireless microphone.
- Press the power button on each microphone to turn it on. The microphones will automatically pair with the karaoke machine.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To power on the machine, locate the power switch on the control panel and toggle it to the 'ON' position.
- To power off, toggle the switch to the 'OFF' position.

5.2 Using the Touchscreen

- The 15-inch touchscreen operates like a standard Android tablet.
- Navigate through pre-installed apps (e.g., YouTube, Spotify, Google Chrome) or download new ones from the Play Store.
- Use the remote control for basic navigation and volume adjustments from a distance.

5.3 Connectivity Options

- **Bluetooth:** Pair your smartphone or tablet wirelessly to stream music.
- **USB/Micro-SD:** Insert a USB drive or Micro-SD card with your music files.
- **AUX-in:** Connect external audio devices using the provided AUX cable.
- **HDMI:** Connect the machine to an external display (e.g., TV) to show lyrics on a larger screen.
- **Guitar Input:** Plug in a guitar to use the machine as an amplifier.

5.4 Microphone Controls

- Adjust individual microphone volume, echo, and EQ settings using the dedicated controls on the microphone itself or the main control panel.
- Utilize 'Magic Mode' to change your voice with various effects like 'Man', 'Woman', 'Electric', or 'Shout'.

6. MAINTENANCE

- Keep the machine clean by wiping it with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Store the machine in a cool, dry place away from direct sunlight and extreme temperatures.
- Ensure microphones are stored securely in their designated sleeves when not in use.

7. TROUBLESHOOTING

7.1 No Sound from Speaker

- Check if the master volume is turned up.
- Ensure the correct playback mode (Bluetooth, USB, AUX) is selected.
- Verify that the connected device's volume is also turned up.

7.2 Microphone Not Working

- Confirm microphones are powered on and have fresh batteries.
- Check microphone volume levels on both the mic and the main control panel.
- Ensure microphones are paired correctly (usually automatic upon power-on).

7.3 Display Lagging or Unresponsive

- Restart the machine.
- Clear cache or uninstall unused apps from the Android tablet interface.
- Ensure a stable Wi-Fi connection for streaming content.

8. SPECIFICATIONS

Feature	Specification
Model Number	X8 2.0
Product Dimensions	15.3 x 9.4 x 25.1 inches
Item Weight	35 pounds
Battery	1 12V 5000 mAh battery (included)
Battery Run Time	3-4 hours
Special Feature	Portable, Touchscreen
Color	Black faux leather

9. WARRANTY & SUPPORT

The MASINGO Allegro X8 2.0 Karaoke Machine comes with a 60-day warranty. For support or warranty claims, please refer to the contact information provided in your product packaging or visit the MASINGO official website.