

[Manuals.plus](#) /

> [Outsunny](#) /

> Outsunny Three-Shelf Outdoor Grill Cart (Model 846-129V00BK) Instruction Manual

Outsunny 846-129V00BK

Outsunny Three-Shelf Outdoor Grill Cart (Model 846-129V00BK) Instruction Manual

Brand: Outsunny | Model: 846-129V00BK

PRODUCT OVERVIEW

The Outsunny Three-Shelf Outdoor Grill Cart, Model 846-129V00BK, is a versatile outdoor utility cart designed for food preparation, serving, and storage. It features a durable stainless steel tabletop and a robust frame, equipped with wheels for easy mobility.



Image: The Outsunny grill cart fully assembled and in use, displaying various food preparation items, ingredients, and utensils on its stainless steel top and shelves.

SETUP AND ASSEMBLY

This section provides step-by-step instructions for assembling your Outsunny grill cart. Ensure all components are present before beginning assembly.

Components Checklist:

- Stainless Steel Tabletop
- Frame components (legs, crossbars)
- Storage Shelves (2 tiers)
- Wheels (2 large, 2 stationary feet)
- Side Handle
- Seasoning Shelf
- Paper Towel Rack
- Garbage Bag Holder
- S-Hooks (4 pieces)
- Assembly Hardware (screws, washers, cotter pins)

Assembly Instructions:

1. **Unboxing and Inspection:** Carefully unpack all components and verify against the parts list in your included manual. Inspect for any damage.
2. **Frame Assembly:** Attach the main frame components (legs and crossbars) using the provided screws. *Important: Do not fully tighten screws until the entire frame is assembled to allow for adjustments.*
3. **Shelf Installation:** Secure the two storage shelves to the frame. The shelves typically lock into place and are then secured with additional screws.
4. **Wheel Attachment:** Install the wheels. For the larger wheels, ensure any washers and cotter pins are correctly placed to secure them to the axle.
5. **Accessory Installation:** Attach the side handle, seasoning shelf, paper towel rack, garbage bag holder, and S-hooks to their designated positions on the cart.
6. **Final Tightening:** Once all components are in place, fully tighten all screws to ensure the cart is stable and secure.
7. **Protective Film Removal:** Remove any protective film from the stainless steel tabletop.

Assembly Video:

Your browser does not support the video tag.

Video: An official product video demonstrating the assembly process of the Outsunny Grill Cart, showing how to connect the frame, attach shelves, wheels, and various accessories.



Image: The assembled Outsunny grill cart positioned on a patio, showcasing its stainless steel top, two lower shelves, and side handle, ready for outdoor use.

OPERATING INSTRUCTIONS

The Outsunny grill cart is designed for versatile outdoor use. Follow these guidelines for optimal operation:

- **Food Preparation:** Utilize the spacious 32" x 20.5" stainless steel tabletop for preparing meals. Its smooth surface is ideal for chopping, mixing, and plating.
- **Grill/Oven Stand:** The sturdy tabletop can accommodate various outdoor cooking appliances, such as pizza ovens, tabletop grills, or griddles. Ensure the appliance's dimensions and weight are within the cart's specifications.
- **Storage and Organization:**
 - The two lower shelves provide ample space for ingredients, cookware, and serving dishes.
 - The integrated seasoning shelf keeps spices and condiments readily accessible.
 - Use the paper towel rack for quick clean-ups.
 - The garbage bag holder offers a convenient solution for waste disposal during cooking.
 - Hang grilling utensils and tools on the four S-hooks.
- **Mobility:** The cart is equipped with two large wheels and two horseshoe-shaped feet. Lift the feet to

engage the wheels for easy movement across patios, decks, or other outdoor surfaces. The horseshoe feet provide stability when the cart is stationary.



Image: A close-up view of the Outsunny grill cart highlighting its multiple storage solutions, including the spice rack, paper tissue holder, tool hooks, and garbage bag holder, with a grill placed on top.

MAINTENANCE

Proper maintenance ensures the longevity and appearance of your grill cart.

- **Cleaning:** The stainless steel tabletop is designed for easy cleaning. Wipe it down with a damp cloth and mild detergent after each use to remove food residues, grease, and water stains. Avoid abrasive cleaners that could scratch the surface.
- **Frame Care:** The powder-coated metal frame can be cleaned with a damp cloth. Ensure it is dried thoroughly to prevent rust.
- **Storage:** When not in use for extended periods, especially during inclement weather, store the cart in a dry, protected area or use a suitable outdoor furniture cover to protect it from the elements.



EASY MOVEMENT

Lift the feet for easy movement

Side Handle

2 Large Wheels

2 Horseshoe Feet

Image: A detailed view of the stainless steel tabletop of the Outsunny grill cart, emphasizing its easy-to-clean surface, with food items and beverages arranged on it.

TROUBLESHOOTING

If you encounter any issues with your Outsunny grill cart, please refer to the following common solutions:

- **Instability:** Ensure all screws are fully tightened. Check that the cart is placed on a level surface.
- **Difficulty Moving:** Verify that the wheels are free of debris and can rotate smoothly. Ensure the horseshoe feet are lifted when attempting to move the cart.
- **Missing Parts/Damage:** If any parts are missing or damaged upon arrival, please contact Outsunny customer support immediately for assistance.

For further assistance, please contact Outsunny customer support.

SPECIFICATIONS

Feature	Detail
Overall Dimensions	39.25" L x 25.5" W x 33" H

Stainless Steel Top Size	32" L x 20.5" W x 1.5" D
Seasoning Tray Size	20.5" L x 5" W x 4.75" H
Storage Shelf Size	28.25" L x 19.75" W
Weight Capacity (Top)	66 lbs.
Weight Capacity (Shelf)	22 lbs.
Material	Stainless Steel, Powder Coated Metal
Color	Black
Number of Shelves	3
Number of Wheels	2 (plus 2 stationary feet)
Assembly Required	Yes
Model Number	846-129V00BK
UPC	196393342800



Image: A diagram of the Outsunny grill cart with all key dimensions labeled in both inches and centimeters, providing a clear visual representation of its size.

WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Outsunny customer service. Refer to your purchase documentation for specific warranty terms and contact details.
Manufacturer: Aosom LLC