

[Manuals.plus](#) /

> [Tangkula](#) /

> Tangkula 4-Piece Patio Dining Set Instruction Manual

Tangkula 71668BN+HW

Tangkula 4-Piece Patio Dining Set Instruction Manual

Model: 71668BN+HW

1. INTRODUCTION

Thank you for choosing the Tangkula 4-Piece Patio Dining Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor furniture. Please read these instructions carefully before assembly and retain them for future reference.



Image 1.1: Tangkula 4-Piece Patio Dining Set

2. SAFETY INFORMATION

To ensure safe use and prevent injury or damage, please adhere to the following safety guidelines:

- **Weight Capacity:** Do not overload the table and chairs beyond their specified weight capacities. The table capacity is 180 lbs (80 kg), each armchair is 400 lbs (180 kg), and the loveseat is 800 lbs (360 kg).
- **Umbrella Hole:** Exercise caution when inserting or removing an umbrella from the table's umbrella hole to prevent injury.
- **Cushions:** Keep seat cushions out of reach of young children to avoid potential choking hazards.
- **Assembly:** Always assemble the product strictly according to the provided instructions to minimize the risk of instability or tip-overs. Ensure all fasteners are securely tightened.
- **Placement:** Place the patio set on a flat, stable surface to prevent wobbling or tipping.
- **Weather Conditions:** During strong winds or severe weather, consider storing cushions indoors and securing or folding any umbrella used with the set.

3. PACKAGE CONTENTS

Verify that all components listed below are present in your package before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 1 x Table
- 1 x Loveseat
- 2 x Chairs
- 3 x Cushions (2 small for chairs, 1 large for loveseat)
- 1 x Instruction Manual (this document)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Tangkula 4-Piece Patio Dining Set is designed to be straightforward. Please follow the detailed assembly instructions provided in the separate assembly guide included with your package. Ensure you have adequate space and the necessary tools before starting.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts and hardware against the parts list in the assembly guide.
3. Follow the step-by-step diagrams and instructions carefully.
4. Do not fully tighten all screws until all components are loosely assembled. This allows for easier alignment.
5. Once all parts are in place, gradually tighten all screws securely.
6. Attach the adjustable footpads to the table legs for stability.

Product Dimensions



Image 4.1: Product Dimensions and Weight Capacities

Note: The screw bag is typically located in Box 1. The time of receipt for multiple boxes may vary.

5. OPERATING INSTRUCTIONS

Your Tangkula Patio Dining Set is designed for comfortable outdoor dining and relaxation. Here are some operational features:

- **Seating:** The set includes two armchairs and one loveseat, providing seating for up to four people. Place the cushions on the seats for enhanced comfort.
- **Umbrella Integration:** The table features a 1.96-inch (5 cm) umbrella hole in the center, compatible with most standard patio umbrellas. Insert your umbrella to provide shade during sunny conditions.



Fits an Umbrella

2" umbrella hole is perfect for most patio umbrellas

Image 5.1: Table with Umbrella Hole Feature

6. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your patio dining set.

- **Cleaning Wood and Metal:** Wipe the acacia wood and metal frames with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners that can damage the finish.
- **Cushion Care:** The seat cushions are equipped with smooth zippers, allowing for easy removal of the covers for cleaning. Hand wash or machine wash cushion covers on a gentle cycle with cold water and mild detergent. Air dry only; do not tumble dry.
- **Cushion Ties:** The cushions include fixing ties to prevent them from moving. Ensure these ties are secured to the furniture frame.
- **Water Accumulation:** The slatted design of the seat and tabletop helps prevent water accumulation. However, after rain, wipe down surfaces to ensure longevity.
- **Protection:** To protect the set from harsh weather conditions and prolong its lifespan, consider using a furniture cover when not in use, especially during off-season periods.

Comfortable Seat Cushions



High-Density Filling



Smooth Zippers



Fixing Ties

Image 6.1: Cushion Features for Comfort and Maintenance

7. TROUBLESHOOTING

If you encounter any issues with your patio dining set, consider the following common solutions:

- **Wobbling Furniture:** Ensure all screws are securely tightened. Check that the furniture is placed on a level surface. The table features adjustable footpads to compensate for uneven ground.
- **Missing Parts:** Double-check the package contents against the parts list. If parts are genuinely missing, contact Tangkula customer support.
- **Difficulty Assembling:** Review the assembly instructions carefully. Sometimes, components may need to be oriented in a specific direction. Do not force parts together.
- **Cushion Shifting:** Ensure the fixing ties on the cushions are securely fastened to the furniture frame.

For issues not resolved by these steps, please contact Tangkula customer support for further assistance.

8. SPECIFICATIONS

Feature	Specification
Model Number	71668BN+HW
Color	Natural (wood) and Black (metal), Beige (cushions)
Material	Acacia Wood, Metal, Polyester, Sponge
Table Dimensions (L x W x H)	47" x 27.5" x 29.5" (120 x 70 x 75 cm)
Armchair Dimensions (L x W x H)	23" x 23" x 34" (58 x 58 x 87 cm)
Loveseat Dimensions (L x W x H)	42.5" x 23" x 34" (108 x 58 x 87 cm)
Small Cushion Dimensions (L x W x Thickness)	20" x 20.5" x 3.2" (50 x 52 x 8 cm)
Large Cushion Dimensions (L x W x Thickness)	39" x 20.5" x 3.2" (100 x 52 x 8 cm)
Seat Height from Ground	16" (40 cm)
Seat Depth	20.5" (52 cm)
Total Net Weight	73 lbs (33 kg)
Table Weight Capacity	180 lbs (80 kg)
Each Armchair Weight Capacity	400 lbs (180 kg)
Loveseat Weight Capacity	800 lbs (360 kg)
Umbrella Hole Diameter	1.96" (5 cm)

9. WARRANTY AND SUPPORT

Tangkula is committed to providing quality products. For specific warranty details, please refer to the warranty information provided at the time of purchase or visit the official Tangkula website. For any questions, missing parts, or support needs, please contact Tangkula customer service through their official channels.

You can visit the Tangkula Store for more information: [Tangkula Official Store](#)