
[Manuals.plus](#) /

› [Ambrane](#) /

› Ambrane Stylo 10 10000mAh Power Bank User Manual

Ambrane Stylo 10

Ambrane Stylo 10 10000mAh Power Bank User Manual

Model: Stylo 10

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Ambrane Stylo 10 10000mAh Power Bank. Please read these instructions carefully before using the device.



Image: Front view of the Ambrane Stylo 10 Power Bank, showcasing its compact design.

SETUP AND INITIAL CHARGING

Before first use, fully charge your Ambrane Stylo 10 Power Bank.

1. **Connect the Power Bank:** Use a Type-C cable to connect the power bank's Type-C input port to a compatible power adapter (not included).
2. **Power Source:** Plug the power adapter into a wall outlet.
3. **Charging Indication:** The LED indicators on the power bank will illuminate to show the charging progress.
4. **Full Charge:** A full charge typically takes approximately 4 to 5 hours with a 20W fast charging input. All LED indicators will be steadily lit when fully charged.



Image: The Ambrane Stylo 10 Power Bank connected to a charger, showing its LED indicators.

OPERATING INSTRUCTIONS

The Ambrane Stylo 10 Power Bank features dual output ports for charging multiple devices.

Charging Your Devices

1. **Connect Your Device:** Use a compatible charging cable (USB-A to device or Type-C to device) to connect your smartphone, tablet, or other compatible device to either the USB-A output port or the Type-C output port on the power bank.
2. **Initiate Charging:** The power bank will automatically begin charging your device. If not, press the power button once to activate charging.
3. **Dual Device Charging:** You can charge two devices simultaneously using both the USB-A and Type-C output ports.
4. **Fast Charging:** The power bank supports 22.5W Power Delivery (PD) and Quick Charge (QC) output. For optimal fast charging, ensure your device and charging cable are compatible with these technologies.



Image: Illustration highlighting the 22.5W fast charging feature with Power Delivery and Quick Charge 3.0.

Supreme Durability

Made up of high-quality materials to ensure toughness



Image: The power bank connected to a smartphone and a tablet, demonstrating universal compatibility and dual output.

Checking Battery Level

Press the power button once to view the current battery level indicated by the LED lights.

MAINTENANCE AND SAFETY

To ensure the longevity and safe operation of your power bank, follow these guidelines:

- Keep the power bank dry and away from moisture.
- Avoid exposing the device to extreme temperatures (hot or cold).
- Do not drop, disassemble, or attempt to repair the power bank yourself.
- Use only certified and compatible charging cables and adapters.
- Clean the exterior with a soft, dry cloth. Do not use harsh chemicals.
- The power bank features multi-layer chipset protection against short circuits, over-voltage, overcurrent, and

overload.




Image: Diagram illustrating the multi-layer chipset protection features of the power bank, including short circuit, over-voltage, and overcurrent protection.

TROUBLESHOOTING

Problem	Possible Solution
Power bank not charging.	Ensure the charging cable is securely connected to both the power bank and the power adapter. Verify the power adapter is functioning correctly and plugged into a live outlet. Try a different Type-C charging cable and adapter.
Device not charging from power bank.	Check if the power bank has sufficient charge (press the power button to check LED indicators). Ensure the charging cable is securely connected to both the power bank and your device. Try a different charging cable. Press the power button on the power bank to initiate charging.
Slow charging.	Ensure both your device and the charging cable support fast charging (Power Delivery or Quick Charge). Using a non-fast charging cable or adapter will result in slower charging speeds.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Name	Stylo 10
Battery Capacity	10000mAh Lithium Polymer
Input (Type-C)	20W Fast Charging
Output (USB-A)	22.5W BoostedSpeed™ (Quick Charge 3.0)
Output (Type-C)	22.5W Power Delivery (PD)
Number of Ports	2 (1 USB-A, 1 Type-C)
Battery Charge Time	Approx. 4-5 hours (with 20W input)
Compatible Devices	Smartphones, iPhones, Tablets, and other USB/Type-C chargeable devices
Dimensions (L x W x Th)	14.7 x 7.4 x 1.6 Centimeters
Item Weight	300 Grams
Special Features	Power Delivery, Quick Charge 3.0, VOOC & Super VOOC Support, Multi-layer Protection

WARRANTY INFORMATION

The Ambrane Stylo 10 Power Bank comes with a**6 Months Manufacturer Warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt for warranty claims. For warranty service, please contact Ambrane customer support.

CUSTOMER SUPPORT

For any queries, technical assistance, or warranty claims, please contact Ambrane customer support:

- **Email:** Care@ambranindia.com
- **Website:** Visit the official Ambrane website for more information and support resources.