T4TREAM ILSC48VDWM-NO

T4TREAM ILSC48VDWM-NO Fluted Makeup Vanity Desk User Manual

Model: ILSC48VDWM-NO | Brand: T4TREAM

Important Safety Information

- **General Safety:** Always follow assembly instructions carefully. Ensure all parts are securely fastened before use.
- **Assembly Caution:** Exercise caution during assembly. It is recommended to have two people for assembly to prevent injury and ensure proper construction.
- **Electrical Safety:** The built-in charging station is for indoor use only. Do not open or attempt to repair the electrical components. Ensure hands are dry when plugging or unplugging devices.
- **Weight Capacity:** Do not overload shelves or drawers. Refer to product specifications for individual weight limits if available.
- **Glass Components:** Handle the glass top and cabinet door with care to prevent breakage. Avoid placing heavy or sharp objects directly on the glass.
- **Stability:** Place the vanity on a flat, stable surface.

Package Contents

The T4TREAM Fluted Makeup Vanity Desk includes all necessary parts and accessories for assembly. Each component is clearly identified with numbered stickers for easy recognition. A pack of spare hardware is also supplied to account for any potential loss during assembly.

Please verify all parts are present and undamaged before beginning assembly. Refer to the included detailed Installation Instructions for a complete list of components.

Setup and Assembly Instructions

Assembly of the T4TREAM Fluted Makeup Vanity Desk requires careful attention to the provided instructions. While an electric drill can expedite the process, it is not mandatory. For optimal safety and ease, two individuals are recommended for assembly.

Estimated Assembly Time: Approximately 3 to 5 hours, depending on individual skill level and tools used.

1. **Unpack and Organize:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Group similar parts and hardware.
2. **Follow Manual:** Refer to the detailed Installation Instructions provided in the package. Each step is illustrated and numbered.
3. **Secure Connections:** Ensure all screws, dowels, and fasteners are tightened securely but do not overtighten to avoid damaging the wood.
4. **Mirror Installation:** Install the 36-inch HD Lighted Mirror according to the instructions, ensuring all electrical connections are made correctly.
5. **Final Placement:** Once assembled, position the vanity on a level surface.

For visual guidance, please refer to the assembly video below, provided by a seller.

Your browser does not support the video tag.

Video: Assembly process for the T4TREAM Vanity Desk, demonstrating the steps from unboxing to final setup. This video is provided by a seller.

Operating Instructions

36-inch HD Lighted Mirror



Image: Close-up of the 36-inch HD Lighted Mirror, highlighting the touch control panel for brightness and light modes.

- **Power On/Off:** Tap the power button icon on the mirror surface to turn the lights on or off.
- **Adjust Brightness:** Press and hold the power button icon to continuously adjust the brightness level. Release when desired brightness is reached.
- **Change Light Modes:** Tap the mode button (often represented by a circular arrow or 'M' icon) to cycle through the three available light settings:
  - Cool Daylight
  - Neutral Light
  - Warm Light
- The mirror retains the last used brightness and color setting when powered off and on again.

Your browser does not support the video tag.

Video: Demonstration of the mirror's lighting features, including power on/off and changing light modes. This video is provided by a seller.

Built-in Charging Station




Image: Close-up of the side table featuring the integrated charging station with two AC outlets and two USB ports.

- **AC Outlets:** Two 125V/12A AC outlets are available for powering hair styling tools, lamps, or other small appliances.
- **USB Ports:** Two 5V/2.1A USB ports are provided for charging smartphones, tablets, and other USB-powered devices.
- Ensure devices are compatible with the provided voltage and amperage to prevent damage.

Storage Features



Image: Overhead view of the vanity desk, showcasing the embedded tempered glass tabletop and the organized compartments within the drawers.

- **Glass Top Drawers:** The main desk features drawers with an embedded tempered glass tabletop, allowing for a clear view and quick access to stored cosmetics and accessories. These drawers include detachable partitions for customizable organization.
- **Side Storage Cabinet:** A side cabinet with a dustproof glass door offers height-adjustable shelves, suitable for storing perfumes, skincare products, or other items of varying heights.
- **Lower Drawers:** Additional drawers are located beneath the side table, providing ample concealed storage space.

Your browser does not support the video tag.

Video: A brief overview of the vanity's storage capabilities, including the glass-top drawers and side cabinet. This video is provided by a seller.

Maintenance

- **Cleaning:** Wipe all surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the

finish or glass.

- **Glass Care:** For the glass top and cabinet door, use a glass cleaner and a lint-free cloth.
- **Electrical Components:** Keep the charging station free from dust and moisture. Do not spray liquids directly onto the outlets or USB ports.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If needed, a small amount of silicone lubricant can be applied.

Troubleshooting

Problem	Possible Cause	Solution
Mirror lights do not turn on.	Power cable not connected, power outlet issue, or mirror light malfunction.	Ensure the power cable is securely plugged into both the mirror and a working wall outlet. Test the outlet with another device. If the issue persists, contact customer support.
Mirror lights are too dim or too bright.	Brightness setting needs adjustment.	Press and hold the power button icon on the mirror surface to adjust the brightness to your preference.
Drawers are difficult to open or close.	Misalignment during assembly, obstruction, or worn slides.	Check for any obstructions within the drawer or along the slides. Verify that the drawer slides were installed correctly during assembly. Apply a small amount of silicone lubricant to the slides if necessary.
Charging station not working.	Power cable not connected, power outlet issue, or device incompatibility.	Ensure the vanity's main power cable is connected. Test the wall outlet. Verify your device is compatible with the charging station's specifications (125V/12A for AC, 5V/2.1A for USB).

Specifications

Feature	Detail
Brand	T4TREAM
Model Number	ILSC48VDWM-NO
Product Dimensions	15.6"D x 48"W x 53.6"H
Item Weight	120 pounds
Frame Material	Engineered Wood
Furniture Finish	Oak
Color	Natural Oak
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Mirror Size	36 inches (HD Lighted)

Feature	Detail
Charging Station	2 AC Outlets (125V/12A), 2 USB Ports (5V/2.1A)
Drawers	5 (including glass-top drawers with dividers)
Side Cabinet	Dustproof glass door, adjustable shelves



Image: Technical drawing illustrating the dimensions and key features of the vanity desk, including storage compartments and mirror size.

Warranty and Support

This T4TREAM vanity desk is manufactured from FSC-Certified wood, ensuring responsible sourcing. The product is designed for durability and comes with a commitment to customer satisfaction.

- **Returns:** This product is returnable until January 31, 2026. Please refer to the retailer's return policy for specific conditions.

- **Customer Support:** For any questions, concerns, or assistance with assembly or product functionality, please contact T4TREAM customer support. Contact information can typically be found on the packaging or the retailer's website.
- **Spare Parts:** A pack of spare parts is included with the product to assist with any hardware needs during assembly.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question