

[Manuals.plus](#) /

› [Faber-Castell](#) /

› Faber-Castell Little Creatives Extra Jumbo Ultra Washable Markers Instruction Manual

Faber-Castell FC354503

Faber-Castell Little Creatives Extra Jumbo Ultra Washable Markers

INSTRUCTION MANUAL

Introduction

The Faber-Castell Little Creatives Extra Jumbo Ultra Washable Markers are designed to inspire creativity in young children. Developed in collaboration with early childhood educators, these markers feature an ergonomic design, crush-proof tips, and ultra-washable, non-toxic, food-grade dyes for safe and easy use. This manual provides essential information for the proper setup, operation, maintenance, and care of your markers.



Image: A set of six Faber-Castell Little Creatives Extra Jumbo Ultra Washable Markers in red, yellow, green, blue, brown, and black.

Setup

Your Faber-Castell Little Creatives Extra Jumbo Ultra Washable Markers come ready for immediate use. No assembly is required.

What's Included:

- 6 Extra Jumbo Ultra Washable Markers (Red, Yellow, Green, Blue, Brown, Black)
- Recyclable storage box

6 Bright & Vibrant Jumbo washable markers



Image: The six Faber-Castell Extra Jumbo Ultra Washable Markers displayed in their original packaging.

First Use:

1. Carefully remove the markers from their recyclable packaging.
2. Remove the cap from the desired marker. The caps are designed to snap securely.
3. The markers are now ready for creative activities.

Operating Instructions

These markers are designed for ease of use by young children, promoting fine motor skills and pre-writing dexterity.

Using the Markers:

- **Ergonomic Grip:** The extra jumbo barrel is designed for comfortable holding, ideal for a child's palmar grasp.
- **Crush-Proof Tips:** The wide, crush-proof tips are engineered to withstand pressure, ensuring durability even with enthusiastic use.
- **Non-Rolling Design:** The specially designed lids and barrels help prevent the markers from rolling off work

surfaces, keeping them accessible and reducing loss.

- **Vibrant Colors:** Use the six bright classic colors (Red, Yellow, Green, Blue, Brown, Black) to create various drawings and art projects on paper.

Jumbo Size

Easy to grasp, ergonomic shape



Special fin & cap
prevent rolling

Image: A child's hand holding a green jumbo marker, demonstrating the ergonomic grip suitable for small hands.

Little Creatives

Specially
designed
creative tools
for little hands

Easy to clean

Preschool tough

Perfectly sized



Image: A child using a red jumbo marker on paper, highlighting the durability of the crush-proof tip.

Maintenance

Proper care ensures the longevity of your Faber-Castell markers and easy cleanup.

Cleaning:

- **Washable Ink:** The markers contain water-based inks made with non-toxic, food-grade dyes that are easily washable from hands and most clothing.
- **Skin:** Wash skin with soap and water to remove marker residue.
- **Clothing:** For best results, wash stained clothing promptly with warm water and detergent. Pre-treating may be necessary for stubborn stains.

Endless Creativity

Bright, vibrant colors encourage maximum creative fun!



Image: A child's hand covered in colorful marker ink, with an illustration of water splashes and text indicating 'Super Washable'.

Storage:

- Always replace the cap securely after each use to prevent the markers from drying out.
- Store markers horizontally in their original recyclable box at room temperature, away from direct sunlight or extreme heat.

Troubleshooting

Here are solutions to common issues you might encounter with your markers.

Marker Appears Dry:

- Ensure the cap was securely replaced after the last use.
- If the marker tip appears dry, try gently pressing it onto a piece of scrap paper for a few seconds to encourage ink flow.

- If the marker remains dry, it may have reached the end of its lifespan and should be replaced.

Stains on Surfaces:

- While markers are washable from most surfaces, immediate cleaning is recommended.
- For non-porous surfaces, wipe immediately with a damp cloth.
- For porous surfaces, washability may vary. Test cleaning methods on an inconspicuous area first.

Safety Information

Faber-Castell Little Creatives markers are designed with child safety in mind.

- **Non-Toxic:** Made with non-toxic, food-grade dyes.
- **Recommended Age:** Suitable for children aged 3 years and older.
- **Supervision:** Adult supervision is recommended during use, especially for younger children.
- **Ingestion:** While made with food-grade dyes, markers are not intended for consumption. In case of accidental ingestion, consult a medical professional.

Specifications

Brand	Faber-Castell
Model Number	FC354503
Ink Color	Multicolor (Red, Yellow, Green, Blue, Brown, Black)
Number of Items	6
Point Type	Fine (2mm and above line size)
Target Audience	Kid (Toddler)
Item Weight	0.14 Kilograms
Item Dimensions	1 x 5.63 x 6 inches
Material Type	Plastic
Ink Base	Water
Water Resistance Level	Not Water Resistant
Grip Type	Ergonomic

Official Product Video

Your browser does not support the video tag.

Video: An official product video from Faber-Castell showcasing the Little Creatives markers for toddlers, highlighting their features and benefits for young artists.

Warranty and Support

Faber-Castell takes pride in creating premium quality art supplies since 1761. For any questions, concerns, or support

regarding your Little Creatives markers, please refer to the official Faber-Castell website or contact their customer service directly.

For more information, visit the [Faber-Castell Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question