



Manuals.plus /

› SUPERJARE /

› SUPERJARE Bakers Rack with Power Outlets Instruction Manual

## SUPERJARE 80932

# SUPERJARE Bakers Rack with Power Outlets Instruction Manual

Model: 80932

## INTRODUCTION

---

Thank you for choosing the SUPERJARE Bakers Rack. This versatile kitchen storage solution is designed to enhance your kitchen organization with its spacious desktop, adjustable shelving, integrated power outlets, and convenient S-shaped hooks. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new bakers rack.



Image: The SUPERJARE Bakers Rack integrated into a kitchen, showcasing its utility as a microwave stand and coffee bar.

## IMPORTANT SAFETY INFORMATION

---

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Assembly:** Always assemble the bakers rack according to the provided instructions. Ensure all parts are securely fastened before use.
- **Weight Capacity:** Do not overload shelves. Distribute weight evenly to maintain stability. Refer to the specifications section for maximum weight limits per shelf.
- **Power Outlets:** Use the integrated power outlets with caution. Ensure no liquids or heavy objects are placed directly on or near the outlets. Do not exceed the maximum wattage (1800W max). Always use the safe switch to turn off power when not in use or during cleaning.
- **Stability:** Utilize the anti-tip device provided to secure the rack to a wall, especially if placing heavy items on upper shelves or if there are children or pets in the household. Ensure the adjustable feet are balanced to prevent

wobbling.

- **Environment:** Keep the area around the shelf clear to prevent accidents. Avoid placing the rack in areas with excessive moisture or direct sunlight.

## Stay Charged with Safety



3 AC Outlets  
1800W max



1 On-off Switch  
Ensure Safety



Power Cord  
6.5-Foot



Image: Detail of the integrated power outlets with a safety switch, highlighting the electrical features.

### SETUP AND ASSEMBLY

The SUPERJARE Bakers Rack is designed for stress-free assembly. All necessary tools and numbered parts are included. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

#### Before You Begin:

- Unpack all components and verify against the parts list (usually found in the included assembly guide).
- Ensure you have enough space for assembly.
- Keep screws and small parts organized.

## **Assembly Steps:**

1. Attach the main frame components using the provided screws. Do not fully tighten screws until all parts are aligned.
2. Secure the bottom and middle shelves to the frame. The middle shelf is adjustable; choose your desired height before fully tightening.
3. Install the top desktop and the upper shelf.
4. Mount the power outlet panel to the designated area on the back frame.
5. Attach the S-shaped hooks to the side bars as desired.
6. Once all components are in place, fully tighten all screws.
7. Install the anti-tip device to secure the rack to a wall for enhanced stability.
8. Adjust the leveling feet at the bottom of the rack to ensure it stands stable on uneven floors.




Image: Detailed dimensions of the bakers rack, useful for planning placement and understanding component sizes.

## OPERATING INSTRUCTIONS

---

### Utilizing the Power Outlets:

- Plug the bakers rack's power cord into a standard wall outlet.
- Use the integrated 3 AC outlets to power kitchen appliances such as coffee makers, blenders, or microwaves.
- Always use the red safety switch to turn the power on or off for the outlets.

- Do not exceed the maximum power rating of 1800W for the outlets.



Image: The spacious desktop, ideal for various kitchen tasks and appliance placement.

### Adjusting the Middle Shelf:

- The middle shelf offers 2 level positions to accommodate items of different heights.
- To adjust, carefully remove any items from the shelf.
- Loosen the screws securing the middle shelf to the frame.
- Reposition the shelf to the desired height and re-tighten the screws securely.

# Adjustable Middle Shelf

2 level positions for storing different height items



Image: Visual representation of the adjustable middle shelf, illustrating its flexibility for various storage needs.

## Using S-Shaped Hooks:

- The included S-shaped hooks can be hung on the side bars of the rack.
- Use them to hang kitchen tools, mugs, towels, or other small items for easy access and clutter-free counters.



Anti-tip Device



6 S-shaped Hooks



Adjustable Feet

Image: Details of the anti-tip device, S-shaped hooks, and adjustable feet, highlighting stability and organizational features.

## MAINTENANCE

---

Regular maintenance will help prolong the life and appearance of your SUPERJARE Bakers Rack.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Power Outlets:** Ensure the power outlets are kept dry and free from dust and debris. Do not attempt to clean the outlets with liquids while plugged in.

## TROUBLESHOOTING

---

| Problem                    | Possible Cause   | Solution  |
|----------------------------|--|---|
| Rack is wobbly/unstable.   | Uneven floor; loose screws; anti-tip device not installed. | Adjust the leveling feet at the bottom. Check and tighten all assembly screws. Install the anti-tip device to a wall.   |
| Power outlets not working. | Power switch off; rack not plugged in; circuit overload.   | Ensure the red safety switch is in the "ON" position. Verify the rack's power cord is securely plugged into a working wall outlet. Reduce the number of appliances plugged in to avoid exceeding 1800W. |
| Difficulty assembling.     | Parts misaligned; screws not fully tightened.              | Refer to the assembly instructions carefully. Ensure screws are only hand-tightened initially, then fully tightened once all parts are in place.  |

## SPECIFICATIONS

---

**Brand:** SUPERJARE

**Model Number:** 80932

**Material:** Engineered Wood, Steel

**Color:** Black

**Product Dimensions:** 31.5" L x 16.5" W x 50.59" H (80cm L x 42cm W x 128.5cm H)

**Desktop Dimensions:** 31.5" L x 16.5" W

**Item Weight:** 32.8 pounds (14.88 kg)

**Number of Shelves:** 3 (including top and bottom, one adjustable middle shelf)

**Power Outlets:** 3 AC Outlets, 1 On-off Switch

**Max Power Output:** 1800W

**Power Cord Length:** 6.5 feet

**Special Features:** Heavy Duty, Adjustable Middle Shelf, 6 S-shaped Hooks, Anti-tip Device, Adjustable Feet

**Assembly Required:** Yes

**Recommended Uses:** Kitchen organization, microwave stand, coffee bar, plant rack, bookshelf

## WARRANTY AND SUPPORT

---

SUPERJARE is committed to providing high-quality products. For any questions, concerns, or assistance with assembly or parts, please contact our customer support team.

Please refer to your purchase documentation for specific warranty details. Keep your proof of purchase for warranty claims.

**Customer Support:** For support, please visit the official SUPERJARE store on Amazon or contact us through the platform where you made your purchase. You can also visit the [SUPERJARE Store](#) for more information.

