Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bibilock 61011

Bibilock 2008 PCS Micro Blocks Cherry Bonsai Tree Building Set Instruction Manual

Model: 61011 | Brand: Bibilock

Introduction

This manual provides detailed instructions for assembling your Bibilock 2008 PCS Micro Blocks Cherry Bonsai Tree Building Set. This set features micro-sized building blocks, offering a challenging yet rewarding construction experience. Please read all instructions carefully before beginning assembly.

Safety Information

Warning: Choking Hazard - Small Parts. This product contains small parts and is not suitable for children under 3 years. The manufacturer recommends this product for ages 14 and up due to the small size and complexity of the micro blocks. Adult supervision is advised for younger builders.

The building blocks are made from ABS materials, which are non-toxic and non-irritating. Ensure all pieces are handled carefully to avoid loss.

Parts List

Your Bibilock Cherry Bonsai Tree Building Set includes approximately 2008 micro-sized building blocks. These pieces are typically divided into numbered bags for easier organization. A block remover tool may also be included to assist with assembly.



Figure 1: Illustration of micro block size. Note the small dimensions, requiring careful handling.

Assembly Instructions

1. **Preparation:** Before starting, carefully open all numbered bags and sort the micro blocks by color and shape. Using a sorting tray or small containers can significantly aid in organization and prevent loss of small pieces.
2. **Consult the Manual:** Refer to the included full-color instruction booklet. Each step is illustrated to guide you through the assembly process. Pay close attention to the orientation and placement of each block.
3. **Base Construction:** Begin by assembling the base of the bonsai tree as indicated in the initial steps of the manual. This forms the foundation for the entire model.
4. **Tree Trunk and Branches:** Proceed with building the tree trunk and main branches. The micro blocks require firm but gentle pressure to connect securely.
5. **Cherry Blossoms and Details:** The cherry blossom pieces are particularly small and delicate. It is often easier to attach the flowers to their stems before attaching the stem assemblies to the tree branches. Exercise patience during this stage, as pieces may occasionally detach.

6. **Final Touches:** Complete any remaining decorative elements, such as the small pond or grassy areas, as per the instructions.



Figure 2: The completed Bibilock Cherry Bonsai Tree model.



Figure 3: The building set with the instruction manual, illustrating the complexity and detail.

Display and Care

Once assembled, your Bibilock Cherry Bonsai Tree is designed for display. Place it on a stable, flat surface away from direct sunlight and excessive heat to prevent material degradation. The compact nature of micro blocks helps maintain structural integrity, but the model should be handled with care to avoid dislodging pieces.

Maintenance

To clean your assembled model, gently dust it with a soft brush or a can of compressed air. Avoid using liquid cleaners or abrasive materials, as these can damage the plastic blocks or cause discoloration.

Troubleshooting

- **Missing Pieces:** In the event of missing pieces, carefully re-check your sorting area and packaging. If pieces are still missing, please contact Bibilock customer support for assistance.
- **Difficulty with Assembly:** Micro blocks require precision. If you encounter difficulty, double-check the instruction manual for the correct placement and orientation. Applying firm, even pressure is key. Some users find a block remover tool helpful.
- **Pieces Detaching:** Due to the small size, some pieces, especially the delicate cherry blossoms, may detach during assembly or handling. Reattach them carefully. For display models, some builders opt for a small amount of plastic-safe adhesive for added stability, though this is not required for basic assembly.

Specifications

Brand	Bibilock
Model Number	61011
ASIN	B0CVTR7H1L
Number of Pieces	2008
Product Dimensions (L x W x H)	8.66 x 1.96 x 11.8 inches (approximate assembled size)
Item Weight	11.5 ounces
Recommended Age	14 years and up
Material	ABS Plastic



Figure 4: Product dimensions of the assembled model.

Customer Support

For any questions, concerns, or assistance with missing parts, please contact Bibilock customer support through the retailer where the product was purchased. Please have your model number (61011) and ASIN (B0CVTR7H1L) ready when contacting support.

© 2024 Bibilock. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVTR7H1L

More documents and user manuals: **https://manuals.plus/**