

## KW29 MAX

# KEQIWEAR KW29 MAX Smartwatch User Manual

Equipped with ten Watch straps, Supports Bluetooth calls, Diversified Sports modes, New Dynamic Dial

## 1. INTRODUCTION

Welcome to the user manual for your new KEQIWEAR KW29 MAX Smartwatch. This guide provides comprehensive instructions on how to set up, operate, and maintain your device, ensuring you get the most out of its features, including Bluetooth calls, multiple sports modes, and dynamic watch faces. Your smartwatch comes with a versatile collection of ten watch straps, allowing for personalized style and comfort.

## 2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- KEQIWEAR KW29 MAX Smartwatch Unit
- 10 x Interchangeable Watch Straps
- Wireless Charging Cable
- User Manual (this document)



Image: The KEQIWEAR KW29 MAX Smartwatch packaging, displaying the smartwatch unit alongside a variety of ten colorful interchangeable watch bands and the wireless charging cable.

## 3. PRODUCT FEATURES

The KEQIWEAR KW29 MAX Smartwatch is designed with user convenience and versatility in mind:

- **10 Watch Straps:** Customize your look for any occasion with a wide selection of interchangeable bands.
- **45mm Case Size:** A comfortable and visible display for all your notifications and data.

- **Wireless Charging:** Convenient and cable-free power replenishment.
- **Multiple Sports Modes:** Track various physical activities with dedicated modes.
- **Bluetooth Calls:** Make and receive calls directly from your wrist when connected to your smartphone.
- **New Dynamic Dial:** Enjoy a range of vibrant and interactive watch faces.
- **Skin-friendly Material:** Watch bands made from environmental-friendly and soft silicone for comfort during extended wear and high-intensity activities.



Image: The KEQIWEAR KW29 MAX Smartwatch, featuring a vibrant digital watch face with large numbers '09' and '35', encased in a metallic frame with a dark green silicone strap, presented on a white display stand.

## 4. SETUP GUIDE

### 4.1 Charging the Smartwatch

1. Place the back of your KEQIWEAR KW29 MAX Smartwatch onto the wireless charging pad.
2. Ensure the charging cable is connected to a compatible USB power adapter (not included) and plugged into a power source.
3. The watch display will indicate charging status. A full charge typically takes approximately 2 hours.

### 4.2 Powering On/Off

- **To Power On:** Press and hold the side button until the KEQIWEAR logo appears.
- **To Power Off:** Press and hold the side button, then select "Power Off" from the options on the screen.

### 4.3 Installing Watch Straps

Your smartwatch comes with 10 interchangeable straps. To install or change a strap:

1. Locate the quick-release pins on the back of each strap.
2. Slide the pin inwards and align the strap with the lug on the watch case.
3. Release the pin to secure the strap. Gently pull on the strap to ensure it is locked in place.

## 4.4 Pairing with Your Smartphone

To utilize all features, including Bluetooth calls and notifications, pair your smartwatch with your smartphone:

1. Download the official KEQIWEAR companion app from your smartphone's app store (iOS App Store or Google Play Store).
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the KEQIWEAR app and follow the on-screen instructions to add a new device.
4. Select "KW29 MAX" from the list of available devices.
5. Confirm the pairing request on both your smartphone and the smartwatch.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Basic Navigation

- **Swipe Up:** Access quick settings or notifications.
- **Swipe Down:** View notifications or quick settings.
- **Swipe Left/Right:** Navigate through widgets, apps, or different watch faces.
- **Tap:** Select an item or open an application.
- **Side Button:** Press to return to the home screen, or press and hold for power options.

### 5.2 Bluetooth Calls

Once paired with your smartphone, you can make and receive calls directly from your smartwatch:

- **Making a Call:** Access the dialer or contacts list on your watch, then tap to initiate a call.
- **Receiving a Call:** When a call comes in, tap the green icon on your watch to answer, or the red icon to decline.

### 5.3 Sports Modes

The KW29 MAX offers multiple sports modes to track your workouts:

1. From the main screen, swipe to find the "Sports" or "Workout" app.
2. Select your desired activity (e.g., Running, Cycling, Walking).
3. Tap to start tracking. The watch will display real-time data such as heart rate, calories burned, and duration.
4. Tap to pause or end the workout.

### 5.4 Changing Watch Faces

Personalize your smartwatch with dynamic watch faces:

- **On Watch:** From the home screen, press and hold the display. Swipe left or right to browse available watch faces and tap to select.
- **Via App:** Open the KEQIWEAR app on your smartphone, navigate to the "Watch Face" section, and download or customize new dynamic dials.



Image: A close-up of the KEQIWEAR KW29 MAX Smartwatch display, showing a red-themed watch face with analog-style hands and digital readouts for heart rate, steps, and other health metrics.

## 6. MAINTENANCE

### 6.1 Cleaning Your Smartwatch

- Wipe the screen and watch body with a soft, lint-free cloth.
- For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Clean the watch straps regularly, especially after intense workouts, using mild soap and water if necessary, then

rinse and dry thoroughly.

## 6.2 Battery Care

- Avoid fully discharging the battery frequently.
- Charge the device regularly, even if not in use, to maintain battery health.
- Do not expose the watch to extreme temperatures.

## 6.3 Software Updates

Periodically check for software updates via the KEQIWEAR companion app. Updates often include performance improvements, new features, and bug fixes.

## 7. TROUBLESHOOTING

Problem	Possible Solution
Watch not turning on	Ensure the watch is fully charged. Try pressing and holding the side button for at least 10 seconds to force a restart.
Cannot pair with smartphone	Ensure Bluetooth is enabled on your phone and the watch. Make sure the watch is within range of your phone. Restart both the watch and the phone. Forget the device in your phone's Bluetooth settings and try pairing again through the KEQIWEAR app.
Inaccurate activity tracking	Ensure the watch is worn snugly on your wrist. Check for software updates. Calibrate sensors via the app if available.
Notifications not appearing	Verify notification permissions are granted to the KEQIWEAR app on your smartphone. Ensure the watch is connected via Bluetooth. Check the watch's "Do Not Disturb" settings.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	KW29 MAX
Manufacturer	Keqiwear Germany
ASIN	B0CVTSQJRM
Visible Screen Diagonal	2" / 6 cm
Connectivity	Bluetooth
Charging Type	Wireless Charging

## 9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact

the manufacturer, Keqiwear Germany, directly. You may also visit their official website for the most up-to-date support resources.

*Note: Specific warranty terms may vary by region and retailer. Please retain your proof of purchase for warranty claims.*



© 2024 KEQIWEAR. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.