

Nor-Tec B0CVV52671

Nor-Tec Mini Wireless Bluetooth AZERTY Keyboard User Manual

Model: B0CVV52671

INTRODUCTION

Thank you for choosing the Nor-Tec Mini Wireless Bluetooth AZERTY Keyboard. This compact and versatile keyboard is designed to provide a seamless typing experience across various devices, including PCs, Macs, tablets, and smartphones. Its ultra-thin design, silent keys, and long-lasting battery make it an ideal companion for both work and leisure.

SAFETY INFORMATION

- Keep the keyboard away from water and other liquids.
- Do not expose the keyboard to extreme temperatures or direct sunlight.
- Avoid dropping or subjecting the keyboard to strong impacts.
- Do not attempt to disassemble or repair the keyboard yourself. Contact qualified personnel for service.
- Use only the provided USB-C cable for charging.

PACKAGE CONTENTS

- Nor-Tec Mini Wireless Bluetooth AZERTY Keyboard
- USB-C Cable
- User Manual (this document)

PRODUCT OVERVIEW

The Nor-Tec Mini Wireless Bluetooth AZERTY Keyboard features a compact design with 78 keys, including a full set of function keys and an AZERTY layout optimized for French language input. It is designed for portability and quiet operation.



Figure 1: Top view of the Nor-Tec Mini Wireless Bluetooth AZERTY Keyboard, showcasing its compact layout and key arrangement.



Figure 2: The retail packaging of the Nor-Tec Mini Wireless Bluetooth AZERTY Keyboard, highlighting its features and compatibility.

SETUP

1. Charging the Keyboard

Before first use, fully charge the keyboard. Connect the provided USB-C cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge provides extended usage time.

2. Bluetooth Pairing

Follow these steps to pair your keyboard with a device:

1. Ensure the keyboard is charged.
2. Locate the ON/OFF switch on the keyboard (usually on the side or top) and slide it to the "ON" position.
3. Press the "Connect" button (often a small button or a key combination like Fn + C) on the keyboard. The Bluetooth indicator light will start blinking, indicating it's in pairing mode.
4. On your device (PC, Mac, tablet, smartphone, Smart TV):

- Go to Bluetooth settings.
 - Turn on Bluetooth.
 - Search for available devices.
 - Select "Nor-Tec Keyboard" or a similar name from the list of found devices.
5. If prompted, enter the pairing code displayed on your device's screen using the Nor-Tec keyboard and press Enter.
 6. Once paired, the Bluetooth indicator light on the keyboard will stop blinking and remain solid or turn off, indicating a successful connection.

The keyboard supports universal compatibility with Windows, macOS, iOS, and Android operating systems. For optimal performance, ensure your device's Bluetooth version is 5.2 or higher, though it is backward compatible with older Bluetooth versions.

OPERATING

Basic Usage

Once successfully paired, the keyboard functions like a standard external keyboard. Simply open any text editor, browser, or application on your connected device and begin typing. The silent keys ensure a comfortable and discreet typing experience.

Function Keys (Fn)

The keyboard includes a 'Fn' key, which allows access to secondary functions printed on certain keys (e.g., media controls, volume adjustment, screen brightness). To use these functions, hold down the 'Fn' key and then press the desired function key.

- **Fn + F1-F12:** Access various system functions depending on your operating system.
- **Fn + OS-specific keys:** Some keys may have icons for Windows, Android, or iOS, allowing you to switch keyboard modes or access OS-specific shortcuts. Refer to your device's manual for specific key mappings.

MAINTENANCE

Cleaning

To clean the keyboard, gently wipe the surface with a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaning solution. Ensure no liquid enters the keyboard. Do not use harsh chemicals or abrasive materials.

Storage

When not in use for extended periods, turn off the keyboard to conserve battery life. Store it in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Keyboard does not turn on.	Low battery.	Charge the keyboard using the provided USB-C cable.
Cannot pair with device.	Bluetooth is off on device; keyboard not in pairing mode; device too far.	Ensure Bluetooth is enabled on your device. Put the keyboard into pairing mode. Move the keyboard closer to the device (within 10 meters).
Keys are not responding.	Keyboard is not connected; low battery; software glitch.	Check Bluetooth connection. Recharge the keyboard. Restart both the keyboard (turn off/on) and your device.
Typing lag or disconnections.	Interference; low battery; device overload.	Move away from other wireless devices. Recharge the keyboard. Close unnecessary applications on your device.

SPECIFICATIONS

Brand	Nor-Tec
Model	B0CVV52671
Keyboard Description	Mini Bluetooth AZERTY Keyboard
Connectivity Technology	Bluetooth 5.2
Number of Keys	78
Compatible Devices	Smart TV, PC, Tablet, Smartphone (Windows, macOS, iOS, Android)
Power Source	Battery
Color	Black
Product Dimensions	25 x 15 x 15 cm (approx. 9.8 x 5.9 x 5.9 inches)
Included Components	USB-C cable

WARRANTY AND SUPPORT

Nor-Tec products are designed for reliability and performance. For information regarding warranty coverage, please refer to the warranty card included with your purchase or contact your retailer. For technical support or further assistance, please reach out to the Nor-Tec customer service department through the contact information provided on the product packaging or the official Nor-Tec website.