

PHILIPS S5885/25

Philips SHAVER Series 5000 S5885/25 Electric Shaver User Manual

Model: S5885/25

1. INTRODUCTION

Welcome to the Philips SHAVER Series 5000 S5885/25 user manual. This document provides essential information for the safe and effective operation, maintenance, and care of your new electric shaver. Please read these instructions carefully before first use and retain them for future reference.

2. IMPORTANT SAFETY INFORMATION

WARNING:

- This appliance is 100% waterproof. It can be used in the shower or with shaving foam/gel. For safety, only use the shaver cordlessly when wet.
- Do not use the appliance if it is damaged.
- Keep the appliance and adapter dry.
- Do not immerse the adapter in water.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Only use the original adapter provided with the appliance.

3. PACKAGE CONTENTS

Upon unpacking, please verify that the following items are included:

- Philips SHAVER Series 5000 S5885/25 Electric Shaver
- Power Adapter

- Charging Stand
- Protective Cap
- Cleaning Brush
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Philips SHAVER Series 5000 S5885/25.



Image 1: The Philips SHAVER Series 5000 S5885/25 electric shaver shown with its charging stand. The shaver features a dark blue body with a silver power button and three rotary shaving heads. Indicator lights for battery, cleaning, and travel lock are visible on the handle.

1. Shaving Unit (with rotary blades)

2. Power Button
3. Battery Indicator
4. Cleaning Indicator
5. Travel Lock Indicator
6. Charging Socket
7. Charging Stand
8. Power Adapter

5. SETUP

Before using your shaver for the first time, ensure it is fully charged.

5.1 Initial Charge

1. Connect the power adapter to the charging stand.
2. Place the shaver into the charging stand.
3. Plug the adapter into a wall outlet.
4. The battery indicator lights will illuminate and flash to show charging progress. A full charge typically takes approximately 1 hour.
5. Once fully charged, all battery indicator lights will remain steadily lit for a few seconds before turning off.

6. CHARGING

The shaver operates cordlessly and requires charging. A full charge provides approximately 45 minutes of shaving time.

6.1 Battery Status Indicators

- **Flashing Lights:** Indicates the shaver is charging.
- **Solid Lights:** Indicates the battery is fully charged.
- **One Flashing Light:** Indicates the battery is low and needs recharging.

For optimal battery life, avoid leaving the shaver connected to the charger for extended periods after it is fully charged.

7. OPERATING THE SHAVER

Your Philips SHAVER Series 5000 S5885/25 is designed for both dry and wet shaving.

7.1 Dry Shaving

1. Ensure your face is clean and dry.
2. Press the power button to turn on the shaver.
3. Move the shaving heads in small, circular motions over your skin.
4. Apply gentle pressure.

7.2 Wet Shaving (with foam or gel)

1. Wet your face and apply shaving foam or gel.
2. Press the power button to turn on the shaver.
3. Move the shaving heads in small, circular motions over your skin.
4. Rinse the shaving heads under running water during shaving to prevent clogging.
5. After shaving, rinse your face and the shaver thoroughly.

Tip: For best results, shave against the direction of hair growth.

8. MAINTENANCE

Regular cleaning and maintenance ensure optimal performance and extend the lifespan of your shaver.

8.1 Cleaning After Each Use

1. Turn off the shaver.
2. Press the release button to open the shaving unit.
3. Rinse the shaving unit and the hair chamber thoroughly under warm running water.
4. Shake off excess water and leave the shaving unit open to air dry.
5. Close the shaving unit.

8.2 Deep Cleaning (Weekly)

1. Perform the steps for cleaning after each use.
2. Carefully remove the shaving heads from the shaving unit.
3. Clean each cutter and guard separately using the provided cleaning brush. Do not mix cutters and guards, as they are a matched set.
4. Rinse all parts under warm running water.
5. Allow all parts to air dry completely before reassembling.

8.3 Replacing Shaving Heads

For optimal shaving performance, it is recommended to replace the shaving heads every 12 months. Replacement heads can be purchased from authorized Philips retailers.

1. Turn off the shaver and disconnect it from the power source.
2. Open the shaving unit and remove the old shaving heads.
3. Insert the new shaving heads, ensuring they click into place correctly.
4. Close the shaving unit.

9. STORAGE

When not in use, store your shaver in a clean, dry place, away from direct sunlight and extreme temperatures. Ensure the protective cap is placed over the shaving heads to prevent damage.

10. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is empty. Travel lock is activated.	Charge the shaver. Press and hold the power button for 3 seconds to deactivate the travel lock.
Poor shaving performance.	Shaving heads are dirty or worn.	Clean the shaving heads thoroughly. Replace shaving heads if they are older than 12 months.
Shaver stops during use.	Battery is low.	Recharge the shaver.

11. SPECIFICATIONS

- **Model:** S5885/25
- **Brand:** PHILIPS
- **Power Source:** Electric cable (for charging)
- **Battery Life:** Approximately 45 minutes (cordless operation)
- **Charging Time:** Approximately 1 hour for a full charge
- **Blade Material:** Alloy steel
- **Head Type:** Rotary
- **Number of Blades:** 3
- **Waterproof:** 100% waterproof for wet and dry use
- **Color:** Black



Image 2: The Philips SHAVER Series 5000 S5885/25 electric shaver highlighting its 7-year motor and battery lifetime. This indicates the expected durability and longevity of key internal components.

12. WARRANTY AND SUPPORT

Philips offers a warranty on this product. For detailed warranty information, please refer to the warranty card included in your package or visit the official Philips website. For product support, troubleshooting

assistance, or to purchase replacement parts, please contact Philips customer service or visit their support portal.

You can find more information and support at the official Philips website: www.philips.com/support