

HIFI WALKER T10 Air

HIFI WALKER T10 Air Magnetic Charging Cable User Manual

Model: T10 Air

1. INTRODUCTION

This manual provides essential instructions for the proper use and maintenance of your HIFI WALKER T10 Air Magnetic Charging Cable. Please read this guide thoroughly before using the product to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

2.1 What's in the Box

- 2 x HIFI WALKER T10 Air Magnetic Charging Cables

2.2 Key Features

- Magnetic Attachment:** Ensures a secure and reliable connection for charging.
- 4-Pin Interface:** Specifically designed for compatibility with HIFI WALKER T10 Air Bone Conduction Headphones.
- USB Connectivity:** Standard USB-A connector for broad compatibility with power sources.
- Durable TPE Cable:** Constructed with Thermoplastic Elastomer (TPE) for flexibility and durability.
- Optimal Length:** Approximately 2 feet (62.5 cm) for convenient use.

MAGNETIC ATTACHMENT




Image 1: Magnetic attachment mechanism for the charging cable. The diagram illustrates how the magnetic pins align with the headphone's charging port.

TPE Cable



Image 2: Detailed view of the 4-pin magnetic connector, highlighting its design and contact points.

3. SETUP

To set up your HIFI WALKER T10 Air Magnetic Charging Cable, follow these steps:

- 1. Identify Components:** Locate the USB-A end of the charging cable and the magnetic 4-pin connector end.
- 2. Connect to Power Source:** Insert the USB-A end of the cable into a compatible USB power adapter (not included), a computer's USB port, or a power bank. Ensure the power source is functional.
- 3. Connect to Headphones:** Align the magnetic 4-pin connector with the charging port on your HIFI WALKER T10 Air Bone Conduction Headphones. The magnetic connection will automatically snap into place. Ensure the pins are correctly aligned for a secure connection.



Image 3: The HIFI WALKER T10 Air headphones are shown connected to a laptop via the magnetic charging cable, illustrating a typical charging setup.

4. OPERATING INSTRUCTIONS

Once the cable is securely connected to both a power source and your HIFI WALKER T10 Air headphones, charging will commence automatically. The charging status is typically indicated by an LED light on your headphones (refer to your headphone's manual for specific LED indicators).

- **Charging Time:** Charging duration varies based on the headphone's battery level and the power output of the USB source.
- **Data Transfer:** This cable is primarily designed for charging. While some data transfer may be possible, its primary function is power delivery.

5. MAINTENANCE

Proper care of your charging cable will extend its lifespan:

- **Cleaning:** Gently wipe the cable and magnetic connectors with a dry, soft cloth to remove dust or debris. Avoid using liquid cleaners directly on the connectors.

- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage to the internal wires.
- **Handling:** Always grasp the connector ends when plugging or unplugging the cable. Avoid pulling on the cable itself, as this can damage the internal wiring.

6. TROUBLESHOOTING

If you encounter issues with your charging cable, consider the following:

- **Headphones Not Charging:**
 - Ensure the USB-A end is fully inserted into a working power source.
 - Verify the magnetic 4-pin connector is securely attached and correctly aligned with the headphone's charging port.
 - Try a different USB power source or port.
 - Inspect the cable for any visible damage (frays, bends, or broken connectors). If damaged, discontinue use.
- **Loose Connection:**
 - Ensure there is no debris on the magnetic contacts of either the cable or the headphones.
 - Confirm the cable is designed for your specific HIFI WALKER T10 Air headphones.

7. SPECIFICATIONS

Feature	Detail
Brand	HIFI WALKER
Model Name	T10 Air
Connector Type	4-Pin Magnetic, USB-A
Cable Type	USB
Compatible Devices	HIFI WALKER T10 Air Bone Conduction Headphones
Special Feature	Magnetic Attachment
Cable Material	TPE
Cable Length	Approx. 2 feet (62.5 cm)
Color	Black
Number of Items	2 (Two-Pack)

Cable Length 2FT(62.5CM)



Image 4: The charging cable is displayed with its length clearly marked as 2 feet (62.5 cm).

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your original purchase or contact HIFI WALKER customer service directly through their official website or the retailer where the product was purchased.

Please retain your proof of purchase for warranty claims.