

EverNice 820287096

EverNice Zipper Foot Model 820287096 Instruction Manual

For Pfaff Sewing Machines

1. PRODUCT OVERVIEW

The EverNice Zipper Foot (Part Number: 820287-096, Alternate Part Number: 98-694404-00) is a specialized presser foot designed for sewing machines. Its primary function is to allow precise stitching close to zipper teeth, cording, or piping without obstruction. This design helps prevent accidental needle strikes on zipper components, ensuring a clean and professional finish.

2. COMPATIBILITY

This zipper foot is compatible with the following Pfaff Sewing Machine Models (Group A Models):

- 1027 Tipmatic
- 1147
- 301 Hobby
- 303 Hobby
- 307
- 309 Hobby
- 420
- 6086
- 6085
- 6087 Varimatic
- 875 Hobbymatic
- 939 Hobbymatic

3. INSTALLATION

Follow these steps to properly install the zipper foot on your compatible Pfaff sewing machine:

1. **Power Off:** Ensure your sewing machine is turned off and unplugged from the power outlet for safety.

2. **Raise Needle and Presser Foot:** Use the handwheel to raise the needle to its highest position. Lift the presser foot lever to raise the existing presser foot.
3. **Remove Current Foot:** Locate the presser foot release lever or screw, typically at the back of the presser foot holder. Release the current presser foot.
4. **Attach Zipper Foot:** Align the bar of the EverNice Zipper Foot with the presser foot holder. Lower the presser foot lever so that the holder snaps onto the zipper foot bar. Ensure it is securely attached.
5. **Verify Attachment:** Gently tug on the zipper foot to confirm it is firmly in place before proceeding.



Image 1: Side view of the EverNice Zipper Foot, highlighting the attachment mechanism.

4. OPERATING INSTRUCTIONS

The zipper foot is designed for specialized sewing tasks. Here's how to use it effectively:

1. **Positioning:** The zipper foot can be attached to either the left or right side of the needle, depending on which side of the zipper or cording you are sewing. Adjust the needle position if your machine allows for fine-tuning.
2. **Sewing Zippers:** Place the fabric and zipper under the foot. Position the foot so that its edge runs along the zipper teeth, allowing the needle to stitch very close to the teeth without hitting them. Sew slowly and guide the fabric evenly.

3. **Sewing Cording and Piping:** For cording or piping, align the foot so that the cord or piping fits snugly in the groove on the underside of the foot. This helps to keep the stitching straight and close to the edge of the cord.
4. **Fabric Guidance:** Always guide the fabric gently with both hands, ensuring it feeds smoothly under the foot. Do not push or pull the fabric forcefully.




Image 2: Top-down view of the EverNice Zipper Foot, illustrating the needle opening and guides for fabric.

5. MAINTENANCE

To ensure the longevity and optimal performance of your EverNice Zipper Foot:

- **Cleaning:** Periodically clean the foot with a soft, dry cloth to remove any lint, dust, or fabric fibers that may accumulate.
- **Storage:** Store the zipper foot in a dry, clean place, preferably in a sewing machine accessory box, to protect it from damage and dust.
- **Inspection:** Before each use, inspect the foot for any signs of wear, bending, or damage. A damaged foot can affect stitch quality or even damage your machine.

6. TROUBLESHOOTING

If you encounter issues while using the zipper foot, consider the following:

- **Uneven Stitches:** Ensure the foot is securely attached and the fabric is being fed evenly. Check your needle for bends or dullness.
- **Fabric Not Feeding:** Verify that the presser foot pressure is correctly adjusted for your fabric type. Ensure the feed dogs are engaged.
- **Needle Hitting Foot:** Double-check that the zipper foot is correctly aligned with the needle. Adjust the needle position if your machine allows, or re-attach the foot. Always turn the handwheel manually for a few stitches to confirm clearance before sewing at full speed.

7. SPECIFICATIONS



Image 3: Front view of the EverNice Zipper Foot.

Feature	Detail
Brand	EverNice
Item Model Number	820287096

Feature	Detail
Alternate Part Number	98-694404-00
Product Dimensions	3.94 x 3.94 x 3.94 inches
UPC	718245118540
Manufacturer	evernice

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support for your EverNice Zipper Foot, please refer to the specific policies provided by your retailer or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.