



[Manuals.plus](#) /

> [NIIMBOT](#) /

> NIIMBOT Clear Round Labels (50x50mm) Instruction Manual for B1/B21/B31 Printers

NIIMBOT BTZ3001

NIIMBOT Clear Round Labels (50x50mm) Instruction Manual

Model: BTZ3001

1. INTRODUCTION

This manual provides instructions for using NIIMBOT Clear Round Labels, model BTZ3001. These labels are designed for use with NIIMBOT B1, B21, and B31 portable Bluetooth label makers. They are suitable for various labeling needs in home, school, office, and small business environments.



Image: NIIMBOT Clear Round Labels (50x50mm) for B1/B21/B31 printers.

2. PRODUCT FEATURES

- **Genuine Labels:** Specifically designed for compatibility with NIIMBOT B1, B21, and B31 portable Bluetooth label makers.
- **Pre-cut Size:** Each label measures 50 x 50 mm (1.97" x 1.97"). Each roll contains 150 labels, with a total of 450 labels in a 3-roll set.
- **Durable Construction:** These labels are waterproof, oil-proof, and tear-resistant. They are self-adhesive and BPA-free, ensuring safe use.
- **Clean Removal:** Labels can be removed easily without leaving residue.
- **Print Color:** Designed for black and white printouts.



Image: Key features of NIIMBOT labels: waterproof, no ink required (thermal printing), self-adhesive, and removable.

3. COMPATIBILITY

These labels are compatible with the following NIIMBOT label printer models:

- NIIMBOT B1 Label Maker
- NIIMBOT B21 Label Maker
- NIIMBOT B31 Label Maker

Ensure your label printer is one of these models for proper function and optimal print quality.

Compatible with NIIMBOT B1/B21/B31 label printer



Image: NIIMBOT B1, B21, and B31 label printers, compatible with these labels.

4. SETUP: LOADING LABELS

To load the labels into your compatible NIIMBOT label printer, follow these general steps:

1. Open the label compartment cover on your NIIMBOT printer.
2. Insert the roll of NIIMBOT labels into the compartment, ensuring the printing side of the labels faces the print head. The labels should feed smoothly.
3. Pull a small section of the label roll out past the print head.
4. Close the label compartment cover securely.
5. **Important:** Do not remove or damage the sticker on the side of the label roll. This sticker contains a printing sensor chip essential for proper print effect and quality.

Your browser does not support the video tag.

5. OPERATING: PRINTING LABELS

Once the labels are loaded, you can begin printing using your NIIMBOT label maker and its associated mobile application.

1. Ensure your NIIMBOT label printer is powered on and connected via Bluetooth to your mobile device.
2. Open the NIIMBOT mobile application on your smartphone or tablet.
3. Select the desired label template or design your own label within the app.
4. Confirm the label size and type match the loaded NIIMBOT Clear Round Labels (50x50mm).
5. Initiate the print command from the application. The printer will automatically feed and print the labels.
6. Carefully tear off the printed label from the printer's output slot.

These labels are suitable for a wide range of applications, including:

- Labeling spice jars, key tags, canning jars, and pantry items.
- Organizing cables, food storage containers, and bottles.
- Creating plant pot labels and name labels for school items.
- General organization in home, office, and small business settings.



Image: Clear round labels used on food storage jars for organization.



Image: A clear round label applied to a shampoo bottle for bathroom organization.



Image: Labels used for organizing clothing in storage boxes.

Your browser does not support the video tag.

Video: Demonstrates printing gift labels, bakery food labels, photo labels, and barcode labels using a NIIMBOT B1 printer.

6. MAINTENANCE AND STORAGE

- **Storage:** Store unused label rolls in a cool, dry place away from direct sunlight and extreme temperatures to preserve adhesive quality and printability.
- **Handling:** Avoid touching the printing surface of the labels excessively before printing to prevent smudges or reduced print quality.
- **Printer Care:** Regularly clean the print head of your NIIMBOT label printer according to its specific instruction manual to ensure clear and consistent printing with these labels.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Poor print quality / Faint print	<p>Incorrect label loading.</p> <p>Damaged sensor chip on label roll.</p> <p>Dirty print head.</p> <p>Low printer battery.</p>	<p>Re-load labels correctly, ensuring the printing side faces the print head.</p> <p>Check if the sensor chip sticker is intact. Replace roll if damaged.</p> <p>Clean the printer's print head as per your printer manual.</p> <p>Charge the label printer.</p>
Labels not feeding	<p>Labels jammed.</p> <p>Label roll not properly seated.</p>	<p>Open cover, clear any jammed labels, and re-seat the roll.</p> <p>Ensure the label roll is firmly placed in its compartment.</p>
Labels not adhering well	<p>Surface is dirty or oily.</p> <p>Labels stored improperly.</p>	<p>Clean and dry the application surface before applying labels.</p> <p>Ensure labels are stored in a cool, dry place.</p>

8. SPECIFICATIONS

Attribute	Detail
Brand	NIIMBOT
Model Number (Labels)	BTZ3001
Color	Clear Round
Size	50x50mm (1.97" x 1.97")
Material	Plastic
Finish Type	Uncoated
Unit Count	3.0 Count (Rolls)
Number of Labels	450 (150 labels/roll x 3 rolls)
Ink Color	Clear (refers to label base, prints black)
Item Shape	Round

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your NIIMBOT labels or compatible label printer, please refer to the documentation provided with your specific label printer model or visit the official NIIMBOT website. Contact information for customer service is typically available on the product packaging or the manufacturer's website.



