

[Manuals.plus](#) /

> [Whirlpool](#) /

> Whirlpool 9 Kg Ozone Technology 5 Star Inverter Front Load Fully Automatic Washing Machine with In-Built Heater (XO9012BYM52E, Midnight Grey, 100+ Tough Stains, 1200 RPM) 9 Kg Grey User Manual

Whirlpool XO9012BYM52E

Whirlpool 9 Kg Front Load Washing Machine User Manual

Model: XO9012BYM52E

1. PRODUCT OVERVIEW

The Whirlpool 9 Kg Ozone Technology 5 Star Inverter Front Load Fully Automatic Washing Machine (Model: XO9012BYM52E) is designed to provide efficient and thorough laundry care. This appliance features advanced technologies such as Ozone Air Refresh, an In-Built Heater, and 6th Sense SoftMove, ensuring optimal cleaning and fabric protection. With a 9 kg capacity, it is suitable for households of 5-6 members.



Figure 1: Front view of the Whirlpool 9 Kg Front Load Washing Machine, highlighting Ozone Air Refresh Technology.

Key features include:

- **Ozone Air Refresh Technology:** Freshens clothes without water or detergent.
- **In-Built Heater:** Assists in removing tough stains and sanitizing clothes.
- **6th Sense SoftMove Technology:** Customised drum movements for different fabric types.

- **100 Tough Stains Removal:** Effectively removes a wide range of common stains.
- **Zero Pressure Fill (ZPF) Technology:** Ensures faster tub filling even with low water pressure.
- **Steam Wash Technology:** Removes up to 99.9% bacteria.
- **15 Wash Programs:** A variety of cycles for diverse laundry needs.

2. INSTALLATION AND SETUP

Proper installation is crucial for the optimal performance and longevity of your washing machine. This appliance is designed for freestanding installation.

2.1 Unpacking


Carefully remove all packaging materials. Ensure that all included components are present: Assembled Transport Bolts, Drain Hose, Liquid Detergent Separator, Transport Caps, and the User Manual.

2.2 Removing Transport Bolts

Before operating the machine, it is essential to remove the transport bolts located at the rear of the appliance. These bolts secure the drum during transit and must be removed to prevent damage during operation. Refer to the detailed instructions in the included user manual for the exact procedure.

2.3 Water Connection

Connect the water inlet hose to a cold water tap and the washing machine's inlet valve. Ensure all connections are secure to prevent leaks. The machine features Zero Pressure Fill (ZPF) Technology, allowing for efficient water filling even if the water pressure is as low as 0.017 MPa or if the water source is just 7 feet above the washing machine tap inlet.





ENERGY CONSUMPTION

0.0342*

KWh/kg/cycle

Label Period : 1st January 2024 to 31st December,2026

Appliance	: Washing Machine
Brand	: Whirlpool
Model / Year	: HA XC 90 BD 5S/2024
Type	: Front Load
Load Capacity	: 9 Kg
Water Consumption	: 9L/Kg/Cycle



BEE/Whi/21/4/19

*Under test conditions, when tested in accordance with latest IEC 60456 standards.
Actual energy consumption will depend on how the appliance is being used.

Why do you need Ozone Air Refresh?

Say goodbye to Laundry Days!

Frequent washing with detergent & water can reduce the life of fabrics in your clothes. Ozone Air Refresh can freshen your clothes, without taking it through a wash cycle, using the power of ozone!



Figure 2: Front and side views of the washing machine, illustrating its compact design for easy placement.

2.4 Drain Connection

Connect the drain hose to a suitable drain pipe or sink, ensuring it is properly secured and positioned to allow for effective water drainage.

2.5 Electrical Connection

Plug the washing machine into a grounded electrical outlet. Ensure the power supply matches the requirements specified in the appliance's technical data.

3. OPERATING INSTRUCTIONS

Your Whirlpool washing machine offers a range of programs and features for diverse laundry needs. The intuitive control panel with a premium metallic knob and advanced LED touch display makes operation simple.

3.1 Control Panel Overview



Figure 3: Detailed view of the control panel, showing the metallic knob and LED display.

The control panel features an On/Off button, Start/Pause button, and an LED display providing information about the selected program and cycle status. The premium metallic knob allows for easy selection of wash programs.

3.2 Wash Programs

The machine offers 15 wash programs to cater to various fabric types and soil levels:

- Sanitize
- Cotton
- Eco Cotton
- Bedding Curtains
- Rapid 30min
- Stainwash
- Baby care
- Daily wash
- Bed & bath

- Woollens
- Delicate
- Active Wear
- Rinse & Spin
- Spin & Drain
- Drum Clean

3.3 Special Technologies

Ozone Air Refresh Technology

This innovative technology allows you to freshen clothes without the need for water or detergent. It is ideal for daily office wear or premium dresses that do not require a full wash cycle but need to be refreshed.



Figure 4: Illustration of Ozone Air Refresh Technology in action.

6th Sense SoftMove Technology

The machine adapts drum movements automatically based on the type of clothes and load, ensuring optimal care for various fabrics. This technology provides 6 customised drum movements for different fabric types, including Daily Care (Mix Load), Slow Motion (Silk & Delicates), Power Shower (Duvets), Soft Cradle (Wool), Wave Motion (Denims), and Energetic Motion (Whites & Cottons).



Figure 5: Visual representation of 6th Sense SoftMove Technology and its drum movements.

Steam Wash Technology

This feature uses steam to remove up to 99.9% of bacteria, providing a hygienic wash for your garments.



Figure 6: Steam Wash Technology for enhanced hygiene.

100 Tough Stains Removal

This washing machine is designed to remove up to 100 tough stains, even those up to 48 hours old, including gravy, hair dye, BBQ sauce, ink, soup, oil stains, and more.



Figure 7: Examples of tough stains effectively removed by the washing machine.

3.4 Add Garment Feature

The 'Add Garment' feature allows you to pause the wash cycle and add forgotten items of clothing, providing flexibility during your laundry routine.

4. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your washing machine.

4.1 Cleaning the Drum

Utilize the dedicated 'Drum Clean' wash program periodically to clean the washing machine drum and prevent odor buildup. The drum is made of fully stainless steel for durability and hygiene.

4.2 Cleaning the Lint Filter

It is advisable to clean the lint filter after every few wash cycles to maintain optimal drainage and prevent

blockages.

4.3 Exterior Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your washing machine.

5.1 Machine Does Not Start

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check if the door is properly closed. The machine will not start if the door is ajar.
- Verify that a wash program has been selected and the Start/Pause button has been pressed.

5.2 Machine Does Not Drain Properly

- Check for any clogs in the drain hose or pump filter.
- Ensure the drain hose is not obstructed, kinked, or positioned too high.

5.3 Excessive Vibration or Noise

- Ensure the machine is level. Adjust the leveling feet if necessary.
- Verify that all transport bolts have been removed.
- Distribute the laundry evenly inside the drum to prevent imbalance.

For other issues or if troubleshooting steps do not resolve the problem, please contact customer support.

6. SPECIFICATIONS

Feature	Detail
Model	XO9012BYM52E
Capacity	9 Kilograms
Energy Rating	5 Star
Annual Energy Consumption	342 Kilowatt Hours Per Year
Maximum Rotational Speed	1200 RPM
Number of Wash Programs	15
Dimensions (LxWxH)	60D x 64W x 85H Centimeters

Item Weight	71 kg 200 g
Drum Material	Stainless Steel
Controller Type	Fully Automatic, Touch
Included Components	Assembled Transport Bolts, Drain Hose, Liquid Detergent Separator, Transport Caps, User manual



100* TOUGH
STAINS REMOVAL

Even Removes 48 Hour Old Tough Stains:

- Gravy
- Hair Dye with ammonia
- Ketchup
- Ink
- BBQ Sauce
- Soup
- Juice
- Soy Sauce
- Fried oil
- Highlighter pen



*T&C Apply

WIDE DRUM ACCESS



Figure 8: Product dimensions and energy efficiency label.

7. WARRANTY AND SUPPORT

Your Whirlpool washing machine comes with a comprehensive warranty to ensure peace of mind.

7.1 Warranty Information

The product includes a **2 Years Comprehensive Warranty** and an **8 years additional warranty on Motor**. The brand warranty can be availed using your Amazon invoice.

7.2 Customer Support

For any queries, service requests, or technical assistance, please contact Whirlpool customer care:

- **Toll-free Customer Care No.:** 18002081800
- **Email:** HELPDESKINDIA@WHIRLPOOL.COM

Manufacturer Address: WHIRLPOOL OF INDIA LTD, PLOT NO. 40, SECTOR-44, GURUGRAM, HARYANA-122002.

© 2024 Whirlpool. All rights reserved.