

[Manuals.plus](#) /

> [CUORY](#) /

> CUORY Smart TV 32-inch User Manual

## CUORY CUO-HDTV32

# CUORY Smart TV 32-inch User Manual

Model: CUO-HDTV32

## INTRODUCTION

Thank you for choosing the CUORY Smart TV 32-inch. This manual provides essential information for setting up, operating, and maintaining your new television. The CUORY Smart TV offers a DLED HD display for crisp and vibrant images with a resolution of 1366x768 pixels, integrated Android 12 for a wide range of applications, ATSC + SMART functionality for digital channels and online content, and Bluetooth connectivity for wireless audio. Its frameless design adds elegance to any space, complemented by versatile USB and HDMI ports.



Image: Front view of the CUORY 32-inch Smart TV, highlighting its key features like Bluetooth, Wi-Fi, and Dolby Audio support, along with the Android TV logo.

## SETUP

---

### Unboxing and Initial Inspection

Carefully remove all components from the packaging. Ensure the following items are present:

- 1x CUORY 32-inch LED TV
- Remote Control
- Power Cable
- TV Stands (2 pieces) and screws
- User Manual (this document)

Inspect the TV and accessories for any signs of damage. If any items are missing or damaged, contact customer support immediately.

### Attaching the TV Stands

To set up your TV on a table or flat surface, attach the included stands.

1. Place the TV face down on a soft, clean surface to prevent screen damage.
2. Align each stand with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws.



Image: Detail showing how the TV stand connects to the television unit.

Alternatively, the TV can be wall-mounted using a compatible VESA mount (not included). Refer to the wall mount's instructions for installation.



Image: Rear view of the CUORY 32-inch Smart TV, showing the mounting points and central panel.

## Connecting Peripherals

Your CUORY Smart TV offers various ports for connecting external devices.

- **HDMI Ports:** Connect Blu-ray players, gaming consoles, cable boxes, etc. The TV has multiple HDMI inputs.
- **USB Ports:** Connect USB drives for media playback or external keyboards/mice.
- **Optical Audio Output:** For connecting to soundbars or home theater systems.
- **RJ-45 (Ethernet) Port:** For a wired internet connection.
- **RF Input:** For connecting an antenna for digital terrestrial television (ATSC).
- **RCA Ports:** For older devices using composite video and stereo audio.



- Conexión de Audio Óptica
- Auricular
- Entrada RJ-45 para equipo de cómputo
- Cable de Radio Frecuencia



- 2 entradas HDMI
- 2 puertos USB
- Adaptadores de video



- Antena fácil de guardar

Image: Detailed view of the CUORY Smart TV's connectivity panel, showing various ports for audio, video, and network connections.



 **androidtv**



RCA



BLUETOOTH



USB

**HDMI**

2 PUERTOS

Image: Visual representation of the CUORY Smart TV's connectivity options, including RCA, Bluetooth, USB, and HDMI ports.

## Powering On

After connecting all desired devices, plug the power cable into the TV and then into a wall outlet. Press the power button on the remote control or on the TV itself to turn it on.

## OPERATING YOUR CUORY SMART TV

---

### Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup wizard. This includes:

- Language selection
- Network connection (Wi-Fi or Ethernet)
- Google account sign-in (optional, for full Android TV features)
- Channel scanning (for ATSC digital channels)
- Time zone and date settings

### Smart TV Features (Android 12)

Your CUORY Smart TV runs on Android 12, providing access to a vast array of applications and streaming services through the Google Play Store.

- **App Access:** Navigate the home screen to find pre-installed apps like Netflix, YouTube, Prime Video, and Spotify. Download more from the Google Play Store.
- **Voice Control:** Use the built-in voice assistant (if available on your remote) to search for content, control playback, and get information.
- **Casting:** Cast content from your smartphone or tablet directly to the TV using built-in casting features.



Image: The CUORY Smart TV screen showing the Android TV home interface with popular streaming applications like Netflix and YouTube.

### Remote Control Usage

The included remote control allows full navigation and control of your TV. It features dedicated buttons for popular streaming services for quick access.



Puerto USB



Entrada  
HDMI



Pantalla LED



## Smart TV 32" HD

- Android 12
- **Resolución** HD1366x768px
- ATSC+Smart
- Efectos de sonido: **Estándar, música, películas, deportes**
- **Control remoto con accesos directos**



Image: The CUORY 32-inch Smart TV alongside its remote control, with a list of features including Android 12, HD resolution, ATSC+Smart, sound effects, and direct access remote buttons.



Image: A close-up view of the CUORY Smart TV remote control, highlighting the dedicated buttons for popular streaming services like Netflix, Prime Video, and YouTube.

## Audio Features (Dolby Atmos)

Experience enhanced audio with Dolby Atmos support, providing immersive sound for your movies, shows, and games. You can adjust sound effects (Standard, Music, Movies, Sports) through the TV's audio settings.



Image: The CUORY Smart TV showcasing a dynamic visual, accompanied by the Dolby Audio logo, indicating its advanced sound capabilities.



Image: The CUORY Smart TV displaying a serene sunset scene over water, with the prominent Dolby logo, emphasizing its audio quality.

## Connectivity

- **Wi-Fi:** Connect to your home wireless network for internet access.
- **Bluetooth:** Pair wireless headphones, soundbars, or other Bluetooth-enabled audio devices.
- **HDMI:** Switch between connected HDMI devices using the input/source button on your remote.
- **USB:** Access media files (photos, videos, music) from a connected USB storage device.

## MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your CUORY Smart TV.

- **Cleaning the Screen:** Use a soft, lint-free cloth specifically designed for electronics. Do not use harsh chemicals or abrasive cleaners. Lightly dampen the cloth with water if necessary, and wipe gently.
- **Cleaning the Body:** Wipe the TV's frame and back panel with a soft, dry cloth.
- **Ventilation:** Ensure the TV's ventilation openings are not blocked to prevent overheating. Maintain adequate space around the TV.
- **Power Off When Not in Use:** For extended periods of inactivity, it is recommended to unplug the TV from the power outlet.

## TROUBLESHOOTING

---

If you encounter issues with your CUORY Smart TV, refer to the following common solutions.

Problem	Possible Cause / Solution
<b>No Power / TV won't turn on</b>	Ensure the power cable is securely plugged into the TV and the wall outlet. Check if the wall outlet is working by plugging in another device. Try pressing the power button on the TV itself, not just the remote.
<b>No Picture / Black Screen</b>	Verify the correct input source is selected (e.g., HDMI 1, HDMI 2). Check cable connections between the TV and external devices. Try restarting the connected device.

Problem	Possible Cause / Solution
<b>No Sound</b>	<p>Increase the volume.</p> <p>Check if the TV is muted.</p> <p>If using external audio devices, ensure they are properly connected and powered on.</p> <p>Check audio output settings in the TV menu.</p>
<b>Smart TV is Slow / Apps Freeze</b>	<p>Ensure a stable internet connection.</p> <p>Close unused applications running in the background.</p> <p>Clear cache for problematic apps in the TV settings.</p> <p><b>Perform a factory reset:</b> Go to Settings &gt; System &gt; About &gt; Reset. <i>Note: This will erase all data and settings.</i></p>
<b>HDMI Port Not Functioning</b>	<p>Try a different HDMI cable.</p> <p>Connect the device to another HDMI port on the TV.</p> <p>Restart both the TV and the connected device.</p>
<b>Missing Remote Control or Base</b>	<p>If these accessories were missing upon delivery, contact your retailer or CUORY customer support immediately. Universal remotes may not fully support all Android TV functions.</p>

## SPECIFICATIONS

Detailed technical specifications for the CUORY Smart TV 32-inch (Model: CUO-HDTV32).

Feature	Detail
<b>Brand</b>	CUORY
<b>Model Name</b>	CUO-HDTV32
<b>Model Year</b>	2024
<b>Screen Size</b>	32 Inches (82 cm visible diagonal)
<b>Display Technology</b>	DLED HD
<b>Resolution</b>	1366x768 pixels (Supports 1080p input)
<b>Refresh Rate</b>	60 Hz
<b>Operating System</b>	Android 12
<b>Tuner Technology</b>	ATSC
<b>Hardware Interface</b>	HDMI, USB
<b>Special Features</b>	Built-in Speaker, Parental Control, HDMI, USB
<b>Remote Control Technology</b>	Bluetooth
<b>Audio Output Mode</b>	Stereo, Digital, Surround (Dolby Atmos support)
<b>Aspect Ratio</b>	16:9

Feature	Detail
Mounting Type	Table Stand
Product Dimensions (LxWxH)	76 x 9 x 46 cm
Product Weight	5 kg



Image: Side profile of the CUORY 32-inch Smart TV, showcasing its slim design.

Your CUORY Smart TV comes with a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official CUORY website.

For technical support, troubleshooting assistance, or inquiries about replacement parts, please contact CUORY customer service.

- **CUORY Official Store:** [Visit CUORY Store on Amazon](#)
- **Protection Plans:** Extended warranty options may be available through your retailer.

© 2024 CUORY. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.