

[Manuals.plus](#) /

› [Timex](#) /

› Timex Women's Main Street 25mm Watch TW2W353009J User Manual

Timex TW2W353009J

Timex Women's Main Street 25mm Watch TW2W353009J User Manual

Model: TW2W353009J

1. INTRODUCTION

This manual provides instructions for the Timex Women's Main Street 25mm Watch, model TW2W353009J. This timepiece features a 25mm silver-tone case, a mother-of-pearl dial, and a silver-tone expansion band. It is equipped with a quartz movement and Timex's Indiglo night-light feature.



Image 1.1: Front view of the Timex Women's Main Street 25mm Watch, showcasing the mother-of-pearl dial and silver-tone expansion band.

2. SETUP

2.1 Setting the Time

1. **Pull the Crown:** Gently pull the crown (the small knob on the side of the watch case) out to the first position.
2. **Adjust Time:** Rotate the crown in either direction to move the hour and minute hands to the correct time.
3. **Push the Crown In:** Once the time is set, push the crown back into its original position to start the watch movement.

2.2 Adjusting the Expansion Band

The watch features an expansion band designed for easy adjustment. Links can be removed to achieve a comfortable fit. For precise adjustment, it is recommended to consult a jeweler or refer to the Timex Sizing Chart video for guidance on self-adjustment.



Image 2.1: Side view of the watch, illustrating the flexible expansion band construction.





Image 2.2: Top-down view of the watch band, showing the two-tone link design.

Your browser does not support the video tag.

Video 2.1: Timex Sizing Chart. This video demonstrates how to measure your wrist and understand watch case sizes for optimal fit. It also provides general guidance on band adjustment.

3. OPERATING INSTRUCTIONS

3.1 Indiglo Night-Light

To activate the Indiglo night-light, press and hold the crown. The entire watch dial will illuminate for easy viewing in low-light conditions.

3.2 Water Resistance

This watch is water resistant to 30 meters (100 feet). This means it is suitable for splashes or brief immersion in water, but not for swimming, showering, or diving. Do not operate the crown while the watch is wet.

4. MAINTENANCE

4.1 Cleaning Your Watch

- **Case and Crystal:** Wipe with a soft, damp cloth. Avoid harsh chemicals.
- **Metal Band:** Use a soft brush and mild soapy water to clean the links. Rinse thoroughly and dry immediately with a soft cloth.

4.2 Battery Replacement

The watch uses one Lithium Metal battery (included). When the watch stops running, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance.



Image 4.1: Back view of the watch case, showing the stainless steel back and water resistance marking.

4.3 Storage

When not wearing your watch, store it in a dry place away from direct sunlight and extreme temperatures. Avoid exposing it to strong magnetic fields.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Crown pulled out; Dead battery	Push crown in; Replace battery (professional service recommended)
Time is inaccurate	Low battery; Exposure to strong magnetic fields	Replace battery; Move watch away from magnetic sources
Band feels too tight/loose	Incorrect band size	Adjust band by removing/adding links (professional service recommended)

6. SPECIFICATIONS

- **Model Number:** TW2W353009J
- **Case Diameter:** 25 Millimeters
- **Case Material:** Brass
- **Band Material:** Stainless Steel
- **Band Width:** 12 Millimeters
- **Band Length:** 7.5 Inches
- **Dial Color:** Multicolor (Mother of Pearl)
- **Crystal Type:** Mineral Glass
- **Movement Type:** Quartz
- **Power Source:** Battery Powered (1 Lithium Metal battery included)
- **Water Resistance Depth:** 30 Meters (100 Feet)
- **Special Features:** Indiglo Night-Light

7. WARRANTY AND SUPPORT

This Timex watch is covered by a Limited Warranty. For specific warranty details, claims, or technical support, please refer to the warranty information provided with your purchase or visit the official Timex website. Keep your proof of purchase for warranty service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CVYLV9B1>

More documents and user manuals: <https://manuals.plus/>