



[Manuals.plus](#) /

> [Gizoon](#) /

> Gizoon 67.1" Tall Bathroom Storage Cabinet User Manual (Model AP17)

Gizoon AP17

Gizoon 67.1" Tall Bathroom Storage Cabinet User Manual

Model: AP17

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Gizoon 67.1" Tall Bathroom Storage Cabinet. Please read these instructions carefully before assembly and use to ensure safe and proper functionality.

SAFETY INFORMATION

Important Safety Precautions:

- Ensure proper mounting to prevent tipping. An anti-tipping device is included and must be installed for stability and safety.
- Do not exceed the weight limit of the shelves to avoid breakage or injury.
- Keep small parts away from children during assembly.

PRODUCT FEATURES

- **Adjustable Shelves:** Features two doors and four compartments with removable or height-adjustable baffles for customized storage.
- **Stable and Secure Design:** Constructed from FSC-certified wood with a waterproof finish. Includes magnetic catches for doors and an anti-tipping device for enhanced stability.
- **Space Optimization:** Tall linen tower design with a compact footprint, ideal for various rooms.
- **Versatile Use:** Suitable for bathroom toiletries, kitchen spices, or as a bookcase in a study.
- **Frosted Glass Door:** Allows visibility of contents while maintaining a modern aesthetic.

ASSEMBLY INSTRUCTIONS

The Gizoon storage cabinet is designed for straightforward assembly. All necessary parts are numbered, and clear

instructions along with assembly tools are provided in the package.

1. Unpack all components and verify against the parts list provided in your package.
2. Follow the step-by-step diagrams and instructions carefully. Ensure not to overtighten screws until the entire unit is assembled.
3. Attach the anti-tipping device to the wall as instructed to secure the cabinet and prevent accidental tipping.



Image: Detailed dimensions of the Gizoon storage cabinet (11.8"D x 15.7"W x 67.1"H) and weight capacities for each shelf (up to 66 lbs for top/bottom, 55 lbs for middle shelves).

3-LEVEL ADJUSTABLE SHELF

OPTIONAL TWO-WAY DOOR OPENING



Image: Illustration showing the 3-level adjustable shelves and the optional two-way door opening for both upper (glass) and lower (solid) cabinet sections.



Image: Close-up view highlighting the frosted glass cabinet door, magnetic mute door catch, integrated anti-tipping device for safety, and the open storage space between the upper and lower cabinets.

Your browser does not support the video tag.

Video: Official product video demonstrating the 67-inch tall storage cabinet in various settings and highlighting its features. This video is provided by the seller, Gizoon Direct.

OPERATING INSTRUCTIONS

- **Adjusting Shelves:** The internal shelves can be removed or repositioned to different heights to accommodate items of various sizes. Refer to the assembly instructions for details on adjusting shelf pins.
- **Door Operation:** The cabinet features two-way doors. Gently pull the knob to open and push to close. Magnetic catches ensure the doors remain securely shut.
- **Placement:** This versatile cabinet can be used in bathrooms, kitchens, living rooms, or laundry rooms for organized storage.



Image: The Gizoon storage cabinet positioned in a bathroom, showcasing its use for storing towels, toiletries, and decorative items.



Image: The Gizoon storage cabinet placed in a living room corner, demonstrating its versatility for displaying books and decorative objects.



Image: The Gizon storage cabinet utilized in a kitchen, providing storage for small appliances, dishes, and other kitchen essentials.

MAINTENANCE

To maintain the appearance and longevity of your cabinet:

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Promptly wipe up any spills to prevent water damage, especially in humid environments like bathrooms.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your Gizon storage cabinet, please refer to the following common solutions:

- **Wobbly Cabinet:** Ensure all cam locks and screws are fully tightened. Verify the cabinet is placed on a level

surface. Install the anti-tipping device securely.

- **Doors Not Closing Properly:** Check if hinges are correctly aligned and tightened. Ensure no items are obstructing the door's path.
- **Missing Parts:** If any parts are missing upon unboxing, please contact customer support immediately.

SPECIFICATIONS

Feature	Detail
Brand	Gizoon
Model Number	AP17
Color	White
Material	Engineered Wood
Product Dimensions (D x W x H)	11.8"D x 15.7"W x 67.1"H
Item Weight	35.7 Pounds
Number of Doors	2
Number of Shelves	3 (Adjustable)
Installation Type	Freestanding
Assembly Required	Yes
Care Instructions	Wipe with Damp Cloth

WARRANTY AND SUPPORT

Gizoon is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, if you have any questions or require assistance during use, please contact Gizoon customer support. We aim to provide answers within 24 hours.

For support, please visit the [Gizoon Store on Amazon](#).