

Yaheetech 29in Zero Gravity Chair

Yaheetech 29-inch Zero Gravity Recliner Chair Instruction Manual

Brand: Yaheetech | Model: 29in Zero Gravity Chair

PRODUCT OVERVIEW

The Yaheetech 29-inch Zero Gravity Recliner Chair is designed for comfort and versatility, suitable for both indoor and outdoor use. It features an adaptive reclining system, a sturdy steel frame, and a removable padded cushion for enhanced comfort, especially in cooler seasons. The chair is foldable for easy storage and transport, and includes a side accessory tray.

- **Adaptive Reclining System:** Adjusts to various angles for activities like napping, sunbathing, reading, or fishing. The backrest can be securely locked at your preferred angle.
- **Strong & Stable Construction:** Features a high-hardness painted steel frame with a triangular structure, supporting up to 182 kg (400 lb). Anti-slip sleeves on legs and footrest ensure stability.
- **Removable Padded Cushion:** An 8 cm (3.15 inch) thick removable pad provides additional softness and warmth, ideal for cool weather. The chair can also be used without the pad, revealing a breathable 550g Texteline fabric surface.
- **Upgraded Details:** Includes a movable, high-density foam pillow for head or back support. A small latch facilitates effortless folding, and a shoulder strap on the carry bag offers convenient transport.
- **Multi-Scenario Application:** Suitable for gardens, poolsides, lawns, beaches, camping, or indoor relaxation.

SETUP

The Yaheetech Zero Gravity Recliner Chair arrives fully assembled. Simply unfold the chair and attach the accessories as desired.

1. **Unfolding the Chair:** Carefully unfold the chair until it is fully extended and stable on a flat surface. Ensure all locking mechanisms are disengaged before unfolding.
2. **Attaching the Removable Pad:** The padded cushion can be secured to the chair frame using the

attached ties. Thread the ties through the designated loops on the chair frame and tie them securely to prevent the cushion from shifting.


3. **Attaching the Movable Pillow:** The headrest pillow is adjustable. Slide the elastic strap of the pillow over the top of the chair's backrest. Adjust its position up or down to suit your comfort.
4. **Attaching the Side Accessory Tray:** The detachable accessory tray can be clipped onto either side of the chair's armrest. Ensure it clicks firmly into place for stability.




Image: The Yaheetech 29-inch Zero Gravity Recliner Chair in its fully assembled state with the removable pad and side accessory tray attached.

DETACHABLE CUPHOLDER

Keep your drinks and devices easily accessible



Book Rest



2 Cup Holders



Phone Mount

Image: A detailed view of the detachable side accessory tray, featuring two cup holders and multiple slots designed to hold a phone, tablet, or other small items.

OPERATING INSTRUCTIONS

- 1. Reclining the Chair:** To recline, gently push back with your body weight while pushing your feet forward on the footrest. The chair will smoothly transition into a reclined position.
- 2. Locking the Recline Position:** Once you find your desired recline angle, locate the red locking rings on the underside of each armrest. Push these rings downwards to engage the lock and secure the chair in position.
- 3. Returning to Upright Position:** To return to an upright position, lift the red locking rings on both sides to disengage the lock. Then, gently lean forward, allowing the chair to return to its original sitting position.
- 4. Folding for Storage:** To fold the chair, ensure it is in the upright position and the locking rings are disengaged. Push the front and back legs towards each other until the chair folds flat. Secure with any integrated locking mechanisms for compact storage.



Image: A close-up view of the red locking ring located beneath the armrest, used to secure the chair in a reclined position.



Image: A visual representation illustrating the range of reclining positions, from an upright sitting posture to a fully reclined zero-gravity position.

MAINTENANCE

- **Cushion Care:** The removable padded cushion can be spot cleaned with a mild detergent and water. For thorough cleaning, follow the care instructions on the cushion label, typically recommending dry cleaning. Ensure the cushion is completely dry before reattaching or storing.
- **Frame Cleaning:** Wipe the painted steel frame with a damp cloth and mild soap. Avoid abrasive

cleaners that could damage the finish. Dry thoroughly to prevent rust.

- **Texteline Fabric Care:** The 550g Texteline fabric is breathable and wear-resistant. It can be cleaned with a damp cloth and mild soap. Its quick-drying properties make it suitable for outdoor use.
- **Storage:** When not in use, especially during inclement weather or off-season, fold the chair and store it in a dry, protected area to prolong its lifespan.



Image: A comparison illustrating the chair's breathable Texteline mesh fabric when the cushion is removed, alongside the soft, tufted padded cushion.

TROUBLESHOOTING

- **Chair not reclining smoothly:** Ensure the locking rings on both armrests are fully disengaged. Check for any obstructions in the reclining mechanism.
- **Chair not locking in position:** Verify that the locking rings are pushed firmly downwards to engage the lock. Ensure the chair is on a level surface.
- **Accessory tray feels loose:** Re-attach the accessory tray, ensuring it snaps securely into place on the armrest.
- **Cushion slipping:** Ensure all ties on the cushion are securely fastened to the chair frame.

SPECIFICATIONS

Feature	Detail
Brand	Yaheetech
Model Name	29in Zero Gravity Chair
Color	Grey
Material	Painted Steel, 550g Texteline, Foam
Product Dimensions (D x W x H)	35"D x 29"W x 43"H
Item Weight	21.05 Pounds
Maximum Weight Recommendation	400 Pounds
Reclining Position Count	3
Is Foldable	Yes

Feature	Detail
Required Assembly	No




Image: A diagram illustrating the key dimensions of the chair, including height, width, depth, and folded dimensions.

SAFETY WARNINGS

- Do not exceed the maximum weight capacity of 400 lb (182 kg).
- Fold the chair with care to avoid injury from pinching.
- Ensure the chair is fully unfolded and all locking mechanisms are engaged before use.
- Always use on a stable, level surface.

WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Yaheetech customer service. Refer to your purchase documentation for specific warranty terms and contact details. You may also visit the official Yaheetech store on Amazon for additional product information and support: [Yaheetech Store](#)

