Swann SWIFI-4KXTRM-GL

Swann Xtreem 4K Wireless Security Camera User Manual

Brand: Swann | **Model:** SWIFI-4KXTRM-GL

Overview | What's in the Box | Setup | Features | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Overview

The Swann Xtreem 4K Wireless Security Camera is designed to provide comprehensive surveillance for both indoor and outdoor environments. Featuring crystal-clear 4K video resolution, this camera offers detailed monitoring day and night. Its 100% wireless design, powered by a long-lasting rechargeable battery, allows for flexible placement without the need for complex wiring. Advanced features like True Detect heat and motion sensing, two-way talk, and active deterrence (spotlights and siren) enhance security and provide real-time alerts. Recordings can be stored locally on the included 32GB Micro SD card or backed up to the cloud via the Swann Security App, with no monthly fees required for basic functionality.



Figure 1: The Swann Xtreem 4K Wireless Security Camera, designed for versatile placement.

2. What's in the Box

Upon unboxing your Swann Xtreem 4K Wireless Security Camera, please ensure all the following components are present:

- XTREEM4K™ Camera
- Outdoor Stand
- USB to USB-C Charging Cable
- 32GB Micro SD Card
- Mounting Screws & Plugs
- Operating Instructions (this manual)
- Theft Deterrent Stickers




Figure 2: All components included with the Swann Xtreem 4K Wireless Security Camera.

3. Setup

Setting up your Swann Xtreem 4K camera is a straightforward process designed for quick deployment. Follow these steps to get your camera operational:

1. **Charge the Camera:** Before initial use, fully charge the camera using the provided USB to USB-C charging cable. A

full charge ensures optimal battery performance.

2. **Download the Swann Security App:** Search for "Swann Security" in your smartphone's app store (iOS or Android) and download the application.
3. **Create an Account:** Open the app and follow the on-screen prompts to create a new account or log in if you already have one.
4. **Add Your Camera:** Within the app, select the option to add a new device. Follow the app's instructions to connect your Xtreem 4K camera to your home Wi-Fi network. This typically involves scanning a QR code on the camera.
5. **Insert Micro SD Card:** Locate the Micro SD card slot on the camera and insert the included 32GB Micro SD card for local storage.
6. **Mount the Camera:** Choose a suitable location for your camera, considering the desired viewing angle and Wi-Fi signal strength. Use the outdoor stand, mounting screws, and plugs to securely install the camera. The camera is designed for both indoor and outdoor use.




Figure 3: Installation and connection steps for the Swann Xtreem 4K camera.

4. Key Features

4.1. Crystal Clear 4K Video

Experience superior clarity with 4K Ultra HD resolution, capturing every detail with precision. This high resolution is crucial for identifying faces, license plates, and other important visual information, providing enhanced security coverage.



Figure 4: The 4K resolution provides exceptional detail for monitoring your property.

4.2. 100% Wireless & Long Battery Life

The Xtreem 4K camera operates completely wirelessly, offering unparalleled flexibility in placement. Its powerful rechargeable battery can last up to 120 days on a single charge, minimizing the need for frequent recharging. This extended battery life is optimized for various environmental conditions, including cold and hot climates.



Figure 5: The camera features an extra-long battery life of up to 120 days.

4.3. True Detect Heat & Motion Sensing

Equipped with Swann's True Detect technology, the camera intelligently identifies heat and motion from objects like people and cars, reducing false alarms triggered by environmental factors such as wind or rain. This ensures you receive relevant alerts and conserve battery life by only recording significant events.



Figure 6: True Detect ensures accurate motion and heat detection, minimizing irrelevant recordings.

4.4. Color Night Vision

The camera provides clear color night vision, allowing you to see details in low-light conditions that traditional black and white night vision might miss. This feature is particularly useful for identifying colors of clothing or vehicles at night.




Figure 7: See clear, colorful images even in low light conditions.

4.5. Two-Way Talk

Communicate directly with visitors or deter intruders using the built-in microphone and speaker. This two-way audio functionality allows you to greet guests, instruct delivery personnel, or issue warnings from anywhere via the Swann Security App.




Figure 8: Engage in real-time conversations with two-way audio.

4.6. Local & Cloud Storage

The camera comes with a 32GB Micro SD card for local storage of recorded footage. Additionally, you can utilize cloud backup options through the Swann Security App, providing an extra layer of security for your recordings without mandatory monthly fees.



Figure 9: Securely store your footage locally and with cloud backup options.

4.7. Active Deterrence

When motion is detected, the camera can automatically trigger its built-in spotlights and siren to deter unwanted visitors. This proactive security measure adds an immediate layer of protection to your property.



Figure 10: Deter potential threats with integrated spotlights and a siren.

5. Operation

The Swann Xtreem 4K camera is primarily operated through the intuitive Swann Security App. This app provides full control and access to your camera's features.

- **Live View:** Access a real-time video feed from your camera at any time, from anywhere, directly through the app.
- **Playback:** Review recorded footage stored on your Micro SD card or in the cloud. The app allows you to easily navigate through timelines and specific events.
- **Alerts & Notifications:** Receive instant push notifications on your smartphone when motion or heat is detected, allowing you to respond promptly.
- **Customization:** Adjust camera settings such as motion sensitivity, recording schedules, and deterrence options (spotlight, siren) directly from the app.
- **Sharing Access:** Grant access to your camera's feed and features to trusted family members or friends through the

multi-user sharing function in the app.



Figure 11: Monitor your property and family activities with the Swann Security App.

6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your Swann Xtreem 4K camera.

- **Battery Charging:** Recharge the camera battery when prompted by the Swann Security App. The frequency of charging depends on usage and environmental conditions. Use only the provided charging cable.
- **Micro SD Card Management:** The camera features rolling recording, meaning it will automatically overwrite the oldest footage once the 32GB Micro SD card is full. You do not need to manually delete files. If you wish to save specific footage, download it to your device via the app before it is overwritten.
- **Cleaning:** Periodically clean the camera lens and housing with a soft, damp cloth to remove dust, dirt, or water spots that may obstruct the view. Avoid using harsh chemicals or abrasive materials.
- **Firmware Updates:** Keep your camera's firmware updated through the Swann Security App to ensure you have the latest features, security enhancements, and bug fixes.

7. Troubleshooting

If you encounter issues with your Swann Xtreem 4K camera, consider the following common solutions:

- **No Power/Not Charging:**
  - Ensure the USB-C cable is securely connected to both the camera and a working USB power source.
  - Verify the power adapter or USB port is functional.
  - Allow the camera to charge for several hours, especially if it has been fully depleted.
- **Wi-Fi Connectivity Issues:**
  - Ensure the camera is within range of your Wi-Fi router.
  - Check your Wi-Fi password for accuracy.
  - Restart your Wi-Fi router and the camera.
  - If issues persist, try resetting the camera to factory settings (refer to the app for specific instructions) and re-pairing it.
- **Poor Video Quality:**
  - Clean the camera lens.
  - Ensure adequate lighting, especially for night vision.
  - Check your Wi-Fi signal strength; a weak signal can affect streaming quality.
- **False Motion Alerts:**
  - Adjust the motion sensitivity settings in the Swann Security App.
  - Ensure the camera's field of view does not include excessive movement from trees, flags, or busy roads if not desired.
  - True Detect technology is designed to minimize false alerts from non-heat generating objects.
- **No Recording:**
  - Verify the 32GB Micro SD card is correctly inserted and not full.
  - Check recording schedules and motion detection settings in the app.
  - Ensure the camera has sufficient battery charge.

For more detailed troubleshooting or persistent issues, please refer to the Swann Security App's help section or the official Swann support website.

8. Specifications

Feature	Detail
Model Number	SWIFI-4KXTRM-GL
Video Capture Resolution	4K (8MP)
Indoor/Outdoor Usage	Outdoor, Indoor
Power Source	Battery Powered (1 Lithium Ion battery included)
Connectivity Protocol	Wi-Fi
Viewing Angle	110 Degrees
International Protection Rating	IP65 (Weatherproof)
Included Storage	32GB Micro SD Card
Battery Life	Up to 120 days (rechargeable)
Dimensions (L x W x H)	2.83 x 7.87 x 8.27 inches
Item Weight	1.52 pounds
Special Features	App Control, 2-Way Talk, Color Night Vision, Motion Detection, Siren, Spotlight

9. Warranty and Support

Swann products are backed by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Swann website. For technical support, product registration, and frequently asked questions, please visit www.swann.com/us/support. You can also access support resources directly through the Swann Security App.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Will the Swann Xtreem 4K Wireless Security Camera work in a shed without Wi-Fi once it has been set up at home?

The Swann Xtreem 4K Wireless Security Camera (SWIFI-4KXTRM-GL) can record to the included 32GB Micro SD card without an active Wi-Fi connection, but its functionality will be significantly limited. Here is what you need...

Read full answer