

IMIKI MT2

IMIKI BUDS PRO MT2 True Wireless Earbuds User Manual

Model: MT2

INTRODUCTION

Thank you for choosing the IMIKI BUDS PRO MT2 True Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual carefully before use and retain it for future reference.

SAFETY INFORMATION

- Do not disassemble or modify the earbuds or charging case.
- Keep the device away from extreme temperatures, humidity, and corrosive substances.
- Avoid dropping or subjecting the device to strong impacts.
- Clean the earbuds and charging case with a soft, dry cloth. Do not use harsh chemicals.
- Keep out of reach of children and pets.
- Dispose of the device responsibly according to local regulations.

PRODUCT OVERVIEW

The IMIKI BUDS PRO MT2 are true wireless in-ear earbuds designed for immersive audio and clear communication. They feature a durable metal charging case and intuitive touch controls.



Image: IMIKI BUDS PRO MT2 True Wireless Earbuds in their open charging case, showcasing the sleek black design.

Components

- Left Earbud
- Right Earbud
- Charging Case (Metal)
- USB-C Charging Cable

Touch Controls

The earbuds feature intuitive touch controls for managing music playback, calls, and voice assistant activation. Specific touch gestures will be detailed in the Operating Instructions section.



Image: Close-up view of an IMIKI MT2 earbud, highlighting its internal electronic components and sleek design.

SETUP

1. Charging the Earbuds and Case

1. Place both earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a power source.
3. The charging case indicators will show the charging status. A full charge for the case and earbuds takes approximately 2 hours.
4. Once fully charged, disconnect the charging cable.



Image: The IMIKI BUDS PRO MT2 charging case with earbuds securely placed inside, ready for charging or storage.

2. Bluetooth Pairing

1. **Initial Pairing:** Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select '**IMIKI BUDS PRO MT2**' from the list.
4. Once connected, the earbuds will indicate successful pairing (e.g., a voice prompt or solid LED light).
5. **Automatic Reconnection:** After initial pairing, the earbuds will automatically connect to the last paired device when removed from the charging case and Bluetooth is enabled on your device.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

Music Playback

Action	Gesture
Play/Pause	Single tap on either earbud
Next Track	Double tap on the Right earbud
Previous Track	Double tap on the Left earbud

Call Management

Action	Gesture
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold on either earbud for 2 seconds

Voice Assistant

- **Activate Voice Assistant:** Triple tap on either earbud.



Image: Exploded view of an earbud illustrating its audio components and a graphic representing dual microphone noise cancellation for clear calls.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use liquids or abrasive cleaners.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place.
- **Water Resistance:** The earbuds are IPX4 water-resistant, meaning they are protected against splashing water from any direction. They are not designed for swimming or submersion. Ensure they are dry before placing them back in the charging case.

TROUBLESHOOTING

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off Bluetooth on your device and turn it back on. Forget "IMIKI BUDS PRO MT2" from your device's Bluetooth list and re-pair. Place earbuds back in the case, close the lid, wait a few seconds, then open to re-enter pairing mode.
No sound from one earbud	Ensure both earbuds are charged. Try placing both earbuds back in the case and taking them out again. Reset the earbuds (refer to specific reset instructions if available, otherwise try re-pairing).
Charging case not charging	Check the USB-C cable and power adapter. Ensure the charging port is clean and free of debris. Try a different charging cable or power source.
Touch controls unresponsive	Ensure earbuds are clean and dry. Restart the earbuds by placing them in the case and taking them out.

SPECIFICATIONS

Feature	Detail
Model Name	IMIKI WIRELESS EARPHONES MT2 BLACK
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Ear Placement	In-Ear
Form Factor	In-Ear
Noise Isolation	Acoustic Isolation (Dual microphone noise cancellation for calls)
Control Method	Touch
Water Resistance Level	IPX4 (Splashproof)
Charging Time	Approximately 2 hours
Battery Life (Earbuds)	Up to 6 hours of playback
Total Battery Life (with Case)	Up to 14 hours
Compatible Devices	Mobile phones, televisions, laptops, smart speakers
Material	Metal (Charging Case)

Audio



Audio Stereo immersivo per un ascolto coinvolgente in ogni situazione

Cancellazione del rumore a doppio microfono per chiamate sempre chiare e senza interruzioni

Image: Graphic illustrating the 300mAh battery capacity of the charging case and the efficient transmission provided by Bluetooth 5.3 technology.

WARRANTY AND SUPPORT

IMIKI products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the documentation included with your purchase or contact IMIKI customer service through their official website. Please note that availability of spare parts and software updates information is not available at this time.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question