

[manuals.plus](#) /› [mooas](#) /› [mooas Visual Shower Clock Digital Bathroom Timer - Model 102590 User Manual](#)**mooas 102590**

mooas Visual Shower Clock Digital Bathroom Timer

Model: 102590

Brand: mooas

1. INTRODUCTION

The mooas Visual Shower Clock is a multi-functional digital device designed for use in various environments, including kitchens and bathrooms. It features a clock, timer, and displays both temperature and humidity. Its waterproof design (IPX5) ensures safe operation in wet conditions. The large, clear LCD screen provides excellent visibility, and the intuitive touch buttons allow for easy operation. This manual provides detailed instructions for setup, operation, and maintenance of your device.

2. PACKAGE CONTENTS

- Main body (mooas Visual Shower Clock)
- Wall mount hook
- User Manual

3. PRODUCT FEATURES

- Multi-functional device: Timer, Clock, Temperature, and Humidity display.
- Large and clear LCD screen for optimal readability.
- Visual Timer Ring to intuitively show time progression.
- Fast and simple timer setting with dedicated 10min, 1min, and 10sec buttons.
- Backlight display for visibility in low-light conditions.
- Multiple placement options: Standing, Wall mount, and Magnet attachment.
- Silent Mode for use in quiet environments.
- 3-Level Alarm Volume Control (Silent/Minimum/Maximum).
- IPX5 waterproof rating for safe use in kitchen and bathroom.

4. SETUP

4.1 Battery Installation

1. Locate the battery compartment on the back of the device.
2. Open the battery cover.

3. Insert 2 AAA batteries (not included), ensuring correct polarity (+/-).
4. Close the battery cover securely.

Note: Ensure the battery compartment is sealed properly to maintain the device's waterproof integrity.



Figure 1: Battery Installation

4.2 Initial Settings (Time, Date, Temperature Unit)

Upon first power-on or after battery replacement, you may need to set the time, date, and preferred temperature unit.

- **Setting Time and Date:** Press and hold the '10min' button to enter time setting mode. Use the '1min' and '10sec' buttons to adjust the values. Press 'ST/SP' to confirm and move to the next setting (e.g., hour, minute, year, month, day).
- **Setting Temperature Unit:** The device displays temperature in Celsius (°C) or Fahrenheit (°F). To switch between units, press and hold the '1min' and '10sec' buttons simultaneously until the unit changes.



Figure 2: Display Overview (Time, Date, Humidity, Temperature)

5. OPERATING INSTRUCTIONS

5.1 Timer Function

The device features a countdown timer with a visual ring indicator.

1. **Setting the Timer:** Use the '10min', '1min', and '10sec' buttons to add time to the timer. Each press adds the corresponding duration.

2. **Starting/Pausing the Timer:** Press the 'ST/SP' button to start the countdown. Press it again to pause the timer.
3. **Resetting the Timer:** While the timer is paused or stopped, press and hold the 'ST/SP' button to reset the timer to zero.
4. **Count-up Function:** If the timer is started from 00:00, it will function as a count-up timer.



Figure 3: Timer Control Buttons

5.2 Alarm Volume Control

Adjust the alarm volume to suit your environment.

- The device offers three alarm volume levels: Silent, Minimum, and Maximum.
- To change the volume, locate the volume control button on the side of the device. Press it repeatedly to cycle through the volume options.



Figure 4: Volume Control

5.3 Backlight

The backlight activates automatically with any button press, providing temporary illumination for the display.



Figure 5: Backlight in Use

6. MOUNTING OPTIONS

The mooas Visual Shower Clock offers versatile mounting options to suit various locations:

- **Standing:** Use the integrated kickstand for tabletop placement.
- **Wall Mount:** Utilize the wall mount hole on the back of the device with the provided wall mount hook.
- **Magnet:** The strong magnet on the back allows attachment to metallic surfaces like refrigerators or metal shower caddies.



Figure 6: Mounting Options (Stand, Wall Mount, Magnet)

7. MAINTENANCE

- **Cleaning:** Wipe the device with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the low battery indicator appears on the display. Ensure the battery compartment is sealed tightly after replacement.
- **Storage:** If storing the device for an extended period, remove the batteries to prevent leakage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Display is blank or dim.	Low batteries or incorrect battery installation.	Replace batteries with new AAA batteries, ensuring correct polarity.
Timer buttons are unresponsive.	Water droplets on the touch buttons.	Wipe the screen and buttons dry. Ensure hands are dry when operating.
Incorrect time/date displayed.	Time/date not set or reset after battery change.	Refer to Section 4.2 to set the correct time and date.
Alarm sound is too low or off.	Volume setting is on Minimum or Silent.	Adjust the alarm volume using the side button (refer to Section 5.2).

9. SPECIFICATIONS

Feature	Detail
Material	Acrylonitrile Butadiene Styrene (ABS)
Weight	220 Grams (approx. 7.8 ounces)
Product Dimensions	4.92"W x 0.94"H (approx. 3.94 x 0.94 x 4.92 inches W x D x H)
Power Source	2 AAA batteries (not included)
Display Type	Digital LCD with Backlight
Waterproof Rating	IPX5
Operating Temperature	32-104°F (0-40°C)
Storage Temperature	15.8°F-122°F (-9-50°C)
Mounting Type	Tabletop, Wall Mount, Magnet

10. PRODUCT VIDEO

Your browser does not support the video tag.

Video: mooas Visual Timer Clock. This official product video demonstrates the features and usage of the mooas Visual Shower Clock, including its timer function, display, and various applications in different environments.

11. WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact mooas customer support. If you encounter any issues or have questions not addressed in this manual, please reach out to our customer service team for assistance.

For further support, visit the official mooas website or contact your retailer.