Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

N newline NP2

N newline Bluetooth Speakerphone NP2 User Manual

Comprehensive instructions for setting up, operating, and maintaining your N newline Bluetooth Speakerphone NP2.

1. Product Overview

The N newline Bluetooth Speakerphone NP2 is designed for high-quality audio conferencing and media playback, offering 360° voice pickup and advanced AI noise reduction. Its compact and portable design makes it suitable for various environments, from professional meetings to personal leisure.



Figure 1: N newline Bluetooth Speakerphone NP2 and included USB-C cable.

- **360° Voice Pickup:** Captures voices clearly from all directions within a 5-meter (16-foot) range.
- **Pro AI Noise Reduction:** Minimizes background noise for clear communication.
- **High-Efficiency Full-Range Speaker:** Delivers HiFi-level audio for calls and music.
- **Dual Connectivity:** Supports both Bluetooth 5.1 and USB-C connections.
- **Extended Battery Life:** Up to 12 hours of continuous use for calls or music playback.



Figure 2: Battery life indication for the NP2 speakerphone.

2. Setup

2.1 Initial Charging

Before first use, fully charge the speakerphone using the provided USB-C cable. Connect the USB-C end to the speakerphone and the USB-A end to a compatible power adapter (not included) or a computer USB port. The charging indicator light will show charging status.

2.2 Connecting via Bluetooth

1. Press and hold the Power button () on the speakerphone until the Bluetooth indicator light begins to flash, indicating pairing mode.
2. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
3. Select "NP2" from the list of available devices.
4. Once connected, the Bluetooth indicator light will become solid.

2.3 Connecting via USB-C

For a wired connection, simply connect the speakerphone to your computer using the provided USB-C cable. The device will be automatically recognized as an audio input and output device. No additional drivers are typically required.



Figure 3: Dual connectivity options for the NP2 speakerphone.

3. Operating Instructions

3.1 Controls and Functions

The NP2 speakerphone features intuitive buttons for easy control of calls and audio playback.



Figure 4: Multi-function buttons on the NP2 speakerphone.

Table 1: Button Functions

Button Icon	Function	Description
	Call Answer/Hang Up	Press to answer an incoming call; press again to end a call.
-	Volume Down	Decreases the speaker volume.
	Microphone Mute	Toggles microphone mute on/off.
+	Volume Up	Increases the speaker volume.
	Power Switch	Press and hold to power on/off; short press for battery status (if applicable).
	Bluetooth	Activates Bluetooth pairing mode.

3.2 Voice Pickup and Noise Reduction

The NP2 features a 360° microphone array and Pro AI Noise Reduction technology to ensure clear voice capture and minimize background distractions during calls. For optimal performance, position the speakerphone centrally within the meeting area.



Figure 5: Illustration of Pro AI Noise Reduction in action.

3.3 Audio Output

Equipped with a 3W high-efficiency full-range speaker, the NP2 delivers clear and rich audio for both voice and music. This ensures that all participants can hear clearly during conferences and that music playback is enjoyable.



Figure 6: High-efficiency full-range speaker for superior audio.

4. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the speakerphone. Do not use liquid cleaners or aerosols.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Avoid Water:** The device is not waterproof. Keep it away from liquids to prevent damage.

5. Troubleshooting

Table 2: Common Issues and Solutions

Problem	Possible Cause	Solution
Device does not power on.	Low battery or no charge.	Charge the speakerphone using the provided USB-C cable. Ensure the power source is active.
Cannot connect via Bluetooth.	Speakerphone not in pairing mode; device Bluetooth off; interference.	Ensure speakerphone is in pairing mode (flashing Bluetooth light). Turn Bluetooth off and on on your device. Move closer to the speakerphone.
Poor microphone quality (others cannot hear me well).	Incorrect microphone placement; software settings; environmental noise.	Ensure the speakerphone is placed centrally and not obstructed. Elevate the speakerphone to ear level if possible, as microphones may be angled. Check microphone input settings on your computer/device. Utilize the AI Noise Reduction feature.
Low speaker volume.	Volume set too low on speakerphone or connected device.	Increase volume using the '+' button on the speakerphone and on your connected device.
No audio when connected via USB.	Incorrect audio output device selected on computer.	Check your computer's sound settings and ensure the NP2 is selected as the default output device. Try a different USB port.

6. Specifications

Table 3: Product Specifications

Feature	Detail
Model Name	NP2
Mounting Type	Tabletop Mount
Speaker Type	Multimedia
Compatible Devices	Desktop, Laptop, Smartphone, Tablet, Television
Controller Type	Button
Surround Sound Channel Configuration	2.0
Battery Life	12 Hours
Included Components	USB-C cable
Item Weight	10.4 ounces
Is Waterproof	FALSE
Maximum Voice Pickup Range	16 Feet (5 meters)
Wireless Communication Technology	Bluetooth 5.1

Feature	Detail
Power Source	Battery Powered
Speaker Maximum Output Power	3 Watts
Frequency Response	20 KHz
Audio Output Mode	Stereo

7. Warranty and Support

The N newline Bluetooth Speakerphone NP2 comes with a**Limited Warranty**. Please refer to the warranty card included in your product packaging for specific terms and conditions, including coverage duration and limitations.

For technical support, troubleshooting assistance, or warranty claims, please contact N newline customer service through their official website or the contact information provided in your product documentation. When contacting support, please have your product model number (NP2) and purchase details ready.

For more information, visit the official N newline store:N newline Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CW336QWG

More documents and user manuals: **https://manuals.plus/**