

Monster Boomerang Petite

Monster Boomerang Petite Neckband Bluetooth Speakers User Manual

Model: Boomerang Petite (M156)

INTRODUCTION

Thank you for choosing the Monster Boomerang Petite Neckband Bluetooth Speakers. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read it thoroughly before use to ensure optimal performance and longevity.

The Monster Boomerang Petite is designed for a comfortable, wearable audio experience, featuring aptX High Fidelity 3D Stereo Sound, up to 15 hours of playtime, and IPX5 water resistance. Its ergonomic design allows for hands-free calls and maintains environmental awareness.



Image: The Monster Boomerang Petite Neckband Bluetooth Speakers, showcasing its ergonomic design.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Monster Boomerang Petite Neck Speaker
- 1 x Type-C USB Charging Cable
- 1 x Quick Start Guide

PRODUCT OVERVIEW

Familiarize yourself with the physical components and controls of your Monster Boomerang Petite.

360 SOUND PERSONALIZER

Surround in sound and vibration with deep bass tones



Image: Close-up view of the control buttons on the left side of the neckband, including power, volume, and multi-

function buttons.

Controls and Indicators

- **Power Button:** Press and hold to power on/off.
- **Volume Up (+):** Increase volume.
- **Volume Down (-):** Decrease volume.
- **Multi-function Button (MFB):** Play/Pause, Answer/End calls, Activate voice assistant.
- **LED Indicator:** Displays power, charging, and Bluetooth status.

Ports



Image: The USB-C charging port located on the underside of the neckband.

- **USB-C Charging Port:** For connecting the charging cable.

SETUP

Charging the Device

1. Connect the provided USB-C charging cable to the charging port on the neck speaker.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. A full charge typically takes approximately 2 hours.
4. Once fully charged, the device provides up to 15 hours of playtime.

Power On/Off

- **To Power On:** Press and hold the Power button for 3 seconds. The LED indicator will flash.
- **To Power Off:** Press and hold the Power button for 3 seconds. The LED indicator will turn off.

Bluetooth Pairing

To connect your Monster Boomerang Petite to a Bluetooth-enabled device:

1. Ensure the neck speaker is powered off.
2. Press and hold the Power button for 5 seconds until the LED indicator flashes rapidly (usually blue and red), indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Monster Boomerang Petite" from the list of found devices.
5. Once connected, the LED indicator will stop flashing and remain solid blue.
6. The speaker will automatically reconnect to the last paired device when powered on, if within range.

OPERATING INSTRUCTIONS

Audio Playback

- **Play/Pause:** Press the Multi-function Button (MFB) once.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.

Volume Control

- **Increase Volume:** Press the Volume Up (+) button.
- **Decrease Volume:** Press the Volume Down (-) button.

Call Management

HANDS & EARS FREE CALL

A new way to get rid of the wire connection



Image: A man wearing the neck speaker while engaged in a hands-free video call on a laptop.

- **Answer/End Call:** Press the MFB once during an incoming call or an active call.
- **Reject Call:** Press and hold the MFB for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Double-press the MFB.

Special Features

- **3D Stereo Sound:** Experience immersive audio with enhanced depth and clarity.
- **Directional Sound:** The speakers are designed to direct sound towards your ears, minimizing disturbance to others while maintaining personal audio.
- **Environmental Awareness:** The open-ear design allows you to hear your audio while remaining aware of your surroundings, which is beneficial for outdoor activities or in shared spaces.



Image: A cyclist wearing the neck speaker, looking over their shoulder at a car, illustrating the ability to hear surroundings.

MAINTENANCE

Proper care ensures the longevity and performance of your Monster Boomerang Petite.

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The device is IPX5 waterproof, meaning it is protected against low-pressure water jets from any direction. It is resistant to sweat and light rain. Do not submerge the device in water or expose it to strong water streams. Ensure the charging port cover is securely closed when not charging to maintain water resistance.

IPX5 WATERPROOF

Full protection against sweat, water, and rain



Image: The neck speaker being splashed with water, demonstrating its IPX5 water resistance.

- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the device fully before long periods of inactivity and recharge it at least once every three months.

TROUBLESHOOTING

If you encounter issues with your Monster Boomerang Petite, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on	Low battery; Device is off	Charge the device fully; Press and hold the Power button for 3 seconds.

Problem	Possible Cause	Solution
Cannot pair with Bluetooth device	Device not in pairing mode; Bluetooth is off on source device; Out of range	Ensure device is in pairing mode (flashing LED); Enable Bluetooth on your device; Move devices closer (within 10 meters).
No sound or low sound	Volume too low; Device not connected; Audio source issue	Increase volume on both the neck speaker and your connected device; Re-pair the device; Check audio output settings on your source device.
Poor microphone quality during calls	Improper positioning; Environmental noise; Software issue	Ensure the neck speaker is positioned correctly around your neck; Move to a quieter environment; Check your connected device's call settings.
Intermittent connection	Interference; Out of range; Low battery	Avoid obstacles between devices; Stay within 10 meters; Charge the device.

SPECIFICATIONS

Feature	Detail
Model Name	M156
Material	Plastic
Speaker Type	Subwoofer
Connectivity Technology	Bluetooth 5.0
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters
Speaker Maximum Output Power	3 Watts
Audio Output Mode	Surround
Special Features	Bass Boost, Hi-Res Audio, Waterproof (IPX5), Built-in Microphone, aptX High Fidelity 3D Stereo Sound, Private Theater, Low Latency, Ergonomic design, 15H Long Playtime, Directional Sound, Powerful Bass, Type-C Fast Charging, Lightweight and Portable, Crystal Handsfree Call

Feature	Detail
Power Source	Battery Powered (1 Lithium Ion battery included)
Item Weight	0.2 Kilograms (7 ounces)
Product Dimensions	4"D x 12"W x 9"H
Control Method	Touch


WARRANTY AND SUPPORT

The Monster Boomerang Petite Neckband Bluetooth Speakers come with a Limited Warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty information provided in your product packaging or contact Monster customer support.

For technical assistance, troubleshooting beyond this manual, or warranty claims, please visit the official Monster website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty services.

© 2024 Monster. All rights reserved.

Related Documents - Boomerang Petite

	<p>Monster Boomerang MS31901 Portable Speaker Quick Start Guide</p> <p>Get started with your Monster Boomerang MS31901 portable speaker. This guide covers setup, Bluetooth pairing, controls, battery information, and LED indicator status.</p>
	<p>Monster Airmars SG01 ENC Gaming Neckband Wireless Headphones - User Manual & Specifications</p> <p>Official user manual and specifications for the Monster Airmars SG01 ENC Gaming Neckband Wireless Headphones. Learn about features, operation, troubleshooting, and warranty.</p>
	<p>Monster Stinger Gaming Wearable Speaker MS32105 - Quick Start Guide</p> <p>Comprehensive guide for the Monster Stinger Gaming Wearable Speaker (Model MS32105). Learn about product overview, charging, power controls, Bluetooth pairing, volume adjustments, music playback, call handling, light modes, sound effects, power saving, and troubleshooting.</p>

	<p>Monster DNA ONE Wireless Speaker User Manual and Specifications</p> <p>Comprehensive user manual for the Monster DNA ONE wireless speaker, detailing setup, operation, features like Monster Share™ Party Mode, safety guidelines, and technical specifications. Includes FCC and IC compliance information.</p>
	<p>Monster DNA MAX Portable Bluetooth Speaker: User Manual, Features, and Specs</p> <p>Comprehensive guide for the Monster DNA MAX portable Bluetooth speaker. Learn about speaker functions, pairing, Monster Share™ Party Mode, charging, product specifications, safety, and warranty.</p>
	<p>Monster Blaster Micro MS62106 Wearable Bluetooth Speaker Quick Start Guide</p> <p>Quick start guide for the Monster Blaster Micro MS62106 wearable Bluetooth speaker, covering product overview, button functions, LED indicators, charging, Bluetooth connection, music control, call mode, stereo pairing, and device reset.</p>