Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LG BD590

LG BD590 Blu-ray Disc Player User Manual

Model: BD590

1. Introduction and Overview

This manual provides essential information for the safe and efficient operation of your LG BD590 Blu-ray Disc Player. The LG BD590 is a versatile home entertainment device featuring Blu-ray and DVD disc playback, integrated Wi-Fi connectivity, a 250GB hard drive for media storage, and superior audio performance.
Key features include:

- Blu-ray and DVD Disc Playback
- Integrated Wi-Fi Connectivity for network access
- USB 2.0 Media Host for external storage
- 250GB Hard Drive for Media Library
- NetCast for YouTube & CinemaNow
- Full HD 1080p output via HDMI with Cinema mode
- Superior audio performance with Dolby Digital 7.1 analog output, TrueHD & dts-HD
- Quick boot with instant tray opening

2. Setup Guide

2.1 Unpacking and Component Check

Carefully remove all components from the packaging. Ensure the following items are present:

- LG BD590 Blu-ray Disc Player unit
- Remote Control
- Power Cord
- Audio/Video Cables (RCA type, if included)
- Owner's Manual (this document)



Figure 2.1: LG BD590 Blu-ray player and included accessories.

2.2 Connecting to Your Television

1. **HDMI Connection (Recommended):** Connect one end of an HDMI cable (not included) to the HDMI OUT port on the rear of the BD590 player and the other end to an HDMI IN port on your television. Note the HDMI input number on your TV.
2. **Analog Connection (Optional):** If your TV does not have an HDMI port, connect the RCA audio/video cables

(red, white, yellow) from the BD590's AV OUT ports to the corresponding AV IN ports on your television.

2.3 Power Connection

Connect the power cord to the AC IN port on the rear of the BD590 player, then plug the other end into a wall outlet.

2.4 Remote Control Setup

Insert two AAA batteries (not included) into the remote control, ensuring correct polarity (+/-). The remote control allows you to operate all functions of the Blu-ray player.



Figure 2.2: LG BD590 Remote Controls.

2.5 Network Connection (Wi-Fi)

The BD590 features integrated Wi-Fi. After powering on the unit, navigate to the network settings menu on your TV screen to connect to your home wireless network. Follow the on-screen prompts to select your network and enter the password.

3. Operating Instructions

3.1 Basic Disc Playback

1. Turn on your TV and select the correct HDMI input (or AV input) that the BD590 is connected to.
2. Press the **POWER** button on the player or remote control to turn on the BD590.
3. Press the **OPEN/CLOSE** button (▲) on the player or remote to open the disc tray.
4. Place a Blu-ray disc or DVD onto the disc tray with the label side facing up.
5. Press the **OPEN/CLOSE** button (▲) again to close the disc tray. The player will automatically begin reading

the disc.

6. Use the remote control's navigation buttons (**UP, DOWN, LEFT, RIGHT**) and **ENTER** button to select menu options on the disc.
7. Use the **PLAY** (►), **PAUSE** (||), **STOP** (■), **FAST FORWARD** (►►), and **REWIND** (◄◄) buttons for playback control.

3.2 Using the USB Media Host

You can play media files (photos, music, videos) stored on a USB flash drive or external hard drive through the BD590.

1. Insert your USB device into the USB 2.0 port on the front of the player.
2. The player should automatically detect the device and display a media browser. If not, press the **HOME** button on the remote and navigate to the USB media option.
3. Browse and select the desired media file using the navigation buttons and **ENTER**.

3.3 Network Features (NetCast)

With an active internet connection, you can access various online content services via NetCast.

1. Press the **HOME** button on the remote control.
2. Navigate to the NetCast menu option.
3. Select desired applications such as YouTube or CinemaNow and follow the on-screen instructions to access content.

4. Maintenance

4.1 Cleaning the Unit

To maintain the appearance and performance of your player:

- Wipe the exterior with a soft, dry cloth. Do not use liquid or aerosol cleaners.
- Never insert anything into the disc tray other than a disc.
- Keep the ventilation openings clear to prevent overheating.

4.2 Disc Care

Handle discs by their edges to avoid fingerprints. Store discs in their cases when not in use to prevent scratches and dust accumulation.

5. Troubleshooting

If you encounter issues with your LG BD590, refer to the following common solutions:

Problem	Possible Solution
No power	Ensure the power cord is securely connected to the player and a working electrical outlet.
No picture/sound	Check HDMI or AV cable connections. Ensure your TV is set to the correct input source.
Disc not playing	Verify the disc is clean and free of scratches. Ensure it is inserted correctly (label side up). Try a different disc.

Problem	Possible Solution
Cannot connect to Wi-Fi	Check your router and internet connection. Re-enter your Wi-Fi password in the network settings. Ensure the player is within range of your Wi-Fi signal.
Remote control not working	Check and replace batteries if necessary. Ensure there are no obstructions between the remote and the player.

For further assistance, please refer to the official LG support website or contact customer service.

6. Specifications

Feature	Detail
Brand	LG
Model	BD590
Media Type	Blu-Ray Disc, DVD
Special Feature	Wireless (Wi-Fi)
Resolution	1920x1080 (Full HD)
Connector Type	HDMI
Connectivity Technology	HDMI, Wi-Fi
Color	Black
Item Weight	4.4 Pounds
Audio Output Mode	Stereo, Dolby Digital 7.1, TrueHD, dts-HD
Built-In Media	Blu-ray (250GB Hard Drive)
Analog Video Format	NTSC
UPC	786513707284
ASIN	B0CW3QCP5T

7. Warranty and Support

7.1 Warranty Information

This LG BD590 Blu-ray Disc Player comes with a**90 days limited warranty**. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty card included with your product or visit the official LG website.

7.2 Customer Support

For technical support, service, or additional product information, please visit the official LG Electronics support website at www.lg.com/us/support or contact their customer service line. You may need your model number (BD590) and serial number when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CW3QCP5T

More documents and user manuals: **https://manuals.plus/**