

[Manuals.plus](#) /

› [GIANTEX](#) /

› GIANTEX 34-Inch Outdoor Dining Table Instruction Manual

GIANTEX GX11214GR-22-PN

GIANTEX 34-Inch Outdoor Dining Table Instruction Manual

Model: GX11214GR-22-PN

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your GIANTEX 34-inch Square Tempered Glass Outdoor Dining Table. Please read this manual thoroughly before assembly and use to ensure safe and correct operation of the product. Keep this manual for future reference.

SAFETY INFORMATION

WARNING:

- Always use an umbrella with a proper base to prevent tipping. An extra umbrella base is needed if you choose to use a patio umbrella (umbrella not included).
- Always follow the assembly instructions for safe setup.
- Do not exceed the maximum weight capacity of 110 lbs (50 kg).
- Keep children away from the assembly area.
- Ensure all bolts and screws are securely tightened before use.
- Do not stand or sit on the table.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- 1 x GIANTEX 34-Inch Outdoor Dining Table
- 1 x Instruction Manual
- All necessary hardware for assembly

SETUP AND ASSEMBLY

The GIANTEX 34-inch Outdoor Dining Table is designed for quick and effortless setup. An easy-to-follow instruction guide and all necessary hardware are included. A screwdriver is recommended for assembly.

1. Unpack all components and verify against the package contents list.
2. Place the tempered glass tabletop carefully on a soft, clean surface to prevent scratches.
3. Attach the metal frame components according to the included assembly guide. Ensure all connections are aligned correctly.
4. Secure all bolts and screws firmly. Do not overtighten.
5. Carefully turn the assembled table upright.
6. Verify the stability of the table before use.



Image: Detail of the table's heavy-duty metal frame and curved legs, designed for stability.

OPERATING INSTRUCTIONS

Your GIANTEX outdoor dining table is designed for outdoor use, suitable for patios, balconies, porches, and gardens. It comfortably seats up to 4 people.

Umbrella Usage

The table features a 1.5-inch diameter umbrella hole in the center, perfect for most standard patio umbrellas. An additional fixing hole is provided to help secure the umbrella in place.

Important Note:

- An umbrella is not included with this table.
- If you choose to use a patio umbrella, an extra umbrella base is required to ensure stability and prevent tipping.



Image: Detail showing the 1.5-inch umbrella hole, tempered glass tabletop, and additional fixing hole for an umbrella.

MAINTENANCE

To ensure the longevity and appearance of your GIANTEX outdoor dining table, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the table surfaces with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- **Frame Care:** The metal frame is rustproof and powder-coated. Inspect regularly for any signs of wear or damage.

- **Glass Care:** The tempered glass tabletop is durable. Avoid using abrasive cleaners or sharp objects that could scratch the surface.
- **Winter Storage:** During harsh weather conditions or off-season, it is recommended to cover the table or store it indoors to protect it from extreme elements.

TROUBLESHOOTING

If you encounter any issues with your GIANTEX outdoor dining table, refer to the following common solutions:

- **Table Wobbles:**
 - Ensure all assembly bolts and screws are securely tightened.
 - Check if the table is placed on an even surface.
- **Difficulty Assembling:**
 - Review the included instruction manual carefully.
 - Ensure all parts are correctly oriented before tightening screws.
 - Do not force components together.
- **Scratches on Glass:**
 - Tempered glass is scratch-resistant but not scratch-proof. Avoid dragging rough objects across the surface.
 - Use placemats or coasters to protect the surface during use.

For issues not covered here, please contact GIANTEX customer support.

SPECIFICATIONS

Product Specifications

Brand	GIANTEX
Model Number	GX11214GR-22-PN
Overall Dimensions (L x W x H)	34" x 34" x 27.5" (86.4 cm x 86.4 cm x 69.8 cm)
Tabletop Material	Tempered Glass
Frame Material	Rustproof Metal (Powder Coated Black)
Umbrella Hole Diameter	1.5" (3.8 cm)
Weight Capacity	110 lbs (50 kg)
Net Weight	28.5 lbs (12.9 kg)
Seating Capacity	4 people
Indoor/Outdoor Usage	Outdoor



Note: If you choose to use an additional patio umbrella, an extra umbrella base is needed

Image: Product dimensions and weight capacity overview.

WARRANTY INFORMATION

GIANTEX products are manufactured to high-quality standards. For specific warranty details, including coverage and duration, please refer to the warranty card included with your product or visit the official GIANTEX website. Please retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact GIANTEX customer service. Contact information can typically be found on the product packaging, the official GIANTEX website, or through your retailer.

For the most up-to-date support information, please visit: [GIANTEX Official Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question