

[Manuals.plus](#) /

› [DORTALA](#) /

› DORTALA 9-Piece Patio Dining Set Instruction Manual (Model DO-HW71816+-CA)

DORTALA DO-HW71816+-CA

DORTALA 9-Piece Patio Dining Set Instruction Manual

Model: DO-HW71816+-CA

1. INTRODUCTION

Thank you for choosing the DORTALA 9-Piece Patio Dining Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor furniture. Please read these instructions carefully before assembly and retain them for future reference.

This set includes one dining table and eight chairs, designed for outdoor use in various settings such as patios, gardens, backyards, and poolside areas. It features a robust construction of acacia wood and weather-resistant rattan, complemented by comfortable cushions.



Image 1: The DORTALA 9-Piece Patio Dining Set arranged in a backyard, showcasing its appearance in an outdoor environment.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- To prevent tip-over, secure all chairs to the table when not in use.
- Always assemble and disassemble the furniture with care, following the provided instructions.
- Keep the area around the furniture clear of debris and other obstacles during assembly and use.
- For your safety, do not sit on the tabletop.
- Keep children and pets away from the furniture when it is not in use or being assembled/disassembled.
- Ensure all bolts and screws are tightened securely before use. Periodically check and re-tighten as necessary.
- Do not exceed the weight capacity: Table: 360 lbs, Each Chair: 400 lbs.

3. PRODUCT OVERVIEW

The DORTALA 9-Piece Patio Dining Set is designed for durability and comfort in outdoor environments. Key components and features include:

- **Sturdy Acacia Wood:** The tabletop and chair armrests are constructed from solid acacia wood, known for its durability and natural resistance to outdoor elements.
- **Weather-Resistant Rattan:** The chairs and table frame feature a mix grey PE rattan weave, offering sun-protective, non-fading, and breathable qualities.
- **Comfortable Cushions:** Eight high-density, sponge-padded, waterproof cushions are included. These cushions have removable polyester covers for easy cleaning.
- **Adjustable Stability:** Non-slip foot pads on the chairs and table can be adjusted to prevent wobbling on uneven surfaces.
- **Umbrella Compatibility:** The dining table includes a 1.96-inch umbrella hole, compatible with most standard patio umbrellas (umbrella and base not included).



Image 2: Fully assembled DORTALA 9-Piece Patio Dining Set. This image shows the grey rattan chairs with light cushions and the acacia wood tabletop.



High Quality Acacia Wood

The tabletop and armrests are made of acacia wood for durability



High Hardness



Natural Appeal



Crack-resistance



Image 3: Close-up view highlighting the high-quality acacia wood used for the tabletop and armrests, emphasizing its durability, natural appeal, and crack resistance.

Mix Grey PE Rattan



Sun-protective



Non-fading



Breathable



Elegant




Image 4: Detail of the mix grey PE rattan material, illustrating its sun-protective, non-fading, breathable, and elegant characteristics.

Removable Thick Padded Cushion



Image 5: Illustration of the removable thick padded cushions, showing the soft sponge filling and the washable zippered cover for easy maintenance.

4. SETUP AND ASSEMBLY

Assembly of the DORTALA 9-Piece Patio Dining Set requires careful attention to detail. It is recommended that at least two adults participate in the assembly process to ensure safety and efficiency.

4.1. Unpacking and Component Check

1. Carefully unpack all components from the packaging. The set may arrive in multiple boxes (e.g., 4 boxes).
2. Verify that all parts listed in the included instruction manual are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately.
3. Lay out all components on a soft, clean surface to prevent scratches during assembly.

4.2. Assembly Steps

Refer to the detailed instruction manual included in your package for step-by-step assembly diagrams and instructions. General guidelines include:

- Begin by assembling the dining table frame, ensuring all connections are secure but not fully tightened until all parts are aligned.
- Attach the acacia wood tabletop panels to the table frame.
- Proceed to assemble each chair individually. Pay close attention to the orientation of chair legs and armrests.
- When attaching components, ensure screws are correctly matched to their designated holes. Note that there may be screws of slightly different lengths; using the wrong screw can cause damage.
- Once all components are loosely assembled, gradually tighten all screws and bolts. Avoid over-tightening to prevent stripping.
- Install the adjustable non-slip foot pads on the table and chairs.
- Place the cushions on the chairs.

Compatible with Most Patio Umbrellas(not included)



Image 6: The dining set positioned outdoors, showcasing the integrated umbrella hole in the center of the table. This image illustrates the set's compatibility with a patio umbrella (not included).



Image 7: Diagram illustrating the dimensions of the dining table and a single chair, along with an indication that the product ships in multiple boxes. Table dimensions: 71" L x 35" W x 29" H. Chair dimensions: 23" L x 24" W x 35" H.

5. OPERATING INSTRUCTIONS

5.1. General Use

- Ensure the dining set is placed on a stable, level surface. Use the adjustable foot pads to stabilize the table and chairs if the ground is uneven.
- Distribute weight evenly across the table and chairs. Do not concentrate heavy loads on one small area.
- When moving the furniture, lift it rather than dragging it to prevent damage to the legs and frame.

5.2. Umbrella Use (Optional)

- If using a patio umbrella, insert the umbrella pole through the 1.96-inch hole in the center of the table.
- Always use a sturdy umbrella base (not included) to secure the umbrella, especially in windy conditions.
- Close and secure the umbrella when not in use or during strong winds to prevent damage to the umbrella, table, or surrounding property.

6. MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your DORTALA Patio Dining Set.

6.1. Cleaning

- **Frame and Tabletop:** Wipe with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The cushion covers are removable and washable. Follow the care instructions on the cushion labels. For general cleaning, spot clean with a mild soap and water solution. Allow to air dry completely before reattaching.

6.2. Protection and Storage

- To protect the acacia wood and rattan from prolonged exposure to harsh weather conditions (e.g., heavy rain, direct sunlight, snow), consider using outdoor furniture covers when the set is not in use.
- During off-seasons or extreme weather, store the cushions indoors in a dry place.
- Periodically check all bolts and screws and re-tighten them as needed to maintain structural integrity.
- Acacia wood may benefit from periodic oiling to maintain its luster and protect it from drying out. Consult a wood care specialist for appropriate products and methods.

7. TROUBLESHOOTING

If you encounter issues with your dining set, refer to the following common solutions:

- **Wobbling Table/Chairs:** Adjust the non-slip foot pads on the bottom of the legs until the furniture is stable. Ensure all assembly screws are securely tightened.
- **Difficulty Assembling:** Review the assembly instructions carefully. Ensure all parts are correctly oriented and that the correct screws are used for each step. Sometimes, loosening all screws slightly, aligning components, and then re-tightening can resolve alignment issues. Consider seeking assistance from another person.
- **Fading Rattan/Wood:** While the rattan is weather-resistant, prolonged exposure to intense UV rays can still cause some fading over many years. Using furniture covers when not in use can help mitigate this. Acacia wood can be re-stained or oiled to restore its color.

8. SPECIFICATIONS

Feature	Detail
Model Number	DO-HW71816+-CA
Color	Grey
Material	Rattan, Steel, Acacia Wood, Polyester, Sponge
Table Dimensions (L x W x H)	75" x 36" x 29" (190.5 cm x 91.4 cm x 73.7 cm)
Chair Dimensions (L x W x H)	24" x 23" x 35" (61 cm x 58.4 cm x 88.9 cm)
Cushion Dimensions (L x W x Thickness)	19" x 18" x 2" (48.3 cm x 45.7 cm x 5.1 cm)
Table Weight Capacity	360 lbs (163 kg)

Chair Weight Capacity (each)	400 lbs (181 kg)
Net Weight of Table	52 lbs (23.6 kg)
Net Weight of Each Chair	17.5 lbs (7.9 kg)
Product Care Instructions	Wipe with Damp Cloth, Wipesible

9. WARRANTY AND SUPPORT

DORTALA stands behind the quality of its products. For specific warranty information, please refer to the warranty card included with your purchase or visit the official DORTALA website. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact DORTALA customer support directly. Please have your model number (DO-HW71816+-CA) and purchase details ready when contacting support.

Visit the [DORTALA Store for more information](#)

© 2024 DORTALA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CW54HB3X>

More documents and user manuals: <https://manuals.plus/>