

TYLT SPKRBTL24BK-T

TYLT 24oz Stainless Steel Water Bottle with Bluetooth Speaker User Manual

Model: SPKRBTL24BK-T

INTRODUCTION

This manual provides comprehensive instructions for the TYLT 24oz Stainless Steel Water Bottle with Built-in Bluetooth Speaker. It covers product features, setup, operation, maintenance, and troubleshooting to ensure optimal use of your device. Please read this manual thoroughly before using the product.

PACKAGE CONTENTS

Verify that all items are present in your package:

- TYLT 24oz Stainless Steel Water Bottle
- Integrated Bluetooth Speaker (detachable)
- USB Charging Cable (Type-C, assumed)
- User Manual (this document)

PRODUCT FEATURES

- **2-in-1 Design:** Combines a 24oz stainless steel water bottle with a detachable Bluetooth speaker.
- **Extended Playback:** Up to 12 hours of continuous audio playback on a single charge.
- **Superior Insulation:** Double-walled stainless steel construction maintains beverage temperature for hours.
- **Portable & Durable:** Lightweight design (1.1 lbs) with a leak-proof lid, wide mouth opening, and robust construction.
- **Bluetooth Connectivity:** Quick and stable pairing with compatible devices for wireless audio streaming.

SETUP

1. Charging the Speaker

Before first use, fully charge the Bluetooth speaker. The speaker is located at the base of the water bottle and can be detached for charging.

1. Gently twist the speaker base counter-clockwise to detach it from the water bottle.
2. Locate the charging port on the speaker.
3. Connect the provided USB charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate. Once fully charged, the light will change or turn off (refer to specific LED behavior in the next section).
5. After charging, reattach the speaker by aligning it with the bottle base and twisting clockwise until secure.



Image: TYLT water bottle with its detachable speaker base shown separately. The speaker base is round and grey, while the bottle is black stainless steel.

2. Bluetooth Pairing

Follow these steps to connect the speaker to your Bluetooth-enabled device:

1. Ensure the speaker is charged and powered off.
2. Press and hold the Power button on the speaker for approximately 3-5 seconds until the LED indicator light flashes rapidly (usually blue), indicating pairing mode.
3. On your smartphone or other device, navigate to the Bluetooth settings.
4. Search for available devices. The speaker should appear as "TYLT Speaker" or similar.
5. Select the speaker from the list to initiate pairing.
6. Once successfully paired, the LED indicator light will typically turn solid blue or flash slowly, and you may hear an audible confirmation tone.
7. The speaker will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

1. Speaker Controls

The speaker features intuitive controls for audio playback and calls:

- **Power Button ():**
 - Press and hold for 3-5 seconds to power ON/OFF.
 - Short press to play/pause music.
 - Short press to answer/end a phone call.
 - Press and hold to reject an incoming call.
- **Volume Up Button (+):**
 - Short press to increase volume.
 - Press and hold to skip to the next track.
- **Volume Down Button (-):**
 - Short press to decrease volume.
 - Press and hold to go to the previous track.
- **LED Indicator:**
 - Flashing Blue: Pairing mode.
 - Solid Blue: Paired and connected.
 - Flashing Red: Low battery.
 - Solid Red (while charging): Charging.
 - Off (while charging): Fully charged.





Image: TYLT water bottle with the speaker base attached, displaying the power symbol and TYLT logo on the speaker grille.

2. Water Bottle Use

The 24oz stainless steel bottle is designed for hydration on the go:

- **Filling:** Unscrew the top lid to fill the bottle with your desired beverage. The wide mouth opening accommodates ice cubes easily.
- **Temperature Retention:** The double-wall insulation keeps drinks cold for extended periods or hot for several hours.
- **Leak-Proof Lid:** Ensure the lid is securely tightened to prevent leaks.
- **Carrying:** Use the integrated strap for convenient portability.

MAINTENANCE

1. Cleaning

- **Water Bottle:** Hand wash only. Do not place the stainless steel bottle in a dishwasher. Use warm, soapy water and a bottle brush for thorough cleaning. Rinse thoroughly.
- **Speaker:** The speaker is not waterproof. Detach the speaker from the bottle before cleaning. Wipe the speaker surface with a dry or slightly damp cloth. Do not submerge the speaker in water or expose it to excessive moisture.
- Ensure both components are completely dry before reassembling.

2. Storage

When not in use, store the water bottle and speaker in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the speaker is fully charged before long-term storage to preserve battery life.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low or no battery charge.	Charge the speaker fully using the provided USB cable.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode (flashing blue LED). Turn on Bluetooth on your device. Move device closer to speaker (within 10 meters). Forget previous pairings on your device and try again.
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume on both the speaker and your connected device. Ensure the speaker is successfully paired and connected.
Water bottle leaks.	Lid not securely tightened; seal damaged.	Ensure the lid is screwed on tightly and correctly. Check the silicone seal inside the lid for any damage or misalignment.

SPECIFICATIONS

- **Model Name:** SPKRBTL24BK-T
- **Capacity:** 24 Ounces (approx. 710 ml)
- **Material:** Stainless Steel (bottle)
- **Connectivity:** Bluetooth

- **Playback Time:** Up to 12 hours
- **Item Weight:** 1.1 Pounds (approx. 0.5 kg)
- **Product Dimensions:** 12 x 4 x 4 inches (approx. 30.5 x 10.2 x 10.2 cm)
- **Care Instructions:** Hand Wash Only (bottle)

SAFETY INFORMATION

- Do not immerse the Bluetooth speaker in water or any other liquids.
- Keep the speaker away from heat sources, direct sunlight, and open flames.
- Do not attempt to disassemble or repair the speaker yourself. This may void the warranty and cause damage.
- Use only the provided charging cable or a certified equivalent.
- Keep out of reach of children.
- The water bottle is designed for beverages; do not use it for corrosive liquids or chemicals.

WARRANTY AND SUPPORT

TYLT products are designed for quality and reliability. For warranty information or technical support, please refer to the official TYLT website or contact their customer service directly. Please retain your proof of purchase for warranty claims.

For further assistance, visit: www.tylt.com