

- Manuals.plus /
- › LITFAD /
 - › LITFAD LT1231135B Shoe Storage Cabinet User Manual

LITFAD LT1231135B

LITFAD LT1231135B Shoe Storage Cabinet User Manual

Model: LT1231135B

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your LITFAD LT1231135B Shoe Storage Cabinet. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.

PRODUCT OVERVIEW

The LITFAD LT1231135B is a freestanding shoe storage cabinet designed to organize footwear efficiently. It features multiple flip-down compartments for discreet storage and a compact design suitable for various living spaces.



Image 1: The LITFAD LT1231135B Shoe Storage Cabinet positioned in an entryway, demonstrating its compact design and white finish. It features three flip-down compartments and a small top surface.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (Manufactured Wood, White)
- Flip-Down Door Mechanisms
- Assembly Hardware Kit (screws, dowels, cam locks, etc.)
- Instruction Manual (this document)

SAFETY INFORMATION

- Keep small parts away from children during assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Ensure all fasteners are securely tightened before use.

- Do not overload the cabinet.
- For stability, consider anchoring the cabinet to a wall, especially if children are present. (Wall anchoring hardware may not be included).

SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent damage. Verify all components listed in the "Package Contents" section are present.
2. **Identify Panels:** Refer to the included diagram (if available) to identify each panel (side panels, top, bottom, back, door panels).
3. **Assemble Frame:** Attach the side panels to the bottom panel using the provided hardware (e.g., dowels and cam locks). Ensure connections are secure.
4. **Install Back Panel:** Slide or nail the back panel into place. This adds rigidity to the structure.
5. **Attach Top Panel:** Secure the top panel to the assembled frame.
6. **Install Flip-Down Mechanisms:** Attach the flip-down door mechanisms to the side panels and then to the door panels. Ensure they operate smoothly.
7. **Attach Doors:** Secure the door panels to the flip-down mechanisms. Test each door for smooth operation.
8. **Final Tightening:** Once fully assembled, gently tighten all screws and fasteners. Do not overtighten.
9. **Positioning:** Place the assembled cabinet in its desired location. Ensure it is on a level surface.




Image 2: Dimensional diagram of the LITFAD LT1231135B Shoe Storage Cabinet, indicating its height of 43 inches (110 cm), width of 12 inches (30 cm), and depth of 6.5 inches (17 cm).

OPERATING INSTRUCTIONS

The LITFAD LT1231135B Shoe Storage Cabinet is designed for simple operation.

- **Opening Doors:** To access a compartment, gently pull the top edge of the flip-down door outwards. The door will pivot downwards, revealing the shoe storage area.
- **Storing Shoes:** Place shoes into the compartments. The capacity depends on shoe size and style. For optimal organization, place shoes heel-to-toe.
- **Closing Doors:** Push the flip-down door upwards until it clicks securely into its closed position.
- **Top Surface:** The top surface can be used for light decorative items or small accessories. Do not place heavy

objects on the top surface.

MAINTENANCE AND CARE

Proper maintenance will ensure the longevity and appearance of your shoe cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the manufactured wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Environment:** Avoid placing the cabinet in direct sunlight or near heat sources, as this can cause discoloration or warping. Maintain a stable room temperature and humidity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Doors do not close properly.	Shoes are obstructing the door; hardware is loose or misaligned.	Ensure shoes are fully inside the compartment. Check and tighten door mechanism screws. Realign if necessary.
Cabinet feels wobbly.	Uneven floor; loose assembly hardware.	Move to a level surface or use shims under the base. Check and tighten all assembly screws. Consider wall anchoring.
Scratches or minor damage.	Accidental impact during assembly or use.	Use a furniture repair pen or touch-up paint matching the white finish.

SPECIFICATIONS

- **Model:** LT1231135B
- **Brand:** LITFAD
- **Material:** Manufactured Wood (Engineered Wood)
- **Color:** White
- **Dimensions (L x W x H):** 12" x 7" x 43" (30cm x 17cm x 110cm)
- **Number of Shelves/Compartments:** 3 (Flip-down doors)
- **Mounting Type:** Freestanding
- **Assembly Required:** Yes
- **Special Feature:** Push door opening (Flip-down mechanism)

WARRANTY INFORMATION

LITFAD products are manufactured with quality and care. Specific warranty details may vary. Please retain your proof of purchase. For warranty claims or inquiries, refer to the contact information in the Support section.

SUPPORT AND CONTACT INFORMATION

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact LITFAD customer support.

- **Online Support:** Visit the official LITFAD store on Amazon: [LITFAD Store](#)
- **Email:** Refer to your purchase documentation for direct email support.

© 2024 LITFAD. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CW5G1M89>

More documents and user manuals: <https://manuals.plus/>