**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## ULTIMEA U0200

# ULTIMEA Portable Mini Projector User Manual

Model: Apollo P10 (U0200)

## Introduction

Thank you for choosing the ULTIMEA Portable Mini Projector. This manual provides essential information for setting up, operating, and maintaining your projector to ensure optimal performance and longevity. The Apollo P10 offers a full HD viewing experience with 2K decoding, 300 ANSI lumens, and versatile connectivity options.

## Package Contents

- ULTIMEA Portable Mini Projector
- Remote Control
- Power Adapter
- User Manual

## Setup Guide

### Step 1: Power On

Connect the power adapter to the projector and a power outlet. Press the power button located on the top of the projector to turn it on. The indicator light will change from red (standby) to blue (powered on).




Image: The ULTIMEA Portable Mini Projector, showcasing its compact design and top-mounted power button.

### Step 2: Focus Adjustment

The Apollo P10 features electric focus. Use the 'F+' or 'F-' buttons on the remote control to achieve a sharp and clear image. This eliminates the need for manual lens adjustments.




Image: The projector's electric focus feature, demonstrating how to adjust image clarity using the remote control.

## Step 3: Connectivity

### Wireless Connection (Screen Mirroring)

The projector supports both 2.4GHz and 5GHz WiFi bands for stable and fast screen mirroring. For Android, iOS, Windows, and Mac devices, you can directly stream your screen to the projector in just two steps. Innovative P2P technology allows iOS synchronization via USB cable even without a home WiFi network, ideal for outdoor movie nights.




Image: A smartphone wirelessly mirroring its screen to the projector, highlighting 2.4G+5G wireless screening capability.




Image: The projector being used outdoors for a movie night, demonstrating P2P technology for screen mirroring without a WiFi connection.

### Wired Connection

The projector offers multiple ports for wired connections, including HDMI, 2 USB ports, AV, and Audio Out. Easily connect devices such as TV Sticks, Roku, Laptops, and gaming consoles like Nintendo Switch for a seamless entertainment experience. The built-in high-fidelity speakers provide captivating sound, and you can also connect external sound devices via Bluetooth for enhanced audio.




Image: A vibrant image projected, highlighting the clear and bright output with 300 ANSI Lumens and 1080P Decoding.




Image: Demonstrating 5.1 Bidirectional Bluetooth Connection, allowing the projector to connect to external audio devices.

---

## Operating Instructions

### Navigating the Interface

The ULTIMEA projector features an intuitive user interface for easy navigation. Use the directional buttons on the

remote control to select options such as Wireless Screen, Wired Screen, Movie, Photo, Music, and Book. The 'OK' button confirms your selection, and the 'Back' button returns to the previous screen.

### Adjusting Settings

Access the 'Setting' menu to customize your viewing experience. Options include:

- **OSD Lang:** Change the On-Screen Display language.
- **Flip:** Adjust projection mode (e.g., Front Table).
- **Factory Reset:** Restore default settings.
- **Software Upgrade:** Update the projector's firmware.
- **WiFi:** Configure wireless network settings.
- **Auto Sleep:** Set automatic shutdown timer.
- **OSD Timer:** Adjust the display time for on-screen messages.
- **Window Zoom:** Adjust the size of the projected image.

---

## Maintenance

To ensure the longevity and optimal performance of your ULTIMEA projector, regular maintenance is recommended:

- **Cleaning:** Gently wipe the lens with a soft, lint-free cloth. For the projector body, use a dry cloth. Avoid abrasive cleaners or solvents.
- **Dust Prevention:** The fully enclosed optical engine design helps prevent dust from entering, but ensure the projector's vents are clear of obstructions for proper airflow.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

---

## Troubleshooting

If you encounter issues with your projector, consider the following common solutions:

- **Blurred Image:** Use the electric focus ('F+' / 'F-') buttons on the remote to sharpen the image. Ensure the projector is placed at an appropriate distance from the projection surface.
- **No Signal:** Verify that the correct input source (HDMI, USB, etc.) is selected in the projector's menu. Check all cable connections for security.
- **Wireless Connectivity Issues:** Ensure your device is connected to the correct 2.4GHz or 5GHz WiFi band. For iOS, try the P2P connection with a USB cable if WiFi is unstable.
- **No Sound/Low Sound:** Check the projector's volume settings. Ensure external speakers (if connected) are powered on and properly paired via Bluetooth or wired connection.
- **Overheating:** Ensure the projector's vents are not blocked. Allow adequate space around the projector for ventilation.

---

## Specifications

| Feature | Detail |
|---|---|
| Brand Name | ULTIMEA |
| Model Number | U0200 |
| Item Weight | 4.24 pounds |
| Package Dimensions | 11.61 x 9.57 x 5.91 inches |
| Color Name | White |
| Special Features | Portable |
| Display Resolution | 1024 x 720 (2K Decoding Supported) |
| Brightness | 300 ANSI Lumens |
| Connectivity Technology | Wi-Fi (5G/2.4G), HDMI, 2*USB, AV, Audio Out |
| Recommended Uses | Home Cinema |
| Visible Screen Diagonal | 150" / 381 cm |

## Official Product Videos

No official seller videos are available for this product in the provided data.

## Warranty and Support

For warranty information, technical support, or any inquiries regarding your ULTIMEA Portable Mini Projector, please refer to the warranty card included in your package or visit the official ULTIMEA website. Contact information for customer service is typically provided on the product packaging or within the full user manual.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0CW5M8T6S**

More documents and user manuals: **https://manuals.plus/**