

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [REACHER](#) /

› **REACHER Sound Machine with Dual Alarm Clock, Bluetooth Speaker, and Wireless Charging Station (Model CR8) User Manual**

REACHER CR8

REACHER Sound Machine with Dual Alarm Clock, Bluetooth Speaker, and Wireless Charging Station

MODEL: CR8

User Manual

1. INTRODUCTION

The REACHER CR8 is a versatile 4-in-1 bedside device designed to enhance your sleep and daily routine. It integrates a sound machine with 20 soothing sounds, a dual alarm clock, a Bluetooth speaker, and a wireless charging station. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.



Image 1.1: The REACHER CR8 Sound Machine, showcasing its wireless charging capability and digital time display.

2. SAFETY INFORMATION

Please read and follow these safety guidelines carefully before using the device:

- Always follow the manufacturer's instructions for safe operation.
- Keep the device dry and away from heat sources.
- Do not expose yourself to loud noises for extended periods.
- This device is not a toy and should not be used as such.
- Do not use the wireless charging station if the device is damaged or wet.
- Ensure proper ventilation around the device during operation.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- REACHER CR8 Sound Machine
- Power Adapter
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the device's components and controls.



Image 4.1: Top view of the REACHER CR8, highlighting the control panel and wireless charging area.

Control Buttons and Ports:

- **Power Button:** Turns the device on/off.
- **Sound Selection:** Cycles through 20 soothing sounds.
- **Volume Control Dial:** Adjusts sound and alarm volume.
- **Alarm 1/2 Buttons:** Sets and activates Alarm 1 and Alarm 2.
- **Snooze Button:** Activates snooze for alarms.
- **Bluetooth Button:** Initiates Bluetooth pairing mode.
- **Dimmer Dial:** Adjusts display brightness (0-100%).
- **DC Power Input:** Connects to the power adapter.

5. SETUP

5.1 Initial Setup and Power Connection

1. Unpack the REACHER CR8 and place it on a stable, flat surface.

2. Connect the provided power adapter to the DC Power Input port on the back of the device.
3. Plug the power adapter into a standard electrical outlet. The display will light up.

5.2 Time Setting

The device automatically syncs time via Bluetooth when connected to a smartphone. Manual adjustment may be available through specific buttons (refer to detailed instructions in the full manual if needed).

5.3 Bluetooth Pairing

To use the Bluetooth speaker function:

1. Press the **Bluetooth Button** on the device. The Bluetooth indicator will flash.
2. On your smartphone or other Bluetooth-enabled device, search for 'REACHER CR8' in the Bluetooth settings.
3. Select 'REACHER CR8' to pair. A confirmation sound will indicate successful pairing.

5.4 Wireless Charging Setup

The integrated wireless charging pad supports Qi-enabled devices.

1. Place your compatible smartphone or device on the center of the charging pad located on top of the sound machine.
2. Ensure the device is properly aligned for optimal charging. A charging indicator on your phone will confirm charging has begun.
3. Note: Cases thicker than 5mm may interfere with wireless charging.

Dual Alarm

with 8 natural alarm sounds



Image 5.1: Illustrates the wireless charging function and case thickness compatibility.

6. OPERATING INSTRUCTIONS

6.1 Sound Machine Operation

The device offers 20 soothing sounds for relaxation and sleep.



5.0 Bluetooth Speaker

command your audio and sync time via bluetooth

Image 6.1: Visual representation of the 20 soothing sounds available on the device.

- **Selecting Sounds:** Press the **Sound Selection** button to cycle through the 20 available sounds (e.g., rain, fan, ocean wave, white noise).
- **Adjusting Volume:** Rotate the **Volume Control Dial** to increase or decrease the sound level.
- **Sleep Timer:** Activate the sleep timer to automatically turn off the sound after a set duration (e.g., 30, 60, 90, 120 minutes). Refer to the device's specific button for timer settings.

6.2 Alarm Clock Functions

Set up to two independent alarms with natural wake-up sounds.

0-100% Dimmable Display

easy to read during the day, no glaring at night



Image 6.2: The dual alarm feature with natural alarm sounds.

- **Setting Alarms:** Press and hold the **Alarm 1** or **Alarm 2** button to enter alarm setting mode. Use the appropriate buttons (e.g., +/- or navigation buttons) to set the desired wake-up time and alarm sound (8 natural sounds available: Beep, Lullaby, Rain, Ocean Wave, Brook, Bell, Bird, Soft Music). Press the alarm button again to confirm.
- **Activating/Deactivating Alarms:** Briefly press the **Alarm 1** or **Alarm 2** button to toggle the alarm on or off. An alarm icon will appear on the display when active.
- **Snooze Function:** When an alarm sounds, press the **Snooze Button** to temporarily silence it for 9 minutes.

6.3 Bluetooth Speaker

After successful pairing (Section 5.3), you can stream audio wirelessly.

Wireless Charging Station

compatible with iPhone, Samsung and other Qi-enabled phones



Image 6.3: Using the device as a Bluetooth speaker.

- Play audio from your connected device. The sound will output through the REACHER CR8 speaker.
- Use the **Volume Control Dial** on the sound machine or your connected device to adjust playback volume.

6.4 Display Brightness

Adjust the display brightness from 0% to 100% to suit your preference.

- Rotate the **Dimmer Dial** (usually located on the back or side) to increase or decrease the display brightness.

6.5 Memory Function

The built-in CR2023 button cell battery saves your last settings, including alarm times, sound preferences, and display brightness, in case of a power outage.

7. MAINTENANCE

To ensure the longevity and proper functioning of your REACHER CR8:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use liquid cleaners or

abrasive materials.

- **Storage:** When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Avoid Obstructions:** Ensure that the ventilation openings are not blocked to prevent overheating.

8. TROUBLESHOOTING

If you encounter issues with your REACHER CR8, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	Power adapter not connected or faulty outlet.	Ensure the power adapter is securely plugged into the device and a working electrical outlet. Try a different outlet.
Wireless charging is not working.	Phone misalignment, thick case, or incompatible device.	Reposition your phone on the charging pad. Remove thick phone cases. Verify your device supports Qi wireless charging.
Bluetooth cannot connect.	Device not in pairing mode, or already connected to another device.	Ensure the sound machine is in Bluetooth pairing mode (flashing indicator). Disconnect from other devices. Restart both devices and try pairing again.
Alarm does not sound.	Alarm not activated or volume too low.	Check if the alarm is set and activated (alarm icon on display). Increase the alarm volume using the Volume Control Dial.
Display is too dim or too bright.	Dimmer setting needs adjustment.	Rotate the Dimmer Dial to adjust the display brightness to your preference.

9. SPECIFICATIONS

Feature	Detail
Product Dimensions	6.7 x 3.4 x 3.1 inches
Weight	1.83 Pounds
Model Number	CR8
Brand	REACHER
Material	Wood, Fabric Display
Power Source	Corded Electric
Wireless Charging Output	Up to 10W (7.5W for iPhone, 5W for standard Qi)


Feature	Detail
Bluetooth Version	5.0
Soothing Sounds	20 (Nature tones, white noise, fan sounds)
Alarm Sounds	8 Natural Sounds
Display Dimmer	0-100% adjustable

10. WARRANTY AND SUPPORT

REACHER products are designed for reliability and performance. For specific warranty details and customer support, please refer to the warranty card included with your purchase or visit the official REACHER brand store.


REACHER Brand Store: <https://www.amazon.com/stores/Reacher/page/FF352095-024E-4C85-B412-EA14D63407D8>

Related Documents - CR8

 <p>Reacher ACR-2P Radio Alarm Clock USER MANUAL</p>	<p>Reacher ACR-2P Radio Alarm Clock User Manual</p> <p>Comprehensive user manual for the Reacher ACR-2P Radio Alarm Clock, covering features like FM radio, dual alarms, snooze, dimmer, USB charging, thermometer, sleep timer, and detailed instructions for setting time, alarms, and using radio functions.</p>
	<p>R9 Wireless Charging Sound Machine User Manual - Reacher</p> <p>User manual for the Reacher R9 Wireless Charging Sound Machine, detailing setup, functions, alarm settings, sound machine features, wireless charging, and safety instructions.</p>
 <p>Reacher R2 User Manual and Warranty</p>	<p>Reacher R2 User Manual and Warranty</p> <p>User manual and warranty information for the Reacher R2, a sound machine and night light with 31 soothing sounds, 8-color night light, and sleep timer. Suitable for babies, children, adults, and seniors.</p>
	<p>Reacher A1S White Noise Machine Alarm Clock User Manual</p> <p>Official user manual for the Reacher A1S White Noise Machine Alarm Clock, providing instructions on setup, features, alarm settings, sound machine, nightlight, and troubleshooting.</p>
	<p>Reacher ACR-WS Alarm Clock User Manual</p> <p>User manual for the Reacher ACR-WS alarm clock, detailing features such as FM radio, wireless charging, USB charging, alarm settings, snooze function, and dimmer. Includes instructions for setup, operation, and care.</p>

	<p>Reacher GX Alarm Clock User Manual: Setup, Features, and Safety Guide</p> <p>Comprehensive user guide for the Reacher GX portable alarm clock. Learn how to set time, alarms, wake-up modes, vibration, auto-dimming, and safety features. Includes troubleshooting and support information.</p>
---	---

Documents - REACHER – CR8



[AMRE Supply Building Maintenance Parts and Supplies Catalog 2018-2019](#)

Explore the comprehensive 2018-2019 catalog from AMRE Supply, featuring a wide range of building maintenance parts and supplies. Discover products for appliances, plumbing, lighting, cleaning, safety, hardware, HVAC, and more. AMRE Supply offers quality products, trusted brands, and efficient services to meet all your property maintenance needs.

lang:en score:9 filesize: 27.44 M page_count: 364 document date: 2018-06-02



[Greenlee Professional Tools Catalog: Electrical, Utility & Communications](#)

Explore Greenlee's comprehensive catalog of professional tools for electrical, utility, and communications trades. Discover hand tools, knockout systems, wire termination, and more, designed for speed, safety, and efficiency.

lang:en score:8 filesize: 48.31 M page_count: 484 document date: 2015-06-11