Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MM-CRMC-A764JBEZ-K-NP

ALLIMITY Air Conditioner Remote Control User Manual

Compatible with Sharp AC Models: CRMC-A764JBEZ, CRMC-A729JBEZ, AY-AP9FHR-WH

1. Introduction and Overview

This manual provides instructions for the ALLIMITY Air Conditioner Remote Control, designed as a direct replacement for various Sharp AC models. This remote control is engineered for ease of use, requiring no complex programming or installation steps. It offers full functionality, replicating all features of the original remote.

Its ergonomic design ensures a comfortable grip, and it provides stable remote control performance with an extended transmission distance. Please ensure your original remote or AC unit model matches the compatible models listed to guarantee proper functionality.

Compatible Models: CRMC-A764JBEZ, CRMC-A729JBEZ, AY-AP9FHR-WH



Figure 1.1: Front view of the ALLIMITY Air Conditioner Remote Control, showing the display screen and various control buttons.

2. Setup: Battery Installation

The remote control operates on standard AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings

inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries.



Figure 2.1: Back view of the remote control, illustrating the battery compartment area.

3. Operating Instructions

This remote control provides intuitive access to all essential functions of your Sharp air conditioner. Point the remote control directly at the air conditioner's receiver when operating.

3.1. Power Button

The large circular button, typically yellow or orange, is the main power button. Press it once to turn the air conditioner ON, and press it again to turn it OFF.

3.2. Mode Selection (MODE)

Press the **MODE** button to cycle through the available operating modes of your air conditioner. Common modes include:

- **AUTO:** The unit automatically selects the operating mode (cooling, heating, fan) based on the room temperature.
- **COOL:** For cooling the room.
- **DRY (Dehumidify):** Reduces humidity in the room.
- **FAN:** Circulates air without cooling or heating.
- **HEAT:** For heating the room (if supported by your AC unit).

3.3. Temperature Adjustment (TEMP. ▲/▼)

Use the **TEMP. ▲** (up arrow) button to increase the desired temperature and the **TEMP. ▼** (down arrow) button to decrease it. The current temperature setting will be displayed on the remote's LCD screen.

3.4. Fan Speed Control (FAN)

Press the **FAN** button to adjust the fan speed. Options typically include Auto, Low, Medium, and High. The fan speed icon on the display will change accordingly.

3.5. Swing Function (SWING)

The **SWING** button controls the vertical airflow direction of the air conditioner. Pressing it will typically activate or deactivate the automatic louver swing, distributing air more evenly.

3.6. Timer Function (TIMER)

The **TIMER** button allows you to set a specific time for the air conditioner to turn ON or OFF automatically. Refer to your air conditioner's main manual for detailed timer programming instructions, as this remote provides the interface for that function.

3.7. Display Button (DISPLAY)

The **DISPLAY** button may control the illumination of the air conditioner's display panel or cycle through different display information on the remote itself, such as current room temperature or set temperature.

3.8. Cancel Button (CANCEL)

The **CANCEL** button is typically used to exit a menu, cancel a timer setting, or clear a specific function.

4. Maintenance

4.1. Cleaning the Remote Control

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these can damage the remote's surface or internal components.

4.2. Battery Replacement

Replace batteries when the remote's range decreases significantly or if the display becomes dim. Always replace both batteries simultaneously with new AAA batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner.
- **Short operating range:**
  - This usually indicates low battery power. Replace the batteries.
  - Ensure no strong light sources (like direct sunlight) are interfering with the infrared signal.
- **Air conditioner not performing desired function:**
  - Verify that the air conditioner unit itself is powered on and functioning correctly.
  - Ensure the remote control model is indeed compatible with your specific Sharp AC unit model.

6. Specifications

Brand:
ALLIMITY

Model Name:
CRMC-A764JBEZ (Replacement for MM-CRMC-A764JBEZ-K-NP)

Compatible Devices:
Sharp AC models: CRMC-A764JBEZ, CRMC-A729JBEZ, AY-AP9FHR-WH

Connectivity Technology:
Infrared

Controller Type:
Button Control

Button Quantity:
2

Maximum Range:
10 Meters

Product Dimensions:
17 x 5 x 1 cm

Item Weight:
59 Grams

Special Features:
Ergonomic

7. Warranty and Support

This ALLIMITY remote control is designed for reliable performance. For any issues not covered in the troubleshooting section, or for warranty inquiries, please contact the seller or the manufacturer directly through the platform where the product was purchased.

Please retain your proof of purchase for warranty purposes.

© 2025 ALLIMITY. All rights reserved. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CW66HJZW

More documents and user manuals: **https://manuals.plus/**