

[Manuals.plus](#) /

› [Energeeks](#) /

› Energeeks EG-S003 Additional Siren Instruction Manual

Energeeks EG-S003

Energeeks EG-S003 Additional Siren Instruction Manual

Model: EG-S003

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Energeeks EG-S003 Additional Siren. Please read this manual thoroughly before using the device to ensure proper function and safety.

SAFETY INFORMATION

- Ensure the device is installed in a dry environment, away from direct water exposure.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Keep the device out of reach of children.
- Use only the specified power source for the device.
- Avoid placing the siren near heat sources or in direct sunlight.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Energeeks EG-S003 Additional Siren Unit
- Mounting Hardware (screws, wall plugs)
- Instruction Manual (this document)

PRODUCT OVERVIEW

The Energeeks EG-S003 is an additional siren designed to enhance your security system. It features a compact design with a prominent red light and an audible alarm.



Image: The Energeeks EG-S003 Additional Siren shown alongside its retail packaging. The siren is white with a red central light and a small button below it. The box displays the 'energeeks' logo and product name in multiple languages.



Image: A detailed close-up of the Energeeks EG-S003 Additional Siren. It highlights the white casing, the large red central light, and the small circular button located at the bottom of the unit.

SETUP

1. Mounting the Siren

1. Choose a suitable location for the siren, preferably indoors and in a central area for optimal sound distribution.
2. Mark the desired drilling points on the wall using the siren's mounting plate as a template.
3. Drill holes and insert the provided wall plugs.
4. Secure the siren's mounting plate to the wall using the screws.
5. Attach the siren unit to the mounted plate.



Image: The Energeeks EG-S003 Additional Siren is shown mounted on a light grey wall plate, which is then affixed to a darker wall surface. This demonstrates a typical installation scenario.

2. Powering the Device

Connect the siren to its designated power source. Ensure the power adapter is securely plugged into both the siren and a working electrical outlet.

3. Pairing with an Alarm System

The EG-S003 siren is designed to integrate with compatible alarm systems. The pairing process typically involves:

1. Activating the pairing mode on your main alarm control panel (refer to your alarm system's manual for specific instructions).
2. Pressing the pairing button on the EG-S003 siren (usually the small button on the front or a button inside the casing).
3. Confirming successful pairing through an indicator light or sound from either the siren or the control panel.

The siren can function as an external siren for your existing alarm system. Additionally, it has the capability to act as a standalone alarm unit if compatible detectors are synchronized with it.

OPERATING THE SIREN

Once successfully paired and powered, the Energeeks EG-S003 siren will operate in conjunction with your security system.

- **As an Additional Siren:** When your main alarm system is triggered, the EG-S003 will activate its audible alarm and flashing light, providing an additional deterrent and notification.
- **As a Standalone Alarm:** If you have synchronized compatible detectors (e.g., door/window sensors, motion detectors) directly with the EG-S003, it can function independently. When a synchronized detector is triggered, the siren will activate.

To disarm the siren, typically you will disarm your main alarm system, or if operating standalone, use the remote control or disarm method associated with the synchronized detectors.

MAINTENANCE

Cleaning

To clean the siren, gently wipe the exterior with a soft, dry cloth. Do not use abrasive cleaners, solvents, or spray liquids directly onto the device.

Battery Replacement (if applicable)

If your siren model includes a backup battery, replace it according to the manufacturer's guidelines when the low battery indicator is active. Ensure the device is powered off before attempting battery replacement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Siren does not activate.	No power; Not paired correctly; Alarm system not triggered.	Check power connection. Re-pair the siren with the alarm system. Verify the main alarm system is functioning.
Siren activates unexpectedly.	False alarm from main system; Detector malfunction (if standalone).	Check your main alarm system's event log. Inspect synchronized detectors for issues.
Siren sound is weak or distorted.	Low battery (if applicable); Obstruction.	Replace backup battery. Ensure no objects are blocking the siren's speaker.

SPECIFICATIONS



Image: The Energeeks EG-S003 Additional Siren shown with measurement indicators, highlighting its dimensions of 10 cm (approximately 3.94 inches) in both width and height.

- **Model Number:** EG-S003
- **Brand:** Energeeks
- **Color:** Multicolour (referring to the light and casing)
- **Dimensions (L x W x H):** 3.54 x 3.54 x 3.54 inches (approximately 9 x 9 x 9 cm)
- **Manufacturer:** ENERGEEKS
- **Included Components:** Siren unit, mounting hardware.
- **Unit Count:** 1

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Energeeks website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question