Abolee FXH009R

Abolee Pedestal Air Circulator Fan FXH009R User Manual

Model: FXH009R

1. Introduction

Thank you for choosing the Abolee Pedestal Air Circulator Fan FXH009R. This fan is designed to provide efficient and quiet air circulation for your home or office. Please read this manual thoroughly before operating the fan to ensure safe use, optimal performance, and proper maintenance. Keep this manual for future reference.



The Abolee Pedestal Air Circulator Fan FXH009R, a sleek black standing fan with a circular head and a stable base.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using this fan.
- Place the fan on a stable, level surface to prevent it from tipping over.
- Do not use the fan near water or in damp environments.
- Always unplug the fan from the power outlet before cleaning, moving, or performing any maintenance.
- Keep fingers, hair, and other objects away from the fan blades and openings during operation.
- Do not operate the fan with a damaged cord or plug. If the cord or plug is damaged, contact customer support.
- Ensure children are supervised when the fan is in use. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not block air openings or operate the fan on a soft surface, such as a bed or rug, where openings may become blocked.

- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fan.

3. Package Contents


Verify that all components are present in the package:

- Fan Head
- Adjustable Stand Pole
- Base
- Remote Control
- User Manual

4. Setup Instructions

Follow these steps to assemble your Abolee Pedestal Air Circulator Fan:

1. **Attach the Stand Pole to the Base:** Carefully insert the bottom end of the adjustable stand pole into the designated slot on the fan base. Twist or secure with provided fasteners until it is firm and stable.
2. **Secure the Fan Head:** Place the fan head onto the top of the adjustable stand pole. Ensure it clicks into place or is securely fastened according to the design.
3. **Verify Connections:** Double-check that all connections are firm and the fan is stable before proceeding.
4. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet.



The Abolee Pedestal Fan in a living room setting, highlighting its 36-inch adjustable height and modern design.

5. Operating Instructions

Your Abolee Pedestal Fan offers various settings for customized comfort. Operate the fan using either the touch control panel on the fan body or the included remote control.

Power On/Off

Press the **Power** button () on the control panel or remote control to turn the fan on or off.

Wind Modes

Press the **Mode** button () to cycle through the available wind modes:

- **Normal Mode:** Provides a constant, steady airflow at your selected speed.
- **Natural Mode:** Simulates a natural breeze by varying the fan speed intermittently.
- **Sleep Mode:** Operates at a low, quiet speed to minimize disturbance during sleep.
- **AI Mode:** Automatically adjusts the fan speed based on the ambient room temperature, providing optimal comfort without manual adjustments.



Close-up of the Abolee Pedestal Fan's control panel and head, illustrating the four available wind modes and four speed settings.

Fan Speeds

Use the **+** and **-** buttons on the control panel or remote to adjust the fan speed from 1 (lowest) to 4 (highest).

Oscillation and Tilt

- **Horizontal Oscillation:** Press the **Oscillation** button ( ) to activate the 70° automatic horizontal swing,

distributing air across a wider area. Press again to stop.

- **Vertical Tilt:** The fan head can be manually adjusted up to 90° vertically to direct airflow precisely where needed.



The Abolee Pedestal Fan showcasing its omni-directional oscillation, with arrows indicating 70 degrees of horizontal swing and 90 degrees of manual vertical tilt.

Timer Function

Press the **Timer** button ( ) to set the fan to automatically turn off after a specified period, from 0 to 24 hours. Each press increases the timer by one hour.

Child Lock

Activate the **Child Lock** feature ( ) to prevent unintended changes to settings by children or pets. Press and hold the button for a few seconds to activate/deactivate.

Remote Control

The included remote control allows for convenient operation from a distance. Ensure the remote has working batteries and is pointed towards the fan's receiver. For optimal performance, store the remote on the fan base when not in use.



A family using the remote control for the Abolee Pedestal Fan, highlighting the convenience of remote operation and the clear LED display on the fan's body.

Your browser does not support the video tag.

This video provides a visual overview of the Abolee Pedestal Fan, including its assembly, operation, and the functionality of its remote control.

6. Maintenance and Cleaning

Regular cleaning helps maintain the fan's performance and extends its lifespan.

- **Before Cleaning:** Always unplug the fan from the power outlet.
- **Cleaning the Blades:** The front grille can be easily removed to access and wipe the fan blades clean. Use a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Exterior Cleaning:** Wipe the exterior surfaces of the fan with a soft, dry cloth.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging.

7. Troubleshooting

If you encounter any issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply.	Check if the power cord is securely plugged into a functional outlet.
Remote control is not working.	Dead batteries or obstruction.	Replace remote control batteries. Ensure there is a clear line of sight between the remote and the fan's receiver.
Weak or no airflow.	Low speed setting or obstructed intake/output.	Increase the fan speed. Check for any obstructions around the fan's air intake or output.
Unusual noise during operation.	Loose parts or debris.	Unplug the fan and inspect for any loose components or debris caught in the fan blades. Clean as per maintenance instructions.
Oscillation not working.	Oscillation function not activated.	Press the oscillation button on the control panel or remote.

8. Specifications

Brand	Abolee
Model Name	FXH009R
Product Dimensions	14"D x 14"W x 36"H
Electric Fan Design	Pedestal Fan / Floor Fan
Power Source	AC
Special Features	Oscillating, Remote Controlled, Timer, Child Lock, AI Mode
Recommended Uses	Air Circulation, Cooling, Drying

Mounting Type	Floor Mount
Controller Type	Remote Control, Touch Panel
Number of Speeds	4
Noise Level	23 Decibels (in Sleep Mode)
Wattage	60 watts
Air Flow Capacity	915 Cubic Feet Per Minute (CFM)
Air Throw Distance	100 feet
Speed	21 feet per second (Max)
Voltage	120 Volts
Indoor Outdoor Usage	Indoor
Motor Type	Brushless DC Motor
Material	Plastic
Blade Material	Plastic
Oscillation	70° Horizontal, 90° Manual Vertical Tilt
Timer	0-24 Hours
UPC	717225932862
Certifications	FCC, RoHS, UL

9. Warranty and Support

Warranty Information

This Abolee product is covered by a product and labor warranty for**5 years** from the date of its original purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or any other customer service inquiries, please refer to the contact information provided in your product packaging or visit the official Abolee website for support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question