

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Edifier](#) /

› [Edifier MG300 Computer Speakers PC SoundBar User Manual](#)

Edifier MG300

Edifier MG300 Computer Speakers PC SoundBar User Manual

Model: MG300 | Brand: Edifier

INTRODUCTION

Thank you for purchasing the Edifier MG300 Computer Speakers PC SoundBar. This manual provides essential information for setting up, operating, and maintaining your new soundbar. Please read this manual thoroughly before use to ensure proper functionality and to maximize your listening experience.

SAFETY INFORMATION

To reduce the risk of electric shock, fire, or damage to your device, please observe the following safety precautions:

- Do not expose the device to rain or moisture.
- Do not place objects filled with liquids, such as vases, on the device.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel.

PACKAGE CONTENTS

Please check the box for the following items:

- Edifier MG300 Soundbar
- USB-A to USB-C Cable
- User Manual

PRODUCT OVERVIEW

The Edifier MG300 Soundbar features dual 52mm full-range speakers and dual inverter tubes for balanced audio. It includes dynamic RGB lighting effects and a hidden microphone for clear voice communication. Control buttons are located on the top panel for easy access.

Powerful Yet Pure Sound

Dual High-quality 52mm Drivers and 2 Mica
Fiber Diaphragms



Image: Internal Speaker Components

This image illustrates the internal structure of the soundbar, showcasing the dual 52mm drivers and mica fiber diaphragms designed for powerful and pure sound reproduction.

SETUP

1. Placement

Position the Edifier MG300 soundbar on a stable, flat surface, ideally directly under your computer monitor. Its compact design (485mm x 70mm x 80mm) is optimized to save desktop space.

Compact size and elevation design

15.67 x 3.33 x 2.89 inches,

better placed under computer screen to save desktop space



Image: Soundbar Placement

The soundbar is shown positioned beneath a computer monitor, demonstrating its space-saving design and ideal placement for desktop use.

2. Power and Connection Options

The MG300 offers two primary connection methods: USB-A and Bluetooth 5.3.

2 Connection Options



USB connection



Bluetooth V5.3 for a stable connection



Image: Connection Options

This image illustrates the two main ways to connect the soundbar: via USB to a computer or wirelessly via Bluetooth to mobile devices.

USB Connection (for PC)

1. Connect the provided USB-A to USB-C cable to the USB-C port on the back of the soundbar.
2. Plug the USB-A end into an available USB port on your computer.
3. The soundbar will power on automatically and be recognized as an audio output device by your computer.

Bluetooth Connection (for Mobile Devices)

1. Press the Bluetooth button on the top panel of the soundbar to enter Bluetooth pairing mode. The RGB lights will flash to indicate pairing mode.
2. On your mobile device (smartphone, tablet), enable Bluetooth and search for available devices.
3. Select "Edifier MG300" from the list of devices to pair.
4. Once connected, the RGB lights will stop flashing and remain solid.

OPERATING INSTRUCTIONS

1. Power On/Off

Press and hold the power button (**U**) on the top panel to turn the soundbar on or off.

2. Volume Control

Use the volume up (+) and volume down (-) buttons on the top panel to adjust the audio level.

3. RGB Lighting Control

The soundbar features dynamic RGB lighting effects. Press the light control button (**O:**) on the top panel to cycle through different lighting modes or to turn the lights off.



Image: RGB Light Control

This image shows the control panel on the soundbar, indicating the button used to manage the RGB lighting effects.

4. Music and Game Sound Modes

The MG300 offers optimized sound effects for both music and gaming. Press the mode button (often integrated with play/pause or a dedicated button) to switch between these modes. In music mode, vocals are amplified for a richer listening experience. In game mode, environmental details are enhanced for immersive realism.

Equipped with game/music sound effects and professional tuning to fit various scenarios



Game modes

Music modes

Image: Game and Music Modes

This image demonstrates the soundbar's adaptability, showing it in use for both gaming and music listening, each with optimized sound profiles.

5. Using the Hidden Microphone

The soundbar features a hidden microphone, cleverly integrated under a silicone protective sleeve on the top panel. This design helps isolate external vibrations, ensuring crystal clear voice calls and communication during gaming or online meetings.

HIDDEN MICROPHONE

You can talk in the state of
Bluetooth/USB computer communication



Image: Hidden Microphone in Use

This image depicts the soundbar's hidden microphone being utilized during a gaming session, emphasizing its clarity for in-game communication.

MAINTENANCE

To ensure the longevity and optimal performance of your Edifier MG300 soundbar, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the soundbar. Do not use liquid cleaners or aerosol sprays, as they may damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the soundbar in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Obstructions:** Ensure that the speaker grilles are not obstructed to maintain proper sound dispersion and prevent overheating.

TROUBLESHOOTING

If you encounter any issues with your Edifier MG300 soundbar, please refer to the following common problems and solutions:

- **No Sound:**

- Ensure the soundbar is powered on and connected correctly (USB or Bluetooth).
- Check the volume levels on both the soundbar and your connected device.
- If using USB, verify that the soundbar is selected as the default audio output device in your computer's sound settings.
- If using Bluetooth, ensure the device is paired and within range.

- **Poor Sound Quality:**

- Ensure the soundbar is placed on a stable surface and not obstructed.
- Try adjusting the volume and switching between music/game modes.
- If connected via Bluetooth, try moving closer to the soundbar to improve signal strength.

- **RGB Lights Not Working:**

- Press the light control button (O:) to cycle through modes or turn them on.
- Ensure the soundbar is powered on.

- **Microphone Not Working:**

- Ensure the soundbar is connected via USB to your PC.
- Check your computer's sound settings to ensure the soundbar's microphone is selected as the input device.

SPECIFICATIONS

Model Name	MG300
Speaker Type	Multi Room
Special Feature	Portable
Recommended Uses	For Computers
Compatible Devices	Computer, Laptop, Smartphone, Tablet
Surround Sound Channel Configuration	2.0
Total Output Power (RMS)	2.5W + 2.5W (5 Watts total)
Bluetooth Version	V5.3
Frequency Response	80Hz - 20kHz
Dimensions (W x H x D)	485mm x 70mm x 80mm (15.67"D x 3.33"W x 2.89"H)
Net Weight	0.9kg (2.6 pounds)
Audio Inputs	Bluetooth, USB-A Soundcard
Control Method	Touch
Audio Driver Size	52 Millimeters

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: Edifier MG300 Overview

This video provides an overview of the Edifier MG300 soundbar, showcasing its features and design. It highlights the multi-driver PC soundbar and subwoofer, Bluetooth 5.3 connectivity, seamless PC and mobile connection, game sound effects, dynamic RGB lighting, USB connection, hidden mic, and immersive sound capabilities.

WARRANTY AND SUPPORT

The Edifier MG300 SoundBar comes with a Limited Warranty. For detailed warranty information or technical support, please refer to the official Edifier website or contact their customer service. Protection plans are also available for extended coverage.