

## Bar ZDQ-B14Y5

# Bar Electric Small Food Steamer ZDQ-B14Y5 Instruction Manual

Model: ZDQ-B14Y5 | Brand: Bar

## 1. INTRODUCTION

---

Thank you for choosing the Bar Electric Small Food Steamer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

## 2. PRODUCT OVERVIEW

---

### 2.1 Components

The Bar Electric Small Food Steamer is designed for versatility, featuring multiple components that allow for various cooking methods. Key components include the main heating base with a non-stick frying pan, a stainless steel steaming pot, an egg steaming rack, and a stainless steel lid.

# FULL FOOD GRADE 304 STAINLESS STEEL



Image: Exploded view showing the main heating base, non-stick frying pan, stainless steel steaming pot, egg steaming rack, and lid.

## 2.2 Key Features

- **Double Tier & Multifunctional:** Combine single or double tiers for steaming. The 26mm deep non-stick frying pan at the base allows for frying ham, bacon, or poached eggs.
- **9.5-Hour Preset & Smart Control Panel:** Offers flexible cooking times with an easy-to-use electronic screen and simple function keys.
- **Healthy Material & Anti-Dry Burn Protection:** Steaming bowl, basket, and plate are made of food-grade 304 stainless steel, ensuring durability, heat resistance, and easy cleaning. Automatic power cut-off when water is low prevents dry burning.
- **Compact Size & Easy Storage:** Designed to save kitchen space, ideal for dormitory or solo use. Separable design facilitates convenient use and cleaning.

## 3. SAFETY INSTRUCTIONS

- Always ensure the appliance is placed on a stable, flat, and heat-resistant surface.
- Do not immerse the main heating base in water or any other liquid.
- Keep out of reach of children and pets.

- Use only the provided power cord and ensure it is properly plugged into a compatible 120V~60Hz outlet.
- Avoid touching hot surfaces during and immediately after operation. Use oven mitts or handles.
- The appliance features anti-dry burn protection, which automatically shuts off power if water levels are too low. Do not override this safety feature.
- Unplug the appliance from the power outlet when not in use and before cleaning.

## 4. SETUP

---

Before initial use, unpack all components and wash the stainless steel parts and non-stick pan with warm, soapy water. Rinse thoroughly and dry. The appliance can be configured in various ways for different cooking needs.

### 4.1 Assembly Options

- **Single Tier Steaming:** Place the steaming pot directly onto the heating base.
- **Double Tier Steaming:** Place the steaming pot on the base, then stack the second steaming basket on top.
- **Frying Only:** Use only the heating base with its integrated non-stick frying pan.



Image: The steamer configured for two-tier steaming, hollow in the middle, and one-tier steaming, demonstrating its versatile assembly options.

## 5. OPERATING INSTRUCTIONS

### 5.1 Control Panel

The smart control panel features an electronic screen and intuitive function keys for easy operation. Use the arrow buttons to adjust the cooking time.



Image: The control panel displaying a timer, with an egg frying in the non-stick pan, highlighting the ease of use.

### 5.2 Steaming

1. Add the appropriate amount of water to the heating base.
2. Place the desired food (e.g., vegetables, eggs, dumplings) into the steaming basket(s).
3. Cover with the stainless steel lid.
4. Press the power button, then use the arrow keys to set the desired steaming time.
5. The appliance will automatically begin steaming.

# LIGHT MEAL & NUTRITIOUS BREAKFAST



Image: The steamer in operation, with corn cobs and eggs being steamed in the upper tier, demonstrating its steaming capability.

## 5.3 Frying

1. Ensure the steaming components are removed, leaving only the heating base with the non-stick frying pan.
2. Add a small amount of oil if necessary.
3. Place food directly into the frying pan (e.g., eggs, ham).
4. Press the power button and set the desired frying time.

## 5.4 9.5-Hour Preset Function

To use the preset function, press the preset button and adjust the desired delay time (up to 9.5 hours) before the cooking cycle begins. This allows for flexible meal preparation.

Your browser does not support the video tag.

Video: An official product video demonstrating the steaming and frying capabilities of the Bar Electric Small Food Steamer, showcasing its versatility and ease of use for various foods.

## 6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your steamer.

- Always unplug the appliance and allow it to cool completely before cleaning.
- The stainless steel steaming pot, egg rack, and lid are dishwasher safe or can be hand-washed with warm, soapy water.
- The non-stick frying pan integrated into the heating base should be wiped clean with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Do not immerse the main heating base in water. Wipe the exterior with a damp cloth.
- For stubborn stains or mineral deposits in the water reservoir, use a mixture of water and vinegar, let it soak, then scrub gently and rinse.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in; power outage; faulty outlet	Check power connection; test outlet with another appliance; contact support if issue persists.
Food not cooking evenly	Overloaded steaming basket; insufficient water; incorrect cooking time	Do not overload; ensure adequate water; adjust cooking time as needed.
Anti-dry burn protection activated	Water level too low	Unplug, allow to cool, add more water, then restart.
Steam leakage	Lid not properly seated; damaged seal	Ensure lid is securely placed; inspect seal for damage and contact support if necessary.

## 8. SPECIFICATIONS



Image: A visual representation of the Bar Electric Small Food Steamer's dimensions, showing its compact size.

Attribute	Detail
Model Number	ZDQ-B14Y5
Brand	Bar
Color	Green
Material	Stainless Steel
Product Dimensions	7.5"L x 8.9"W x 9.8"H
Capacity	1 Liters (water) / 14 Eggs
Power	360W
Voltage	120V~ 60Hz

Attribute	Detail
Current	3A
Manufacturer	Bear

## 9. WARRANTY AND SUPPORT

---

This product comes with a one-year free warranty from the date of purchase. For customer support, warranty claims, or any inquiries regarding your Bar Electric Small Food Steamer, please contact us:

- **Email:** [customer.service@pandabrand.com](mailto:customer.service@pandabrand.com)

Please retain your proof of purchase for warranty validation.