Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Csasan V90

Csasan V90 Wireless Sport Earbuds User Manual

Model: V90

Introduction

Thank you for choosing the Csasan V90 Wireless Sport Earbuds. These earbuds are designed to provide a high-quality audio experience with features tailored for active lifestyles, including a secure fit, long battery life, and water resistance. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

What's Included

Please check the package contents to ensure all items are present:

- 2x Sports Earbuds
- 1x Type-C Charging Case
- 1x USB-C Charging Cable
- 3x Pairs of Eartips (S/M/L)
- 1x Detailed User Manual



Image: Csasan V90 Wireless Sport Earbuds and their charging case, showing the earbuds with earhooks and the digital display on the case.

Product Overview

The Csasan V90 earbuds feature an ergonomic design with earhooks for a secure fit, making them ideal for sports and active use. They come with a portable charging case that also displays battery levels.



Image: Diagram illustrating the dimensions of the earbuds and charging case, along with icons indicating compatibility with iOS, Android, and Windows devices for automatic pairing.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case features a dual LED display to show the battery level of both the case and individual earbuds.

1. Connect the provided USB-C charging cable to the charging port on the case and a power source.
2. The LED display on the case will indicate charging status. A full charge takes approximately 1.5 hours for the case.
3. Place the earbuds into the charging case. They will begin charging automatically.



Image: The Csasan V90 charging case connected via USB-C cable, highlighting its 48-hour total playtime capacity.

2. Initial Pairing

The earbuds utilize Hall technology for seamless pairing.

1. Ensure Bluetooth is enabled on your device (smartphone, tablet, etc.).
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "V90" from the list.
4. Once connected, you will hear a confirmation prompt, and the earbuds will be ready for use.
5. After the initial pairing, the earbuds will automatically connect to your last paired device when the case is opened.

3. Fitting the Earbuds

For optimal sound quality and comfort, choose the correct ear tip size and ensure a secure fit.

1. The earbuds come with three sizes of ear tips (S/M/L). Try each size to find the one that provides the best seal and comfort for your ear canal.

2. Gently insert the earbud into your ear canal and rotate it slightly to ensure a snug fit.
3. Position the flexible earhook over your ear to secure the earbud in place, especially during physical activity.



Image: Visual guide on how to achieve a secure and comfortable fit with the Csasan V90 earbuds, including the use of flexible earhooks and the selection of appropriate ear tip sizes.

Operating Instructions

The Csasan V90 earbuds feature smart touch controls for easy management of audio and calls.



Image: A visual representation of the touch-sensitive area on the earbud and the corresponding functions for music playback, call management, and voice assistant activation.

Touch Control Functions

Action	Function
Single Tap (L/R Earbud)	Play/Pause Music, Answer Call
Double Tap (L Earbud)	Previous Track
Double Tap (R Earbud)	Next Track
Triple Tap (L Earbud)	Volume Down
Triple Tap (R Earbud)	Volume Up
Long Press (2 seconds) (L/R Earbud)	Reject Call, Activate Voice Assistant

Action	Function
Long Press (3 seconds) (L/R Earbud)	Power On/Off (if not in case)

Note: When placing earbuds back into the charging case and closing the lid, they will automatically disconnect and power off.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds have an IP7 waterproof rating, meaning they can resist sweat, rain, and minor water splashes. Do not submerge them in water or expose them to high-pressure water jets. Ensure earbuds are dry before placing them back in the charging case to prevent damage.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.

Troubleshooting

If you encounter issues with your earbuds, try the following solutions:

Common Issues and Solutions

Problem	Solution
Earbuds not pairing/connecting	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "V90" in your device's Bluetooth settings and re-pair. ◦ Place earbuds back in the case, close the lid, wait a few seconds, then open to re-initiate pairing mode.
Only one earbud working	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the charging case, close the lid, and then open it again. ◦ Try resetting the earbuds (refer to the detailed user manual for specific reset instructions if available).
Low volume or poor sound quality	◦ Adjust volume on both your device and the earbuds. ◦ Ensure ear tips are clean and provide a good seal in your ear canal. ◦ Try different sized ear tips. ◦ Clean any debris from the earbud speaker mesh.

Problem	Solution
Charging case not charging	◦ Check the USB-C cable and power adapter. Try a different cable or adapter. ◦ Ensure the charging port on the case is clean and free of debris.

SPECIFICATIONS

Detailed technical specifications for the Csasan V90 Wireless Sport Earbuds:

Feature	Detail
Model Name	V90
Brand	Csasan
Connectivity Technology	Wireless (Bluetooth 5.3)
Ear Placement	Over Ear
Form Factor	In Ear
Control Type	Touch Control
Waterproof Rating	IP7
Battery Life (Earbuds)	Up to 8 hours on a single charge
Total Playtime (with Charging Case)	Up to 48 hours
Charging Time	Approx. 1.5 hours (for charging case)
Audio Driver Size	13 mm
Noise Control	None (Features CVC8.0 noise reduction for calls)
Item Weight	3.52 ounces (0.1 Kilograms)



Image: Key features of the Csasan V90 earbuds, including Bluetooth 5.3, 13mm drivers, and enhanced bass.



Image: Illustration of the Environmental Noise Cancellation (ENC) technology, showing its effect on reducing ambient noise for clearer calls.

Warranty and Support

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official Csasan website. Keep your proof of purchase for warranty claims.

Manufacturer: Csasan
Model: V90
ASIN: B0CW9PLZC5

© 2024 Csasan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CW9PLZC5

More documents and user manuals: **https://manuals.plus/**