Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HONOR Magic6 Pro

HONOR Magic6 Pro Smartphone User Manual

Model: BVL-N94

1. Introduction

This manual provides essential information for setting up, operating, and maintaining your HONOR Magic6 Pro smartphone. Please read this guide thoroughly to ensure proper use and to maximize the device's capabilities. The HONOR Magic6 Pro features a powerful 3.3 GHz Octa-core processor, 12GB of RAM, 512GB of internal storage, and runs on Android 14, powered by a 5600 mAh non-removable battery.

2. What's in the Box

Upon unboxing your HONOR Magic6 Pro, please verify that all items are present:

- HONOR Magic6 Pro Smartphone
- USB Cable





Image 1: Front view of the HONOR Magic6 Pro smartphone, showcasing its display.

3. Initial Setup

3.1. SIM Card Installation

The HONOR Magic6 Pro supports Dual SIM functionality. To install your SIM cards:

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejector tool (not included, typically found with your network provider's SIM card) into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM cards into the designated slots on the tray, ensuring the gold contacts face downwards and the notched corner aligns correctly.

4. Carefully push the SIM tray back into the phone until it is flush with the device's side.





Image 2: Side view of the HONOR Magic6 Pro, illustrating the location of the SIM card tray and physical buttons.

3.2. Powering On and Initial Configuration

To power on your device for the first time:

1. Press and hold the Power button (located on the right side) until the HONOR logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. You may also be prompted to transfer data from an old device or set up security features like fingerprint or facial recognition.

4. Operating Your Device

4.1. Basic Navigation

Your HONOR Magic6 Pro uses a touchscreen interface for most interactions:

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on photos and web pages.
- **Power Button:** Press to wake/sleep the screen; press and hold to power off or restart.
- **Volume Buttons:** Adjust media volume, call volume, or ringtone volume.

4.2. Calls and Messaging

To make a call, open the Phone app and dial the number or select a contact. To send a message, open the Messages app, tap to compose a new message, enter the recipient and your text.

4.3. Camera Functions

The HONOR Magic6 Pro is equipped with advanced front and rear cameras. Open the Camera app to capture photos and videos. You can switch between front and rear cameras, select different modes (e.g., Portrait, Night, Pro), and adjust settings.





Image 3: Rear view of the HONOR Magic6 Pro, highlighting the prominent camera module.

4.4. Connectivity

Your device supports various connectivity options:

- **Wi-Fi:** Connect to wireless networks for internet access. Go to Settings > Network & internet > Wi-Fi.
- **Bluetooth:** Pair with wireless headphones, speakers, and other devices. Go to Settings > Connected devices > Bluetooth.
- **Mobile Data (2G/3G/4G LTE/5G):** Access the internet via your cellular network. Ensure your SIM card is active and mobile data is enabled in Settings > Network & internet > Mobile network.

4.5. Dual SIM Management

With Dual SIM functionality, you can use two different phone numbers or network providers simultaneously. Manage your preferred SIM for calls, messages, and mobile data in Settings > Network & internet > SIMs.

5. Care and Maintenance

5.1. Battery Management

To optimize battery life:

- Avoid extreme temperatures.
- Use the provided USB cable for charging.
- Enable battery saver mode when needed.
- Close unused apps running in the background.

5.2. Software Updates

Regularly check for software updates to ensure your device has the latest features and security patches. Go to Settings > System > System update.

5.3. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials.

6. Troubleshooting

If you encounter issues with your HONOR Magic6 Pro, try the following common solutions:

- **Device not responding:** Press and hold the Power button for about 10 seconds to force a restart.
- **Network issues:** Check if your SIM card is properly inserted. Toggle Airplane Mode on and off. Restart your device. Verify network settings.
- **Apps crashing:** Clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). If the issue persists, try reinstalling the app.
- **Battery draining quickly:** Review battery usage in Settings > Battery. Reduce screen brightness, disable unnecessary features (GPS, Bluetooth, Wi-Fi) when not in use.
- **Charging problems:** Ensure the USB cable is securely connected to both the phone and the power adapter. Try a different USB cable or power source.

For more complex issues, consult the official HONOR support website or contact customer service.

7. Technical Specifications

Feature	Specification
Model Name	HONOR Magic6 Pro
Model Number	BVL-N94
Operating System	Android 14
CPU Model	Snapdragon S4
CPU Speed	3.3 GHz
RAM	12 GB
Internal Storage	512 GB
Screen Size	6.8 Inches
Resolution	1280 x 2800
Refresh Rate	120 Hz
Battery Capacity	5600 mAh (non-removable)
Connectivity	2G, 3G, 4G LTE, 5G, Wi-Fi, Bluetooth, GPS
Special Features	Dual SIM
Dimensions	7.17 x 3.78 x 1.46 inches (Package)
Item Weight	14.4 ounces
Color	Black
Audio Jack	No headphone jack

8. Warranty Information and Support

Your HONOR Magic6 Pro is covered by a limited warranty. For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official HONOR website. For technical support, software updates, and service inquiries, please visit the HONOR support portal or contact their customer service directly.

© 2024 HONOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CW9Q16J4

More documents and user manuals: **https://manuals.plus/**