

[Manuals.plus](#) /

> [ADEKO Kids](#) /

> ADEKO Kids Bed CPD 120x180 User Manual

ADEKO Kids CPD

ADEKO Kids Bed CPD 120x180 User Manual

Model: CPD 120x180

1. PRODUCT OVERVIEW

Thank you for choosing the ADEKO Kids Bed Model CPD 120x180. This manual provides essential information for the safe assembly, use, and maintenance of your new children's bed. Please read all instructions carefully before beginning assembly.



Image 1.1: The ADEKO Kids Bed Model CPD 120x180, showcasing its natural wood finish and sturdy design.

Key Features:

- **Robust Construction:** Made from durable, smoothly sanded, and brushed wood to prevent splinters.
- **Child-Safe Design:** Rounded edges to minimize injury risk.
- **High Weight Capacity:** Supports up to 90 kg, suitable for children aged 3 years and older.
- **Integrated Slatted Frame:** A sturdy slatted frame is included for optimal mattress support and air circulation.
- **Easy Assembly:** Designed for straightforward assembly with included hardware.

2. SAFETY INFORMATION

Child safety is our top priority. Please adhere to the following safety guidelines:

- Always ensure all bolts and dowels are securely tightened during assembly and periodically check for looseness.
- The bed is designed for children aged 3 years and older.
- Do not exceed the maximum weight capacity of 90 kg.
- Keep small parts away from young children during assembly to prevent choking hazards.
- Ensure the bed is placed on a flat, stable surface.
- Regularly inspect the bed for any signs of wear or damage. Discontinue use if any structural damage is found.



Image 2.1: Icons representing product safety and suitability for children.

3. COMPONENTS AND PACKAGE CONTENTS

Before starting assembly, verify that all parts are present and undamaged. The package includes:

- Bed frame components (headboard, footboard, side rails)
- Slatted frame
- Assembly kit (bolts, dowels, and necessary tools if provided)
- QR code for online instructions

If any parts are missing or damaged, please contact ADEKO Kids customer support before proceeding with assembly.

4. SETUP AND ASSEMBLY

The ADEKO Kids Bed is designed for easy assembly. For environmental reasons, printed instructions are not included. Detailed assembly instructions are available online. Please scan the QR code provided in the packaging or visit the ADEKO Kids website for a step-by-step guide.



Image 4.1: Icon indicating online instructions are available.

General Assembly Tips:

- Clear a spacious area for assembly.
- Lay out all components and hardware before starting.
- Follow the online instructions precisely.
- Do not overtighten bolts, but ensure they are snug.
- It is recommended to have two people for assembly.

5. USAGE AND OPERATION

Mattress Requirements:

A mattress is not included with this bed. The mattress must have dimensions of **120x180 cm**. The maximum recommended mattress height is **12 cm**, and the minimum recommended thickness is **8 cm** to ensure proper fit and safety within the bed frame.



Image 5.1: Detail of a mattress tag, indicating mattress compatibility.

Weight Capacity:

The bed is designed to support a maximum weight of 90 kg. This capacity includes the weight of the child and the mattress.



Image 5.2: Icon representing the weight capacity of the bed.

Slatted Frame:

The included slatted frame provides essential support for the mattress, ensuring even weight distribution and promoting healthy sleep. Ensure the slats are correctly installed and secured according to the assembly instructions.




Image 5.3: Close-up view of the slatted frame providing mattress support.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your ADEKO Kids Bed, follow these care instructions:

- **Cleaning:** Wipe the wooden surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they can damage the wood finish.
- **Dusting:** Regularly dust the bed with a dry, soft cloth.
- **Inspection:** Periodically check all bolts and connections to ensure they remain tight. Retighten if necessary.
- **Environmental Conditions:** Avoid placing the bed in direct sunlight or near heat sources, as this can cause the wood to dry out, crack, or warp. Maintain a stable room temperature and humidity.



Image 6.1: Icon indicating the use of responsibly sourced wood (FSC certified).

7. TROUBLESHOOTING

If you encounter any issues with your ADEKO Kids Bed, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose bolts or uneven floor.	Check and tighten all assembly bolts. Ensure the bed is on a level surface.
Slats are creaking or shifting.	Slats not properly seated or damaged.	Verify that each slat is correctly placed in its holder. Replace any damaged slats.

Problem	Possible Cause	Solution
Difficulty assembling a part.	Incorrect orientation or missing hardware.	Refer to the online assembly instructions. Ensure parts are oriented correctly. Check for all necessary hardware.

If the problem persists after attempting these solutions, please contact ADEKO Kids customer support for further assistance.

8. PRODUCT SPECIFICATIONS

Specification	Detail
Brand	ADEKO Kids
Model Number	CPD
Product Dimensions (L x W x H)	189 x 126 x 42 cm
Item Weight	25 Kilograms
Recommended Mattress Size	120x180 cm (max height 12 cm, min thickness 8 cm)
Finish Type	Wood (Pine)
Assembly Required	Yes
Included Components	Installation Manual (online), Slatted Frame

BED/MATTRESS	
120X180	
A	LENGTH
189 cm	
B	WIDTH
126 cm	
C	HEIGHT
44,7 cm	




Image 8.1: Detailed dimensions diagram for the ADEKO Kids Bed Model CPD 120x180.

9. WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the terms and conditions provided at the time of purchase or visit the official ADEKO Kids website. ADEKO Kids is committed to providing high-quality products and customer satisfaction.

Customer Support:

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact ADEKO Kids customer support through the retailer's platform or the official brand website. Please have your product model number (CPD) and purchase details ready when contacting support.

© 2024 ADEKO Kids. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question