

[Manuals.plus](#) /

> [Nuby](#) /

> Nuby Mini Gripper No-Spill Baby Sippy Cups with Soft Spout - 6 oz - 6+ Months Instruction Manual

Nuby Mini Gripper No-Spill Baby Sippy Cups

Nuby Mini Gripper No-Spill Baby Sippy Cups with Soft Spout

Model: Mini Gripper

INTRODUCTION

The Nuby Mini Gripper Soft Spout Sippy Cup is designed to assist babies aged 6+ months in transitioning to independent drinking. These cups feature a soft silicone spout gentle on gums and teeth, and a no-spill valve to prevent leaks, making them ideal for everyday use at home or on the go.

SAFETY GUIDELINES

- Always supervise children during use.
- Before each use, inspect the product. Discard at the first sign of damage or weakness.
- Do not use abrasive cleaning agents or scourers.
- Do not store in direct sunlight or near a heat source.
- Keep all components not in use out of children's reach.
- This product is not a toy.
- Ensure all parts are correctly assembled before use to prevent leaks.
- This product is BPA Free.

PACKAGE CONTENTS

Each pack contains three (3) Nuby Mini Gripper No-Spill Baby Sippy Cups.

- 3 x Cup Bases (6 oz / 180 mL capacity)
- 3 x Soft Silicone Spouts
- 3 x Screw Rings



Image: Three Nuby Mini Gripper Sippy Cups in pink, purple, and aqua colors, showcasing the complete product set.

SETUP AND ASSEMBLY

1. Before first use, disassemble all components and clean thoroughly.
2. Insert the soft silicone spout into the screw ring from the top. Ensure the spout is pulled through completely and seated firmly.
3. Fill the cup base with the desired liquid (water, milk, or juice) up to the 6 oz (180 mL) mark. Do not overfill.
4. Screw the assembled spout and ring onto the cup base until secure. Do not overtighten.

6 oz
180 ml | 6⁺m

**SOFT
SILICONE**



Soft Spout


Soft silicone spout is gentle on gums and teeth while remaining resistant to bites

Image: A close-up of the soft silicone spout, highlighting its design for gentle use on gums and teeth.

OPERATING INSTRUCTIONS

The Nuby Mini Gripper Sippy Cup is designed for easy use by babies 6 months and older.

- Offer the cup to your child. The contoured shape and textured grooves are designed for small hands to grip easily.
- The built-in TOUCH-FLO™ valve in the soft silicone spout is pressure-sensitive. It opens only when your child sips and closes when they stop, preventing drips and spills.



Touch-Flo

Pressure-sensitive touch-flo silicone spout helps prevent leaks and is gentle on gums & teeth

Image: A young child happily drinking from a Nuby Mini Gripper Sippy Cup, illustrating the ease of use and soft spout.



Mini Gripper

Nuby's Mini Grippers are designed specifically for the smallest hands, featuring a smaller profile for extra help with gripping and holding

Image: A graphic detailing the Touch-Flo pressure-sensitive silicone spout, which helps prevent leaks and is gentle on gums and teeth.

Your browser does not support the video tag.

Video: Official product video demonstrating the features and use of the Nuby Mini Gripper Sippy Cups, including the soft spout and no-spill technology.

MAINTENANCE AND CLEANING

- Disassemble all parts before cleaning.
- Wash all components in warm, soapy water or on the top rack of a dishwasher.
- Rinse thoroughly with clean water.
- Allow to air dry completely before reassembling or storing.
- Sterilization: This product is suitable for sterilization by boiling, steam, or cold water sterilization methods.



Image: A graphic illustrating the Mini Gripper's size, specifically designed for tiny hands still developing their grip, compared to a full-size cup.

TROUBLESHOOTING

Leaking

- **Issue:** Cup leaks when inverted or shaken.
- **Solution:** Ensure the silicone spout is correctly seated within the screw ring and the screw ring is tightened securely onto the cup base. The TOUCH-FLO™ valve relies on proper assembly for its no-spill function.
- **Issue:** Liquid drips from the vent hole.
- **Solution:** This can occur if the valve is not fully closed or if the cup is subjected to extreme pressure changes. Ensure the spout is clean and free from debris.

Difficulty Drinking

- **Issue:** Child struggles to get liquid from the spout.
- **Solution:** Ensure the child is applying a gentle sucking action. The TOUCH-FLO™ valve requires suction to open. Check that the spout is not blocked by food particles or debris.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Nuby
Model	Mini Gripper
Capacity	6 oz (180 mL)
Recommended Age	6+ Months
Material	BPA Free
Dishwasher Safe	Yes (Top Rack)
Microwaveable	Yes
Liquid Flow Speed	Medium Flow
Item Weight	0.12 Pounds
UPC	039175810459

WARRANTY AND CUSTOMER SUPPORT

Nuby products are manufactured to high-quality standards. For any questions, concerns, or warranty information, please refer to the official Nuby website or contact their customer support directly. Keep your purchase receipt for proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CW9YXS3S>

More documents and user manuals: <https://manuals.plus/>