

uscce UE-268-Gray

uscce Alarm Clock Bluetooth FM Radio Instruction Manual

Model: UE-268-Gray

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your uscce Alarm Clock Bluetooth FM Radio. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Figure 1: The uscce Alarm Clock Bluetooth FM Radio with a smartphone placed on its wireless charging pad.

KEY FEATURES

- **Versatile Multifunctional Device:** Bluetooth speaker alarm clock with 10W fast wireless charger station, built-in FM radio, and 7-color night light.
- **Exceptional Audio Quality:** Enjoy superior sound with the 10W stereo Bluetooth speaker for a rich and immersive audio experience.
- **Powering Devices While You Sleep:** Convenient wireless charging and an extra USB charging port ensure your devices are fully charged.
- **0-100% Display Dimmer:** Customize the brightness of the display to your personal comfort.
- **7 Color Night Light with Adjustable Brightness:** Choose from seven vibrant colors and adjust brightness for ambiance.
- **Stylish Modern Design:** A combination of fabric and wooden finish offers a contemporary and fashionable appearance.



Figure 2: Overview of the uscce Alarm Clock's all-in-one functionalities.

SETUP GUIDE

1. Power Connection

Connect the provided power adapter to the DC IN port on the back of the alarm clock. Plug the adapter into a standard wall outlet. The display will light up, indicating the device is powered on.




Figure 3: Rear view of the alarm clock, highlighting the power input and USB charging port.

2. Setting the Time

1. Press and hold the "TIME SET" button (usually marked with a clock icon) until the hour digits begin to flash.
2. Use the "HOUR" and "MINUTE" buttons to adjust the time.
3. Press "TIME SET" again to confirm and exit time setting mode.

3. Setting the Alarm

1. Press and hold the "ALARM" button (usually marked with an alarm bell icon) until the alarm time digits begin to flash.
2. Use the "HOUR" and "MINUTE" buttons to set your desired alarm time.
3. Press "ALARM" again to confirm. You may be prompted to select an alarm sound or radio station.
4. To activate/deactivate the alarm, short press the "ALARM" button. An alarm icon will appear/disappear on the display.

OPERATING INSTRUCTIONS

1. Display Dimmer

The display brightness can be adjusted from 0% to 100% to suit your preference. Locate the dimmer switch or button, typically on the back or side of the unit, and slide or press it to change the brightness level.



☀️ - 0-100% Dimmable Display

Customize the brightness of the display to match the lighting of the room



Figure 4: Visual representation of the 0-100% dimmable display feature.

2. Night Light Operation

The alarm clock features a 7-color night light. Press the "LIGHT" button (often marked with SNOOZE/LIGHT) to cycle through the available colors. Hold the button to adjust the brightness of the night light.



Figure 5: The alarm clock showcasing its 7-color night light options.

3. Wireless Charging

Place your Qi-compatible smartphone or wireless earbuds on the designated wireless charging pad on top of the alarm clock. Ensure the device is centered on the charging pad for optimal charging. A charging indicator will typically appear on the clock's display or your device's screen.



 - **Wireless Charging**

 - **USB Charging**

:

2 Ways to charge your devices while you sleep

Figure 6: Demonstrating both wireless and USB charging capabilities of the alarm clock.

4. USB Charging

An additional USB charging port is located on the back of the unit. Connect your device's USB charging cable to this port to charge non-wireless charging compatible devices.

5. FM Radio Operation

To activate the FM radio, press the "FM" button (often marked with a radio icon). Use the "TUNE +/-" buttons to manually tune to your desired station. For better reception, extend the FM antenna located at the back of the unit.



- Digital FM Radio

Enjoy your favorite channels, music, or news



Figure 7: The alarm clock displaying an FM radio frequency.

6. Bluetooth Speaker Pairing

Press the "BT" button to enter Bluetooth pairing mode. The display will show "BT" or a flashing Bluetooth icon. On your smartphone or other Bluetooth-enabled device, search for "uscce Alarm Clock" (or similar name) in the Bluetooth settings and select it to pair. Once paired, you can stream audio wirelessly to the alarm clock's 10W stereo speakers.



- 10W Powerful Bluetooth Speaker

Delivers high-fidelity stereo sounds

Figure 8: Internal view highlighting the 10W powerful Bluetooth speakers.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the alarm clock. Do not use liquid cleaners or abrasive materials.
- **Storage:** If storing the device for an extended period, disconnect it from power and store it in a cool, dry place.
- **Avoid Water:** Keep the device away from water and high humidity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/Display off	Power adapter not connected or outlet not working.	Ensure power adapter is securely plugged in and try a different outlet.

Problem	Possible Cause	Solution
Wireless charging not working	Device not Qi-compatible, not centered, or thick case.	Ensure device supports Qi wireless charging. Reposition device. Remove thick phone cases (over 3mm).
Poor FM radio reception	Antenna not extended or local interference.	Fully extend the FM antenna. Try repositioning the unit.
Bluetooth not pairing	Device not in pairing mode or too far.	Ensure the alarm clock is in Bluetooth pairing mode. Keep devices within 10 meters.

SPECIFICATIONS

Brand: uscce

Model: UE-268-Gray

Color: Gray - White Digits

Display Type: Digital

Special Features: Bluetooth, Wireless Charging, Nightlight, Dimmable

Product Dimensions: 3.5"W x 2.96"H

Power Source: Corded Electric

Frame Material: Wood

Item Weight: 1.23 pounds (556.38 Grams)

UPC: 768561057498

Warranty Type: 18-month Warranty

WARRANTY AND SUPPORT

Your uscce Alarm Clock Bluetooth FM Radio comes with an 18-month warranty. For any support inquiries, troubleshooting assistance, or warranty claims, please visit the official uscce Store on Amazon or contact customer service through your purchase platform.

Official Store Link: [Visit the uscce Store](#)