

Menegotti MEL1800W

Menegotti MEL1800W Electric Mixer and Trowel Kit Instruction Manual

Model: MEL1800W

1. INTRODUCTION

Thank you for choosing the Menegotti MEL1800W Electric Mixer and Trowel Kit. This manual provides essential information for the safe operation, assembly, maintenance, and troubleshooting of your new tool. Please read this manual carefully before use to ensure optimal performance and safety.

This kit is designed for efficient mixing of various construction materials such as mortars, glues, paints, plaster, grouts, and waterproofing agents. The accompanying trowels are ideal for finishing and leveling surfaces, particularly for ceramic and porcelain tile installations.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury when using this power tool.

- **Electrical Safety:** Ensure the power supply voltage matches the tool's specified voltage (220 Volts). Do not use the mixer in wet conditions or expose it to rain. Always use a ground fault circuit interrupter (GFCI) when operating in damp locations.
- **Personal Protective Equipment:** Wear appropriate safety gear, including eye protection, hearing protection, and gloves. Avoid loose clothing that could get caught in moving parts.
- **Work Area:** Keep your work area clean and well-lit. Cluttered or dark areas invite accidents. Keep children and bystanders away while operating the tool.
- **Secure Grip:** Always maintain a firm grip on the mixer handles during operation. The dual shaft design requires stable handling.
- **Material Safety Data Sheets (MSDS):** When mixing chemicals or hazardous materials, always consult the manufacturer's MSDS for specific safety precautions and ventilation requirements.
- **Before Adjustments:** Disconnect the mixer from the power source before making any adjustments, changing accessories, or storing the tool.
- **Inspect Tool:** Before each use, inspect the mixer, power cord, and mixing paddles for any damage. Do not use a damaged tool.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present and undamaged. If any items are missing or damaged, please contact your retailer.

- 1 x Menegotti MEL1800W Electric Mixer
- 1 x Dual Mixing Paddle
- 1 x Paddle Extender
- 1 x Fixed Wrench for assembly
- 1 x Instruction Manual (this document)
- 1 x Stainless Steel Trowel (27 x 12 cm)
- 1 x Stainless Steel Trowel (35 x 15 cm)
- 1 x Stainless Steel Trowel (43 x 18 cm)



Image 3.1: Overview of the Menegotti MEL1800W Electric Mixer and Trowel Kit, showing the mixer unit, dual mixing paddles, and three different sized trowels.

4. SETUP AND ASSEMBLY

Before assembly, ensure the mixer is disconnected from the power supply.

1. **Attach the Paddle Extender:** If desired, screw the paddle extender onto the mixing paddle. Ensure it is securely tightened.
2. **Install Mixing Paddle:** Insert the assembled mixing paddle (with or without extender) into the mixer's chuck. Use the provided fixed wrench to securely tighten the chuck, ensuring the paddle is firmly seated and centered. Repeat for the second paddle.
3. **Power Connection:** Before plugging in the mixer, verify that your electrical outlet provides 220 Volts.




Image 4.1: Diagram illustrating the dimensions of the Menegotti MEL1800W Electric Mixer with paddles attached, showing overall height, width, and paddle length.

5. OPERATING INSTRUCTIONS

5.1. Mixer Operation

1. **Material Preparation:** Place the material to be mixed into a suitable, sturdy mixing container. Ensure the container is large enough to prevent splashing.
2. **Power On/Off:** Plug the mixer into a 220V power outlet. Press the ON/OFF button to start or stop the mixer.
3. **Speed Control:** The mixer features 6 variable speed levels. Use the speed adjustment dial to select the appropriate speed for your material. Start at a lower speed to prevent splashing and gradually increase as needed. The maximum rotation speed is 700 rpm.
4. **Lock Button:** For continuous operation, press the lock button after starting the mixer. Press the ON/OFF button again to release the lock.
5. **Mixing Technique:** Immerse the mixing paddles fully into the material before starting. Move the mixer slowly through the material, ensuring thorough and homogeneous mixing. Avoid hitting the sides or bottom of the container forcefully.
6. **Overload Protection:** If the mixer experiences excessive resistance, it may slow down or stop. Reduce the load or adjust the speed. Continuous overloading can damage the motor.

MEDIDAS



SOLUÇÕES EM FERRAMENTAS

Image 5.1: Close-up view of the Menegotti MEL1800W Electric Mixer's control panel, highlighting the ON/OFF button, lock button, and speed adjustment dial.

5.2. Trowel Usage

The kit includes three stainless steel trowels of different sizes (27x12 cm, 35x15 cm, 43x18 cm) for various applications.

1. **Material Application:** Use the trowel to scoop and spread mixed materials such as mortar or adhesive onto the surface.
2. **Notched Edge:** The notched edge of the trowel is used to create uniform ridges in the material, ensuring proper adhesion and coverage for tiles or other finishes.
3. **Flat Edge:** The flat edge can be used for smoothing, leveling, and removing excess material.
4. **Cleaning:** Clean the trowels immediately after use to prevent material from hardening on the blade.




Image 5.2: A set of three stainless steel trowels with black handles, varying in size, included in the kit.



Image 5.3: A hand holding a trowel, demonstrating its ergonomic handle, alongside close-up views of the notched edges for spreading adhesive.



Image 5.4: Diagram showing the dimensions of a trowel (27mm width, 270mm length) and highlighting its construction with special galvanized steel and four screw fixings.

6. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and safe operation of your tools.

- **Cleaning the Mixer:** After each use, disconnect the mixer from the power supply. Remove the mixing paddles and clean them thoroughly with water and a brush before the material hardens. Wipe down the mixer body with a damp cloth. Do not use harsh chemicals or immerse the mixer in water.
- **Cleaning Trowels:** Immediately after use, scrape off any excess material from the trowels. Wash them with water and soap, ensuring all notches are clean. Dry thoroughly to prevent rust.
- **Storage:** Store the mixer and trowels in a dry, clean place, away from direct sunlight and extreme temperatures. Keep them out of reach of children.
- **Inspection:** Regularly inspect the power cord for cuts or damage. Check the mixing paddles for wear or bending.

Replace damaged parts immediately.

7. TROUBLESHOOTING

If you encounter issues with your Menegotti MEL1800W Electric Mixer, refer to the following common problems and solutions:

• **Mixer Does Not Start:**

- Check if the power cord is securely plugged into a 220V outlet.
- Verify that the power outlet is functional (test with another appliance).
- Ensure the ON/OFF button is fully pressed.
- Check for any tripped circuit breakers or blown fuses.

• **Poor Mixing Performance:**

- Ensure the mixing paddles are securely attached and not loose.
- Adjust the speed setting to match the material's consistency. Thicker materials may require lower speeds.
- Check if the paddles are worn or bent and replace if necessary.
- Ensure the material quantity is within the mixer's capacity.

• **Excessive Vibration or Noise:**

- Check if the mixing paddles are properly balanced and securely tightened.
- Inspect paddles for damage or bending.
- Ensure the mixer is not overloaded.

If the problem persists after attempting these solutions, please contact customer support.

8. TECHNICAL SPECIFICATIONS

Feature	Specification
Model	MEL1800W
Brand	Menegotti
Power	1800W
Voltage	220 Volts
Frequency	60 Hz
Max Rotation Speed	700 rpm
Speed Levels	6 (Variable)
Mixing System	Dual Shaft
Material (Mixer)	Plastic, Galvanized Steel

Feature	Specification
Material (Trowels)	Stainless Steel
Product Dimensions (Mixer)	46 x 39 x 15 cm (Length x Width x Height)
Product Weight (Mixer)	Approximately 5.8 kg

TENSÃO

127V OU 220V

FREQUÊNCIA

60 Hz

POTÊNCIA

1800W

VELOCIDADE ROTAÇÃO

700 rpm

ISOLAÇÃO

Dupla isolação

CLASSE DE PROTEÇÃO

II

PESO

5,3kg





SOLUÇÕES EM FERRAMENTAS

Image 8.1: Graphic displaying key technical specifications of the Menegotti MEL1800W Electric Mixer, including voltage, frequency, power, rotation speed, insulation, protection class, and weight.

9. WARRANTY INFORMATION

This Menegotti MEL1800W Electric Mixer and Trowel Kit comes with a manufacturer's warranty against defects in materials and workmanship. The specific duration and terms of the warranty may vary. Please refer to your purchase receipt or contact your retailer for detailed warranty information.

Extended warranty options may also be available for purchase. Consult your retailer for details on extended coverage plans.

10. CUSTOMER SUPPORT

For technical assistance, spare parts, or any questions regarding the operation or maintenance of your Menegotti MEL1800W Electric Mixer and Trowel Kit, please contact the retailer where you purchased the product. They will be able to provide guidance or direct you to the appropriate service center.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question